

## **REPAIR PARTS MANUAL** MODEL NO. WZ125H92B Lawn Tractor

# UIZARD

532 19 02-37 01.21.04 TR PRINTED IN U.S.A.

## HOW TO USE THIS MANUAL

This manual is designed to provide the customer with a means to identify the parts on his/her tractor when ordering repair parts. The illustrations may or may not represent the actual assemblies; therefore, it is not recommended to use this manual as a guide to assemble or disassemble the tractor. Some hardware and parts are drawn larger in order to more readily identify them.

Each tractor has its own model number.

The model number for your tractor can be found on the fender under the seat.


When ordering parts, always give the following information:

- Product "Lawn Tractor"
- Model Number WZ125H92B
- Part Number
- Part Description


## **TABLE OF CONTENTS**

SCHEMATIC	3
ELECTRICAL	4-5
CHASSIS AND ENCLOSURES	6-7
DRIVE	
STEERING WHEEL	10-11
SEAT	
DECALS	
ENGINE	
MOWER LIFT	
MOWER DECK	
WARRANTY	

#### TRACTOR - - MODEL NUMBER WZ125H92B, PRODUCT NO. 964 77 38-02 SCHEMATIC



TRACTOR - - MODEL NUMBER WZ125H92B, PRODUCT NO. 964 77 38-02 ELECTRICAL




TRACTOR - - MODEL NUMBER WZ125H92B, PRODUCT NO. 964 77 38-02 ELECTRICAL

	PART NO.	DESCRIPTION
1	532 16 34-65	Battery
2 8	874 76 04-12	Bolt Hex Hd 1/4-20 unc x 3/4
	532 17 66-89	Box Battery Fender
16	532 17 61-38	Switch Interlock
21	532 18 37-59	Harness Asm. Light
22	532 12 46-70	Bulb
24	532 12 47-80	Cable Battery 6 Ga. 11" Red
25	532 14 61-47	Cable Battery 6 Ga. Red w/16 wir
26	532 17 51-58	Fuse
27	873 51 04-00	Nut Keps Hex 1/4-20 unc
28	532 12 47-73	Cable Ground 6 Ga. 12" black
29	532 12 13-05	Switch Plunger Nc Gray
30	532 17 55-66	Switch Ign
33	532 14 04-01	Key
40	532 17 97-20	Harness Ign.
41	871 11 04-08	Bolt Blk Fin Hex 1/4 - 20 x 1/2
42	532 13 15-63	Cover Terminal Red
43	532 17 88-61	Solenoid
48	532 14 08-44	Adapter Ammeter Rectangular
52		Protection Wire Loop
90		Cover Terminal Battery
		ant dimonsions given in LLS inches

**NOTE:** All component dimensions given in U.S. inches. 1 inch = 25.4 mm.

TRACTOR - - MODEL NUMBER WZ125H92B, PRODUCT NO. 964 77 38-02 CHASSIS




TRACTOR - - MODEL NUMBER WZ125H92B, PRODUCT NO. 964 77 38-02 CHASSIS

KEY NO.	PART NO.	DESCRIPTION
1 2 5 6 8 9 10 11 13 15 16 17 18 24 25 26 28 29 30 31 33 34	532 18 44-19 532 15 51-38 532 18 54-80 872 14 06-08 532 17 49-96 532 18 69-52 874 18 05-12 873 51 05-00 532 18 67-07 532 12 69-38 874 78 06-16 819 13 13-12 873 80 06-00 532 18 38-26 532 18 98-37 532 17 45-11	Drawbar BumperHood/Dash Saddle Clip, Retainer Slide-On Dash Bolt, Carriage 3/8-16 x 1 Dashboard, Panel LH Dashboard, Panel RH Machine screw 5/16-18 unc x 3/4 Nut, Keps 5/16-18 unc Hood Pnt BumperHood Bolt, Hex Head, Fin. 3/8-16 x 1 Gr. 5 Washer 13/32 x 13/16 x 12 Ga. Nut Lock Hex w/Ins. 3/8-16 unc Grille (Includes key nos. 29 & 212) Lens Grille Fender Fender Fender Bracket Footrest, LH
35 37 38 39 145 166 205 206 208 209 212	872 11 06-06 817 49 05-08 532 17 57-10 532 17 47-14 532 15 65-24 532 17 18-75 817 49 06-08 532 17 01-65 817 67 06-08 817 00 06-12	Bolt 3/8-16 x 3/4 Screw Thdrol 5/16-18 x 1/2 Bracket Asm. Pivot Mower Rear Bracket Pivot Rod Pivot Chassis/Hood Screw Hi-Lo #13-16 x 3/4 Screw Thdrol 3/8-16 x 1/2 Bolt Shoulder 5/16-18 TT Screw Thdrol 3/8-16 x 1/2 Screw Hexwsh Thdr 3/8-16 x 3/4 Insert Lens Reflective

**NOTE:** All component dimensions given in U.S. inches. 1 inch = 25.4 mm.


TRACTOR - - MODEL NUMBER WZ125H92B, PRODUCT NO. 964 77 38-02 DRIVE



## TRACTOR - - MODEL NUMBER WZ125H92B, PRODUCT NO. 964 77 38-02 DRIVE

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1		Transaxle Hydro Gr 322-0510 (Order parts from transaxle manu-	71 73		Strap Torque Lh Hydro Strap Torque Rh Hydro
		facturer)	74	532 13 70-57	
8	532 16 56-19	Rod Shift Fender	75		Washer 25/32 x 1-1/4 x 16 Ga.
10		Pin Cotter 1/8 x 1 CAD	76	812 00 00-01	
14		Washer Lock Hvy Helical 1/4	77	532 12 35-83	Key, Square
15		Bolt Hex Flg Hd 5/16-18 x Gr.5	78		Washer 25/32 x 1-5/8 x 16 Ga.
16		Nut Lock Hex W/Ins. 5/16-18 unc P	81		Shaft Asm. Cross Hydro
19		Nut Lock Hex W/Wsh 3/8-16 unc	82		Spring Torsion T/A
21	532 10 69-33		83		Washer 17/32 x 3/4 x 16 Ga.
22		Rod, Brake Hydro	84		Link Transaxle
24 25	873 35 06-00		89 95		Console, Shift Control Asm Bypass Hydro
25 26	819 13 13-16	Spring, Brake Rod	95 96		Retainer Spring 1" Zinc/Cad
20 27		Pin Cotter 1/8 x 3/4 CAD.	103	873 94 08-00	Nut Hex Jam Toplock 1/2-20 unf
28		Rod, Parking Brake	112		Washer 9/32 x 3/4 x 10 Ga.
29		Cap, Parking Brake	116		Bolt 3/8-16 unc x 1
30		Bracket, Transaxle	120		Nut Lock 3/8-16 unc
32		Bolt Hex Hd 5/16-18 unc x 3/4	150		Spacer Retainer
34		Shaft, Foot Pedal	151		Washer 13/32 x 2 x 10 Ga.
35		Bearing, Nylon	156		Washer Srrtd 5/16 ID x 1.0 x .125
36	819 21 16-16	Washer			Tk
37	532 12 49-63		158	532 16 55-89	Bracket Shift Mount
38		Pulley, Idler, Composite	159	532 18 39-00	
39		Bolt Fin Hex 3/8-16 unc x 2-3/4	161		Bolt Rdhd Sqnk 1/4-20 x 3/4 Gr. 5
41		Keeper, Belt Idler	162		Nut Crownlock 1/4-20 unc
47		Pulley, Idler, V-Groove	163		Bolt Hex Fin 1/4-20 unc x 1 Gr. 5
48		Bellcrank Clutch Grnd Drv Stl	165		Bracket Pivot Lever
49		Retainer, Belt	166		Screw 5/16-18 x 5/8 TT Yellow
50		Bolt 3/8-16 unc x 1-1/2	168		Bolt Shoulder 5/16-18 x .561 TT
51		Nut Crownlock 3/8-16	169		Plate Fastening
52 53		Nut Crownlock 5/16-18	171 197		Screw Thdrl 3/8-16 x 1/2
53 55	532 10 57-10	Spring, Return, Clutch	197	532 16 98-45	Nyliner Snap-In 5/8" ID
55 56		Bolt Fin Hex 3/8-16 unc x 1-1/4	199		Bolt Shoulder 5/16-18 unc
50 57		V-Belt, Ground Drive	200		Bolt Rdhd Sqnk 5/16-18 unc x 1
59		Keeper, Center Span	202		Bolt Carr Sh 3/8-16 x 1-3/4 Gr. 5
61		Screw 3/8-16 x .875	205		Washer 17/32 x 1 x 16 Ga.
62	532 12 48-72		212		Nut Hexflange Lock
63	532 18 02-19		263		Screw 3/8-16 x 3/4
64		Bolt Hex 7/16-20 x 4 Gr. 5-1.5	268	532 18 24-02	Guard Muffler
65	810 04 07-00		275	819 13 16-14	Washer 13/32 x 1 x 14 Ga.
66		Keeper Belt Engine			
69		Screw Hex Wsh 1/4-1/2 unc	NOTE	: All compon	ent dimensions given in U.S. inches
70	532 18 02-18	Guide Belt Mower Drive RH		1 inch = 25.	.4 mm

TRACTOR - - MODEL NUMBER WZ125H92B, PRODUCT NO. 964 77 38-02 STEERING ASSEMBLY




TRACTOR - - MODEL NUMBER WZ125H92B, PRODUCT NO. 964 77 38-02 STEERING ASSEMBLY

KEY NO.	PART NO.	DESCRIPTION
1	532 17 59-04	Wheel Steering
2	532 17 51-31	
3		Spindle Asm LH
4	532 16 98-39	Spindle Asm RH
5		Bearing Race Thrust Harden
6		Washer 25/32 x 1-5/8 x 16 Ga
7		Washer 27/32 x 1-1/4 x 16 Ga
8	812 00 00-29	Ring Klip #t5304-75
9	532 12 49-37	Bearing Col Strg Blk
10	532 17 51-21	
11		Washer Lock Hvy Hici Spr 3/8
12	8/3 94 08-00	Nut Hex Jam Toplock 1/2-20 Unf
13 15		Spacer Brace Axle Nut Hexflange Lock
17		Shaft Asm Strg
26		Bushing Link Drag Blk LR
28	819 13 14-16	Washer 13/32 x 7/8 x 16 Ga
29	817 00 06-12	Screw 3/8-16 x .75
30		Pin Cotter 1/8 x 3/4 Cad
32		Rod Tie Wire Form 19 75 Mech
36		Bushing Strg Nat .623/.618Id
37		Screw TT #10-32 x 5 x 3/8 Flange
38	532 17 59-05	Cap Wheel Steer P/L
39		Washer 9/16 ID x 2-3/8 OD 12 Gr.
40		Nut crownlock 3/8-24
41 42		Adaptor Wheel Strg
42 43		Boot Shaft Steering Washer 25/32 x 1 1/4 x 16 Ga
43 44		Extension Steering
46		Cap Spindle Fr Top Blk
47		Fitting Grease
51		Nut Crownlock 1/4-28
54		Bolt Hex 1/4-28 Unf x 1-1/4 Gr. 8
65	532 16 03-67	Spacer Brace Axle
67		Bolt RDHD SQ 3/8-16 Unc x 2-1/4
68	532 16 98-27	
71		Steering Asm
82		Bracket Susp. Chassis Front
88		Bolt Shoulder 7/16-20
91 05	532 17 55-53	Cup Steering Washer Hardened
95	532 18 89-67	washer Hardened
NOTE	E: All compone	ent dimensions given in U.S. inches.

**NOTE:** All component dimensions given in U.S. inches. 1 inch = 25.4 mm.

TRACTOR - - MODEL NUMBER WZ125H92B, PRODUCT NO. 964 77 38-02 SEAT ASSEMBLY



#### **KEY PART**


#### DESCRIPTION NO. NO.

- 1 532 17 53-89 Seat 532 14 05-51 Bracket Pivot Seat 8 720 2
- 871 11 06-16 Bolt Fin Hex 3/8-16 unc x 1 3
- 819 13 16-10 Washer 13/32 x 1 x 10 Ga. 4
- 5 532 14 50-06 Clip Push-In
- 6 7
- 8
- 873 80 06-00 Nut Lock Hex w/Wsh 3/8-16 unc 532 12 41-81 Spring Seat Cprsn 2 250 Blk Zi 817 00 06-16 Screw 3/8-16 x 1.5 819 13 16-14 Washer 13/32 x 1 x 14 Ga. 9
- 10 532 18 24-93 Pan Seat
- 12
- 532 12 12-46 Bracket Mounting Switch 532 12 12-48 Bushing Snap Blk Nyl 50 Id 13


KEY NO.	PART NO.		DESCRIPTION
14			Bolt Rdhd Sht Nk 1/4-20 x 1-1/2
15	532 13	43-00	Spacer Split 28 x 96 Yel Zinc
16			Spring Cprsn 1 27 Blk Pnt
17	532 12	39-76	Nut Lock 1/4 Lge Flg Gr. 5 Zinc
21	532 17	18-52	Bolt Shoulder 5/16-18 unc -2A
22	873 80	05-00	Nut Lock Hex W/Insert 5/16-18 unc
23	871 11	08-14	Bolt Hex
24	819 17	19-12	Washer 17/32 x 1-3/16 x 12 Ga.
25	532 12	70-18	Bolt Shoulder 5/16-18 x 62
26	810 04	08-00	Washer Lock Hvy HLCLSPR 1/2

**NOTE:** All component dimensions given in U.S. inches. 1 inch = 25.4 mm

TRACTOR - - MODEL NUMBER WZ125H92B, PRODUCT NO. 964 77 38-02 DECALS




WHEELS & TIRES




part No.	DESCRIPTION	
532 06 532 10 532 05 532 18 532 12 532 12 532 12 532 18 532 10 532 12	51-39 Stem Valve 62-22 Tire F Ts 15 x 6 - 6 Service 99-04 Tube Front (Service Item Only) 33-37 Rim Asm 6" front Service 49-57 Fitting Grease (Front Wheel Only) 49-59 Bearing Flange (Front Wheel Only) 33-38 Rim Asm 8" rear Service 62-68 Tire R Ts 18 x 9.5-8 C. Service 49-26 Tube Rear (Service Item Only)	
	NO. 532 05 532 06 532 10 532 05 532 18 532 12 532 12 532 12 532 12 532 18 532 10 532 12	

**NOTE:** All component dimensions given in U.S. inches 1 inch = 25.4 mm

TRACTOR - - MODEL NUMBER WZ125H92B, PRODUCT NO. 964 77 38-02 ENGINE



TRACTOR - - MODEL NUMBER WZ125H92B, PRODUCT NO. 964 77 38-02 MOWER LIFT



KEY	PART	
NO.	NO.	DESCRIPTION

- 532 15 94-61 Wire Asm Inner W/Plunger 532 15 94-76 Shaft Asm Lift 1
- 2345678 532 18 88-22 Pin Groove

- 532 18 88-22 Pin Groove 812 00 00-02 E Ring #5133-62 819 21 16-21 Washer PLTD 21/32 x 1 x 21 Ga. 532 12 01-83 Bearing Nylon Blk 629 Id 532 10 94-13 Grip Handle Bicycle Matte Blk 532 12 45-26 Button Plunger Black 532 13 98-65 Link Lift LH


- 11
- 532 13 98-66 Link Lift RH 12
- 532 12 46-70 Retainer Spring 13

#### KEY PART NO. NO. DESCRIPTION

- 532 17 32-88 Link Front 15
- 873 35 08-00 Nut Jam Hex 1/2-13 unc 16
- 532 17 56-89 Trunnion 17
- 873 80 08-00 Nut Lock W/Wsh 1/2-13 unc 18
- 532 13 98-68 Arm Suspension Rear 19
- 532 16 35-52 Retainer Spring 532 16 98-65 Bearing Pvt Lift 20
- 31
- 873 54 06-00 Nut Crownlock 3/8-24 32

NOTE: All component dimensions given in U.S. inches 1 inch = 25.4 mm

TRACTOR - - MODEL NUMBER WZ125H92B, PRODUCT NO. 964 77 38-02 MOWER



#### TRACTOR - - MODEL NUMBER WZ125H92B, PRODUCT NO. 964 77 38-02 MOWER

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1		Mower Deck Assembly	53		Brake Assembly
2	872 14 05-06		54		Washer, Hardened
3		Bracket Assembly, Sway Bar	55		Idler Arm Assembly
4		Bracket Sway Bar	56		Spacer, Retainer
5		Retainer Spring	67		Knob RD 3/8-16 Plstc Thd
6		Bar Sway Deck	68	532 18 02-13	
7	532 14 06-08		89		Washer 13/32 x 13/16 x 11 Ga.
8		Bolt, Hex 3/8-24 x 1.25 Gr. 8	107		Spacer, Retainer
9		Washer, Lock Hvy Hlcl 3/8	108		Stiffener, Idler Arm
10 11		Washer,Hardened Blade, Mower	113 122		Screw Thdrol 5/16-18 x 1/2
13		Shaft Assembly, Mandrel, Vented	122		Rod, Brake, LH Rod, Brake, RH
14		Housing, Mandrel, Vented	146		Bolt Carriage Idler
15		Bearing, Ball, Mandrel	148		Spring Return Idler
16		Stripper, Mower Deck	149		Retainer Spring Yellow Zinc
19		Bolt, Shoulder	150		Washer $9/32 \times 3/4 \times 10$ Ga.
21		Nut Crownlock 5/16-18	152	532 17 60-79	
23		Bracket, Mower Deflector	158		Screw Hex Thd Cut 1/4-20 x 1/2
24	532 10 53-04		164		Bracket Asm Idler Support
25		Spring, Torsion, Deflector	168		Bracket Deck Cable
26	532 11 04-52		169	532 17 49-77	Bracket Asm Suspension
27	532 17 61-62	Shield, Deflector	170		Bracket Suspension RF
28	819 11 10-16	Washer 11/32 x 5/8 x 16 Ga.	171	532 16 52-37	Brace Support Susp. Frt
29	532 12 19-80	Rod, Hinge	172	532 17 23-55	Bracket Suspension LF
30	532 17 39-84	Screw Thdrol	185		Head Asm Cable Clutch
31		Washer, Spacer		532 13 07-94	Mandrel Assembly (Includes
32		Pulley, Mandrel			Housing, Shaft and Shaft Hardware
33		Nut, Toplock, Flanged			Only - Pulley Not Included)
34		Bolt Rdhd 3/8-16 x 1-3/4		532 18 13-76	Replacement Mower,Complete
36		Pulley, Idler, Flat	NOTE		ent dimensions given in U.S. inches
40		Nut Crownlock 3/8-16		1 = 25.4  mm	an amenaiona given in 0.0. Inches
45	532 12 47-88	Retainer, Spring	1 11101	- 20.4 mm	

## **SERVICE NOTES**





Issued January 1980 Revised January 1991

## SERVICE POLICY WARRANTY



#### LIMITED WARRANTIES FOR NEW PEERLESS GEAR POWER TRAIN COMPONENTS

#### A. Products Warranted

Peerless Gear and Machine Division of Tecumseh Products Company ("Tecumseh"), subject to the limitations contained below, will, at its option, repair or replace, without charge for parts or labor only, any part of a new Power Train Component (which as used herein means and includes the transaxle, gear box, transmission, differential and right angle drives, and any part of the Power Train Component), EXCEPT any new Power Train Component incorporated in equipment used for commercial or rental purposes, which is found upon examination by any Tecumseh Authorized Service Outlet or by Tecumseh's factory in Grafton, Wisconsin, to be DEFECTIVE IN MATERIAL AND/OR WORKMANSHIP if received by Tecumseh or a Tecumseh Authorized Service Outlet for such examination within TWO YEARS from the date of sale to the original consumer purchaser of Peerless Series 820, 900, 910, 915, 920, 930 transaxles and Series 1100 angle drive and ONE YEAR for all other Peerless products. New Power Train Components incorporated in equipment used for commercial purposes are warranted in the same manner and to the same extent EXCEPT such Power Train Components are warranted for NINETY (90) DAYS ONLY, and must be received by Tecumseh or by a Tecumseh Authorized Service Outlet for such examination within 90 days from the date of sale to the original purchaser. New Power Train Components Incorporated in equipment used for rental purposes are warranted in the same manner and to the same extent EXCEPT such Power Train Components are warranted for THIRTY (30) DAYS ONLY, and must be received by Tecumseh or a Tecumseh Authorized Service Outlet within 30 days from the date of sale to the original purchaser.

#### **B. Products And Items Not Warranted**

- 1. Alterations or Modifications of Power Train Components.
- 2. Accidents, Normal Maintenance, Failure to follow the Original Equipment Manufacturer's Manual.

This warranty covers only parts of new Power Train Components which are found upon examination to be defective in material or workmanship as delivered to the original purchaser. This warranty does not cover defects caused by depreciation or damage caused by normal wear, accidents, improper maintenance, improper use or abuse of the product, failure to follow the instructions contained in an Instruction Manual for the operation of the Power Train Component and parts. The cost of normal maintenance and replacement of service items which are not defective shall be paid for by the original purchaser.

#### C. Securing Warranty Service

Warranty service can be arranged for by contacting either a Tecumseh Authorized Service Outlet (any Tecumseh Registered Service Dealer, Tecumseh Authorized Service Distributor, or Tecumseh Central Warehouse Distributor) or by contacting Tecumseh, c/o Service Manager, Engine and Transmission Group Service Division, 900 North Street, Grafton, Wisconsin 53024. Warranty service can only be performed by a Tecumseh Authorized Service Outlet or by Tecumseh at its factory in Grafton, Wisconsin. At the time of requesting warranty service, evidence must be presented of the date of sale to the original purchaser. The purchaser shall pay any charges for making service calls and/or for transporting the product to and from the place where the inspection and/or warranty work is performed. The purchaser shall be responsible for any damage or loss incurred in connection with the transportation of Power Train Components and/or part(s) of the Power Train Components submitted for inspection and/or warranty work.

#### D. Limitation of Damages and Implied Warranties

The foregoing EXPRESSED WARRANTY IS IN LIEU OF ALL OTHER EXPRESS WARRANTIES. Neither Tecumseh nor any of its affiliates makes any warranties, representations or promises, written or oral, as to the quality of the Power Train Component or any of its parts, other than as set forth herein.

ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, TO THE EXTENT THAT EITHER MAY APPLY TO ANY PART(S) OF POWER TRAIN COMPONENTS, SHALL BE LIMITED IN DURATION TO THE PERIODS OF THE EXPRESSED WARRANTIES DEFINED IN PARAGRAPH A HEREOF. IN NO EVENT WILL TECUMSEH BE LIABLE FOR ANY INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES AND/OR EXPENSES. Some states do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damages, so the above limitation(s) or exclusion(s) may not apply to you. This warranty gives you specific legal rights and you may also have other legal rights which vary from state to state.

#### E. No Dealer Warranty

Tecumseh neither assumes nor authorizes any other person, natural or corporate, to assume for Tecumseh any other obligations or liabilities in connection with or with respect to any part(s) of a Power Train Component. The seller or dealer of part(s) of a Power Train Component has no authority, whatsoever, to make any representations or promises on behalf of Tecumseh or to modify the terms or limitations of Tecumseh's warranty in any way.

## LIMITED WARRANTY

The Manufacturer warrants to the original consumer purchaser that this product as manufactured is free from defects in materials and workmanship. For a period of one (1) year from date of purchase by the original consumer purchaser, we will repair or replace, at our option, without charge for parts or labor incurred in replacing parts, any part which we find to be defective due to materials or workmanship. This Warranty is subject to the following limitations and exclusions.

- 1. This warranty does not apply to the engine. Please contact your nearest dealer where they will send the machine to the engine manufacturer.
- Transportation charges for the movement of any power equipment unit or attachment are the responsibility of the purchaser. Transportation charges for any parts submitted for replacement under this warranty must be paid by the purchaser unless such return is requested by your dealer.
- 3. Battery Warranty: On products equipped with a Battery, we will replace, without charge to you, any battery which we find to be defective in manufacture, during the first ninety (90) days of ownership. After ninety (90) days, we will exchange the Battery, charging you 1/12 of the price of a new Battery for each full month from the date of the original sale. Battery must be maintained in accordance with the instructions furnished.
- 4. The Warranty period for any products used for rental or commercial purposes is limited to 90 days from the date of original purchase.
- 5. This Warranty applies only to products which have been properly assembled, adjusted, operated, and maintained in accordance with the instructions furnished. This Warranty does not apply to any product which has been subjected to alteration, misuse, abuse, improper assembly or installation, delivery damage, or to normal wear of the product.
- 6. Exclusions: Excluded from this Warranty are belts, blades, blade adapters, normal wear, normal adjustments, standard hardware and normal maintenance.
- 7. In case of any problem within the boundaries of this warranty, contact the nearest department store, indicate the model number, serial number and the date of purchase of your machine. This warranty does not apply to accidental damages. All implicit warranties are limited to the same time frames. Or contact:

E.M. Services 54 Rue Lambrechts 92400 Courbevoie France Telephone: (1) 46678078 Fax: (1) 46678095

THIS WARRANTY DOES NOT APPLY TO INCIDENTAL OR CONSEQUENTIAL DAMAGES. ANY IMPLIED WARRANTIES ARE LIMITED TO THE SAME TIME PERIODS STATED HEREIN.

# WIZARD