



# REPAIR PARTS MANUAL


## MODEL NO. RE621CE

### Rotary Lawn Mower

---

# Rally

# ROTARY LAWN MOWER - - MODEL NUMBER RE621CE



# ROTARY LAWN MOWER - - MODEL NUMBER RE621CE


3

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	167163	Handle, Upper Dlx Comf.	27	83816	Screw
2	161105X479	Handle, Lower	28	111190X	Cable Clamp
3	131036	Bail, Cont. Wire Dlx Comf. Blk	29	134612	Shield, Debris Modified
4	132001	Guide, Rope, Side	30	851514	Adapter
5	63601	Nut, Hex Lockwasher 1/4-20	31	159267	Blade, 21"
6	66426	Wire, Tie	32	851074	Washer, Hardened
7	131959	Bolt, Handle 5/16-18 x 1.75	33	850263	Lockwasher, Helical Spring 3/8
8	87692	Knob, Handle	34	851084	Screw, Hex Head 3/8-24 x 1.38
9	164265	Grip, HdI Foam Smooth	35	84596	Pulley, Engine
10	161551	Bolt, Sq. Neck	36	87677	Key, Hi Pro
11	73990500	Nut, Hex Lockwasher Ins. 5/16-18 UNC	37	150406	Bolt, Engine
12	51793	Cotter, Hairpin	38	-----	Engine Briggs & Stratton 12H802
13	133107	Cable			Order parts from engine manufacturer
14	850733X004	Bracket, Upstop	39	165844	Grass Catcher Bag
15	83816	Screw, Hex Washer Head Tapping 10-2	40	161358	Grass Catcher Frame
16	162085	Kit, Door Rear	41	144929	Screw
17	161548	Seal, Door	42	164137	Throttle Control
18	165261	Plug, Mulcher	43	145494	Decal Inter. Warning
19	163424	Kit, Housing	44	161057	Warning Decal (Not Shown)
20	161568X479	Handle, Bracket	45	<b>54583</b>	Screw
21	168227X479	Handle, Bracket Asm. Right	--	<b>177058</b>	Replacement Parts Manual
22	150078	Screw, Hex Wshd	--	173222	Operator's Manual(Euro)
23	163183	Bolt, Hex Head 5/16-18 x 5/8	--	173225	Operator's Manual(Scand)
24	63124	Nut, Hex Lock Wshr 5/16-18			
25	161333	Baffle, Side			
26	163409	Screw 12 x 5/8			

**NOTE:** All component dimensions given in U.S. inches

1 inch = 25.4 mm

## ROTARY LAWN MOWER - - MODEL NUMBER RE621CE



## ROTARY LAWN MOWER - - MODEL NUMBER RE621CE

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	161587	Cable Drive	24	57808	Screw Hex Head Tapping 1/4-20 x .75
2	161473	Bail Control Drive	25	170011	Drive Pawl
3	161478X004	Bracket, Downstop	26	166450	Pinion, Drive
4	83816	Screw Hex Wash Head Tapping 10-2	28	12000058	E-Ring 7/16
5	161537	Cover Drive	29	88080	Cover, Dust Wheel
6	750634	Screw Thdrol 10-25 x .50	30	67725	Washer 1/2 x 1-1/2 x .134
7	160816	V-Belt	32	162062	Wheel 9 x 2
8	132010	Nut Lock Flanged 3/8-16 Zinc	33	83923	Nut Hex Flange Lock
9	163939	Pulley Driven	34	57143	Wave Washer
10	160813X004	Belt Keeper	35	160785 X004	Shaft Asm. Rear
11	17541011	Screw Hex Wash Head 10-24 X .668	36	160786X004	Shaft Asm. Front
12	75192	Spring	37	161463	Retainer Front Shaft
13	169611	Transmission Asm.	38	163409	Screw 12 x 5/8
14	145354	Pin Spring Thrust	39	700279	Clip Retainer
15	57079	Washer Hardened	40	146247	Wheel 8 x 2
16	161584	Rod Connecting	41	77400	Hubcap
17	161602	Spring Extension	42	52160	Washer
18	160477X004	Spring Selector	43	19572216	Washer
19	161961	Knob Selector Spring	44	62335	Washer
20	12000022	E-Ring 7/8	45	88118	Felt Washer
21	163365	Bearing Support			
22	169911	Bearing Ball			
23	161118X004	Retainer Drive Asm. Stmp.			

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm