



SRM-4600
Cylinder, Crankcase, Piston, Fan Cover


No.1



SRM-4600



Cylinder, Crankcase, Piston, Fan Cover

Key	Lv	Part no.	Part description	Quantity
5		900238-05014	SCREW 5*14	3
6		159905-43130	GUARD, TOP	1
7		900238-05010	SCREW 5*10	1
8		101514-42230	COVER, CYLINDER (BS)	1
9		101011-47530	CYLINDER	1
10		900162-05020	BOLT, H.S. 5*20	4
11		101010-42231	GASKET, CYL. BASE	1
13		100000-43230	PISTON KIT	1
13		100000-43231	PISTON KIT	1
12	+	100011-43230	RING, PISTON	2
14	+	100013-00410	PIN, PISTON	1
15	+	100015-00120	CIRCLIP, PISTON PIN	2
16	+	100012-27930	BEARING, NEEDLE	1
16	+	100012-12331	BEARING, NEEDLE	1
17	+	100014-17330	SPACER, PISTON PIN	2
17	+	V307-000050	WASHER, CIRCULAR 10	2
18		100212-27930	OILSEAL	1
19		100200-42230	CRANKCASE SET	1
20	+	100215-02830	PIN, DOWEL	4
26	+	900162-05030	BOLT, H.S. 5*30	4
21		900810-36201	BEARING, BALL 6201	1
21		94035-36201	BEARING BALL	1
22		100100-43130	CRANKSHAFT ASSY	1
23		100142-12330	KEY, WOODRUFF	1
24		900810-36202	BEARING, BALL 6202	1
25		100242-42230	GASKET, CRANKCASE	1
27		900238-04010	SCREW 4*10	4
28		101534-42230	PLATE, GUIDE	1
29		101511-42230	COVER, FAN (BS)	1
30		900162-05025	BOLT, H.S. 5*25	4
31		900702-00035	CIRCLIP 35	1
32		100213-02830	OILSEAL	1
33		890112-43230	LABEL, MODEL	1




SRM-4600
Starter

No.2





SRM-4600
Starter

Key	Lv	Part no.	Part description	Quantity
5		177202-41030	PAWL ASSY, STARTER	1
6	+	900700-00004	E-RING 4	1
8	+	177234-40630	SPRING, RETURN	1
9	+	177218-40630	PAWL, STARTER	1
10		900502-00008	NUT 8 (3N)	1
11		177200-43130	STARTER ASSY (BS)	1
11		A051-000170	STARTER,RECOIL	1
12	+	177236-40630	SCREW	1
13	+	177214-41030	WASHER	1
14	+	177215-43130	DRUM, STARTER	1
15	+	177220-40630	SPRING, REWIND	1
17	+	177226-01110	ROPE, STARTER	1
18	+	177227-05530	GUIDE, ROPE	1
18	+	177227-42030	GUIDE, ROPE	1
19	+	177228-11120	GRIP, STARTER	1
20		900162-04020	BOLT, H.S. 4*20	4
21		890118-49330	LABEL, ECHO	1




SRM-4600
Magneto, Clutch

No.3




SRM-4600
Magneto, Clutch

Key	Lv	Part no.	Part description	Quantity
5		159017-10230	PLUG, SPARK (RCJ-7Y)	1
6		159011-03432	COIL, SPARK PLUG	1
7		159012-03433	CAP, SPARK PLUG	1
8		156112-40630	GROMMET	1
9		156626-42230	COIL, IGNITION	1
9		156601-12920	COIL,IGNITION	1
10		900238-05020	SCREW 5*20	2
11		162021-42230	LEAD	1
12		156635-43130	LEAD, GROUND	1
13		156801-42230	FLYWHEEL	1
14		900600-00010	WASHER 10	1
15		900605-00010	WASHER, SPRING 10	1
16		900503-00010	NUT 10 (3N *1.25)	1
17		175049-03920	WASHER	2
18		175009-42231	SHOE, CLUTCH	2
19		175018-42230	SPRING, CLUTCH	1
20		175048-03920	WASHER	2
21		175046-06230	BOLT, CLUTCH	2
22		900600-00006	WASHER 6	2
23		900238-05010	SCREW 5*10	1




SRM-4600
Air Cleaner

No.4





SRM-4600
Air Cleaner

Key	Lv	Part no.	Part description	Quantity
4		900500-00005	NUT 5	2
5		130016-42231	GASKET, INTAKE	1
6		130017-43130	INSULATOR	1
7		900162-05025	BOLT, H.S. 5*25	2
8		130016-06231	GASKET	1
8		130016-06232	GASKET, INTAKE	1
9		123000-47532	CARBURETOR ASSY	1
10		130307-47531	CASE, AIR CLEANER	1
10		130307-47532	CASE, AIR CLEANER	1
10		130307-47533	CASE, AIR CLEANER	1
12		900605-00005	WASHER, SPRING 5	2
13		130021-47530	BOLT, 5	2
13		130021-51530	BOLT, 5	2
14		130310-06230	FILTER, AIR	1
15		130313-06230	COVER, AIR CLEANER	1
16		890121-21430	LABEL, CHOKE	1
17		900238-04008	SCREW 4*8	2
18		890169-47530	LABEL, ADJUSTING	1



SRM-4600
Muffler, Fuel Tank

No.5



SRM-4600



Muffler, Fuel Tank

Key	Lv	Part no.	Part description	Quantity
4		131004-46730	CAP ASSY, FUEL TANK	1
4		131004-08960	CAP ASSY, FUEL	1
5	+	131016-40930	GASKET, FUEL CAP	1
5	+	131016-55830	GASKET, FUEL CAP	1
6	+	131051-52430	CONNECTOR, CAP	1
7		131923-11120	CUSHION	3
8		131010-43130	TANK, FUEL	1
8		131010-46930	TANK, FUEL	1
8		131010-46931	TANK, FUEL	1
9		131924-43130	CUSHION	1
10		131910-43130	BRACKET, FUELTANK(BL)	1
11		900238-05014	SCREW 5*14	2
12		131328-40630	COVER, VENT	1
13		131300-49930	VALVE, CHECK	1
13		131300-56430	VALVE, CHECK	1
14		132013-26630	CLIP	1
15		132010-43130	PIPE, FUEL (INNER)	1
17		131205-19830	STRAINER, FUEL	1
20		145510-42231	GASKET, MUFFLER	1
22		145610-47530	MUFFLER	1
23		900162-05020	BOLT, H.S. 5*20	2
25		145866-43131	GASKET, MUFFLER LID	1
26		145867-47530	LID, MUFFLER	1
27		900238-04010	SCREW 4*10	7
28		145871-43130	COVER, MUFFLER	1
29		900238-05014	SCREW 5*14	1



SRM-4600
Carburetor

No.6





SRM-4600
Carburetor

Key	Lv	Part no.	Part description	Quantity
		123000-47532	CARBURETOR ASSY	1
1	+	123130-02960	SCREW	5
2	+	123142-03930	COVER, M. DIAPHRAGM	1
3	+	123141-03930	DIAPHRAGM, METERING	1
4	+	123140-03930	GASKET, M. DIAPHRAGM	1
5	+	123139-03930	SCREW, M. LEVER PIN	1
6	+	123138-03930	PIN, METERING LEVER	1
7	+	123123-03930	LEVER, METERING	1
8	+	123122-47530	SPRING, METER. LEVER	1
9	+	123137-04260	VALVE, INLET NEEDLE	1
10	+	123127-03930	CLIP, THROTTLE SHAFT	1
14	+	123126-10631	SCREEN, INLET	1
15	+	123113-47530	SPRING, THR. RTN.	1
16	+	123117-05020	SHAFT, THROTTLE	1
17	+	123172-26030	SWIVEL	1
18	+	123173-07930	CLIP	1
19	+	123120-47530	NEEDLE, HIGH SPEED	1
20	+	123119-22130	SPRING, NEEDLE	1
21	+	123118-40430	NEEDLE, IDLE	1
22	+	123121-22130	SPRING, NEEDLE	1
23	+	123114-03930	SCREW	1
23	+	123114-38830	SCREW	1
24	+	123116-10530	VALVE, THROTTLE	1
28	+	123146-10631	PLUG, WELCH	1
29	+	123112-15030	DIAPHRAGM, FUEL PUMP	1
30	+	123125-15030	GASKET, FUEL PUMP	1
31	+	123124-24430	COVER, FUEL PUMP	1
32	+	123134-04260	SCREW, IDLE ADJUST	1
33	+	123133-06320	SPRING, IDLE ADJUST	1
34	+	123110-03930	SCREW, PUMP COVER	1
35	+	123149-26030	WASHER	1



SRM-4600
Drive Shaft, Tools

No.7



SRM-4600
Drive Shaft, Tools



Key	Lv	Part no.	Part description	Quantity
5		610011-06230	SHAFT, DRIVE	1
6		890617-46830	LABEL, CAUTION	1
6		890617-43130	LABEL, CAUTION	1
7		301200-06230	HOOK ASS'Y	1
8	+	301207-05630	HOOK	2
9	+	301224-06230	GUIDE	1
11	+	900242-05014	SCREW 5*14	2
13		610206-43130	HOUSING ASSY, D.SHFT	1
20		900142-05025	BOLT 5*25 (W/W,SW)	2
21		610922-40430	HOLDER	1
22		610923-40430	HOLDER	1
23		610910-40430	CUSHION	1
24		900162-05020	BOLT, H.S. 5*20	4
25		610205-43130	FLANGE (BS)	1
25		610203-43130	FLANGE, ASY	1
20	+	900142-05025	BOLT 5*25 (W/W,SW)	2
21	+	610922-43130	HOLDER, MAIN PIPE	1
22	+	610922-55630	HOLDER, PIPE	1
23	+	610910-51830	CUSHION	1
26		900701-00012	CIRCLIP 12	1
27		900807-06001	BEARING, BALL 6001	2
28		900702-00028	CIRCLIP 28	1
29		175005-43130	DRUM, CLUTCH	1
61		895610-00130	L-WRENCH (4MM)	1
63		898502-01130	PIN 2*22 (W/POUCH)	1
64		897518-01131	LOCKING TOOL	1
65		895112-00330	SPANNER 8*10	1
66		895410-08030	WRENCH, W/S. DRIVER	1
66		X602-000020	TOOL, WRENCH	1



SRM-4600


Handle

No.8





SRM-4600
Handle

Key	Lv	Part no.	Part description	Quantity
5		351102-47530	GRIP ASSY, F-HANDLE	1
6	+	900246-03025	SCREW 3*25	4
7	+	900220-05030	SCREW 5*30	1
8	+	900500-00005	NUT 5	1
9		178012-05960	LOCKOUT, THROTTLE	1
10		178013-35631	SPRING, THR. LOCK	1
11		178010-05960	CONTROL, THROTTLE	1
12		163401-43130	SWITCH, IGNITION	1
14		178001-43230	WIRE, THROTTLE	1
15		178127-43230	TUBE	1
16		900502-00006	NUT 6 (3N)	2
17		900605-00006	WASHER, SPRING 6	2
19		178121-43230	BAND	2
24		351110-43230	HANDLE, FRONT	1
25		351301-43230	BRACKET ASSY HNDL(BS	1
26	+	900142-05025	BOLT 5*25 (W/W,SW)	4
27	+	900142-05030	BOLT 5*30 (W/W,SW)	4
28		351642-08130	BAND	1
29		900100-06014	BOLT 6*14	1
30		351610-08130	HANDLE, FRONT	1
31		351311-02330	GRIP, HANDLE	1
32		301300-24830	HARNESS ASSY	1
32		301300-24831	HARNESS ASSY	1
32		301001-52130	HARNESS, SHOULDER	1
33		890157-39130	LABEL, SWITCH	1



SRM-4600
Gear Case, Shield, Blade

No.9



SRM-4600

Gear Case, Shield, Blade

Key	Lv	Part no.	Part description	Quantity
9		610400-40430	HOUSING ASSY, GEAR	1
9		610400-40431	CASE ASY, GEAR	1
9		610400-40433	CASE ASY, GEAR	1
10	+	900702-00028	CIRCLIP 28	1
11	+	900807-06001	BEARING, BALL 6001	1
12	+	900800-06001	BEARING, BALL 6001	1
13	+	610300-40430	GEAR SET	1
15	+	610239-04130	WASHER, SHIM	2
17	+	900142-05030	BOLT 5*30 (W/W,SW)	2
18	+	610434-50030	BOLT 8* 6	1
18	+	610434-50031	BOLT 8* 8	1
19	+	900701-00012	CIRCLIP 12	1
20	+	900220-05010	SCREW 5*10	1
21	+	900605-00005	WASHER, SPRING 5	1
22	+	900600-00005	WASHER 5	1
23	+	900800-36000	BEARING, BALL 6000	1
25	+	900706-00012	CIRCLIP 12	1
26	+	610310-07130	SHAFT, P.T.O.	1
27	+	900810-06201	BEARING, BALL 6201	1
28	+	900702-00032	CIRCLIP 32	1
29	+	610315-07130	SPACER	1
30	+	610413-07130	OILSEAL	1
31	+	610313-07130	PLATE, ADAPTER (U)	1
31	+	610313-07131	PLATE, ADAPTER (U)	1
31	+	610313-07132	PLATE, ADAPTER (U)	1
32	+	610314-07130	PLATE, ADAPTER (L)	1
33	+	900511-00010	NUT 10 (L-H)	1
34	+	900300-20022	PIN, SPLIT 2*22	1
35	+	610443-21232	PLATE, GUARD	1
35	+	C536-000030	COVER,GEAR CASE	1
36	+	900238-05020	SCREW 5*20	3
37		699200-07131	CUP ASSY, FREE	1
38	+	610333-07130	PLATE, ADAPTER (L)	1
39	+	699226-05430	HOLDER, BEARING	1
40	+	900814-06202	BEARING, BALL 6202	1
41	+	699227-04630	NUT	1

SRM-4600

Gear Case, Shield, Blade

Key	Lv	Part no.	Part description	Quantity
42	+	699228-08930	PLATE, COVER	1
44	+	900141-05012	BOLT 5*12	4
45		610336-07131	PLATE, ADAPTER (L)	1
50		699001-50430	SHIELD ASSY	1

51	+	699011-43130	BRACKET, SHIELD	1
52	+	699010-54430	SHIELD, BLADE	1
53	+	699013-52130	PLATE, SHIELD	1
54	+	900242-05018	SCREW 5*18	4
55	+	900603-00005	WASHER 5	4
56	+	900500-00005	NUT 5	6
57	+	900242-05014	SCREW 5*14	4
58	+	699015-52130	PLATE, SHIELD	1
59	+	900142-05025	BOLT 5*25 (W/W,SW)	2
60	+	699016-52130	KNIFE, CORD	1
60	+	699016-54530	KNIFE	1
61	+	900242-05012	SCREW 5*12	2
65		898503-50030	SCABBARD KIT, BLADE	1
65		P021-007470	SCABBARD, BLADE	1
66	+	898562-43230	FIXTURE, SCABBARD	1
68		695001-55630	SAW, CIRCULAR 10*80T	1
68		695001-55631	SAW, CIRCULAR 10*80T	1
69		696001-55630	BLADE, 8-CUTTER 10IN	1
69		696001-55631	BLADE, 8-CUTTER 10IN	1

