



PB-251(37), 37009053-, Cylinder, Crankcase, Piston
P014-000030-10Hb, 2010/05/31





PB-251(37), 37009053-, Cylinder, Crankcase, Piston
 P014-000030-10Hb, 2010/05/31

Key	Lv	Part no.	Part description	Quantity	Note1	Note2
1		900106-05008	BOLT, H.S. 5* 8	2		
2		A160-000821	COVER,CYLINDER	1		
3		A130-000780	CYLINDER	1		
4		900162-05025	BOLT, H.S. 5*25	4		
5		V100-000190	GASKET,CYL	1		
6		P021-010260	PISTON KIT	1		
7	+	A101-000140	RING, PISTON	1		
8	+	V606-000000	PIN,ENG 8	1		
9	+	100015-04630	CIRCLIP, PISTON PIN	2		
10	+	100014-11520	SPACER, PISTON PIN	2		
11		A011-000371	CRANKSHAFT,ASM	1		
12	+	V553-000060	BEARING,NEEDLE 8	1		
13		P021-008231	CRANKCASE KIT	1		
14	+	100212-42031	OILSEAL	2		
15	+	900162-05028	BOLT, H.S. 5*28	3		
16	+	100242-42030	GASKET, CRANKCASE	1		
17	+	94035-36201	BEARING BALL	1		
18	+	100215-03930	PIN, DOWEL	2		




PB-251(37), 37009053-, Air Cleaner, Carburettor, Muffler
P014-000030-10Hb, 2010/05/31



PB-251(37), 37009053-, Air Cleaner, Carburettor, Muffler
 P014-000030-10Hb, 2010/05/31

Key	Lv	Part no.	Part description	Quantity	Note1	Note2
1		V299-000250	KNOB,FASTENER	1		
2		131911-03460	WASHER	1		
3		A232-000340	LID,CLEANER	1		
4		X506-000090	LABEL,CHOKE	1		
5		A226-000470	ELEMENT, AIR FILTER	1		
5		A226-000471	ELEMENT, AIR FILTER	1		
6		900105-05060	BOLT, H.S. 5*60	2		
7		A244-000070	PLATE,PREVENT	1		
8		P021-010980	CLEANER CASE ASY	1		
9		130016-42031	GASKET, INTAKE	1		
10		A021-001591	CARBURETOR,DIAPHRAGM	1		
13		V103-000400	GASKET,INTAKE	1		
14		900162-05025	BOLT, H.S. 5*25	2		
15		A200-000280	INSULATOR, INTAKE	1		
16		V103-000390	GASKET,INTAKE	1		
17		A160-000830	COVER,CYLINDER	1		
18		C459-000010	COVER,THROTTLE	1		
19		V104-000820	GASKET,EXHAUST	1		
20		A300-000810	MUFFLER, EXHAUST	1		
21		A310-000070	SCREEN, ARRESTOR	1		
22		900603-00005	WASHER 5	2		
23		V203-000190	BOLT,5	2		
24		V104-000940	GASKET,EXHAUST	1		
25		A313-000840	GUIDE, EXHAUST	1		
26		A313-000850	GUIDE, EXHAUST	1		
27		91367-04010	SCREW	5		
28		P021-011200	COVER,MUFFLER KIT	1		
29		900106-05014	BOLT, H.S. 5*14	2		
32		A313-001070	GUIDE, EXHAUST	1		


PB-251(37), 37009053-, Starter, Magneto
P014-000030-10Hb, 2010/05/31



PB-251(37), 37009053-, Starter, Magneto
 P014-000030-10Hb, 2010/05/31

Key	Lv	Part no.	Part description	Quantity	Note1	Note2
1		V485-000820	LEAD	1		
2		152115-05530	BUSHING	1		
3		A425-000000	SPARKPLUG	1		
4		A426-000010	TERMINAL,SPARKPLUG	1		
5		A429-000010	COVER,CAP	1		
6		A427-000013	CAP,SPARK PLUG	1		
7		156110-04920	BUSHING	1		
8		X532-000720	LABEL,OPERATION	1		
10		91113-04020	BOLT	2		
11		A411-000290	COIL, IGNITION	1		
12		A409-000210	ROTOR,MAGNETO	1		
13		E101-000071	HUB,FAN	1		
14		P021-013780	SPACER	1		
15	+	V263-000070	NUT,5	1		
16	+	900163-04016	BOLT HSH	4		
17		A052-000250	PULLEY,ASM STARTER	1		
18	++	900700-00004	E-RING 4	2		
19	++	V452-000280	SPRING,TORSION	2		
20	++	A514-000070	PAWL	2		
21		A051-001060	STARTER,RECOIL ASY	1		
22	+	177236-44330	SCREW	1		
23	+	P022-008260	ROPE	1		
24	+	177215-44430	DRUM, STARTER	1		
25	+	177220-42030	SPRING, REWIND	1		
26	+	V420-001440	CUSHION	1		
27	+	177246-11120	CLIP, STARTER ROPE	1		
28	+	177228-27030	GRIP, STARTER	1		
29	+	177227-42030	GUIDE, ROPE	1		
30		900106-05014	BOLT, H.S. 5*14	3		
31		X502-000330	LABEL,ECHO	1		
32		X503-008160	LABEL,MODEL	1		

PB-251(37), 37009053-, Handle
P014-000030-10Hb, 2010/05/31




PB-251(37), 37009053-, Handle
P014-000030-10Hb, 2010/05/31

Key	Lv	Part no.	Part description	Quantity	Note1	Note2
1		900238-05025	SCREW 5*25	1		
2		900602-00005	WASHER 5	1		
3		C453-000260	LEVER, THROTTLE	1		
4		900603-00005	WASHER 5	1		
5		C411-000010	LID,HANDLE	1		
6		900562-50005	LOCKNUT 5	1		
7		C450-000241	CONTROL, THROTTLE	1		
8		900253-05025	SCREW 5*25	1		
9		900253-05020	SCREW 5*20	3		
10		C454-000130	ROD, THROTTLE	1		
11		V431-000000	CABLE,INNER	1		
12		C400-000471	HANDLE, FRONT	1		
13		V263-000070	NUT,5	1		
14		X505-002310	LABEL,CAUTION	1		
15		A440-000770	SWITCH, ON OFF	1		
16		V486-000070	TERMINAL,LEAD	1		
17		890157-06560	LABEL, SWITCH	1		
18		V485-000830	LEAD	1		



PB-251(37), 37009053-, Fuel Tank
P014-000030-10Hb, 2010/05/31




PB-251(37), 37009053-, Fuel Tank
 P014-000030-10Hb, 2010/05/31

Key	Lv	Part no.	Part description	Quantity	Note1	Note2
1		131004-55530	CAP ASSY, FUEL TANK	1		
2	+	131016-55830	GASKET, FUEL CAP	1		
3	+	131051-56030	CLIP, FUEL CAP	1		
4		A356-000030	VALVE,CHECK	1		
5		132013-09820	CLIP	2		
6		V471-001220	PIPE	1		
7		132115-01461	GROMMET	1		
8		900603-00005	WASHER 5	2		
9		900253-05020	SCREW 5*20	2		
10		V471-001860	PIPE	1		
11		132010-49730	PIPE 3*6*85	1		
12		132115-44330	GROMMET	1		
13		131205-07320	STRAINER, FUEL	1		
14		A350-000550	TANK, FUEL	1		
15		V420-001430	CUSHION	1		



PB-251(37), 37009053-, Fan Case, Blower Pipe
P014-000030-10Hb, 2010/05/31



PB-251(37), 37009053-, Fan Case, Blower Pipe
 P014-000030-10Hb, 2010/05/31

Key	Lv	Part no.	Part description	Quantity	Note1	Note2
1		E104-000080	GRID, BLOWER	1		
2		900253-05020	SCREW 5*20	3		
3		X547-000520	LABEL,ECHO	1		
4		X505-002080	LABEL,CAUTION	1		
5		900253-05020	SCREW 5*20	8		
6		E103-000461	CASE,FAN	1		
7		900100-08014	BOLT 8*14	1		
8		100143-19830	WASHER	1		
9		E100-000070	FAN,BLOWER	1		
10		E103-000451	CASE,FAN	1		
11		900162-04020	BOLT, H.S. 4*20	4		
12		E162-000000	FIXTURE, BLOW PIPE	2		
13		900253-05020	SCREW 5*20	2		
14		C410-000391	HANDLE, REAR	1		
15		C410-000400	HANDLE, REAR	1		
16		900253-05020	SCREW 5*20	2		
17		E165-000191	PIPE,BLOWER	1		
18		E165-000210	PIPE,BLOWER	1		
19	+	E178-000050	GUARD,PIPE	1		
20	+	V583-000080	RING	1		
21		895410-06960	WRENCH, W/S-DRIVER	1		



PB-251(37), 37009053-, Carburettor
 P014-000030-10Hb, 2010/05/31

Key	Lv	Part no.	Part description	Quantity	Note1	Note2
		A021-001591	CARBURETOR,DIAPHRAGM	1		
1	+	125344-13931	SCREW	3		
2	+	P005-002090	POST	1		
3	+	P005-002000	COVER ASY, ROTOR	1		
4	+	P005-000100	SCREW,THROTTLEADJUST	1		
5	+	P005-000190	E-RING	1		
6	+	P005-001270	PLUG, H AJUST SCREW	1		
7	+	P005-000280	O-RING	1		
8	+	P005-000940	SPRING, METER. LEVER	1		
9	+	125323-08260	ARM, VALVE	1		
10	+	125338-13930	PIN, METERING ARM	1		
11	+	125337-08260	VALVE, INLET NEEDLE	1		
12	+	125339-42030	SCREW	1		
13	+	P005-000200	GASKET, METERING	1		
14	+	P005-001780	DIAPHRAGM	1		
15	+	125342-52130	COVER, DIAPHRAGM	1		
16	+	125344-52130	SCREW	1		
17	+	P005-000010	STRAINER	1		
18	+	P005-001260	SCREW,MAINN MIXTURE	1		
19		P005-001270	PLUG, H AJUST SCREW	1		
20	+	P005-001250	RETAINER,PLUG BALL	1		
21	+	P005-000510	DIAPHRAGM, PUMP	1		
22	+	P005-000520	GASKET, PUMP	1		
23	+	P005-001890	BASE, ASY PRIMER	1		
24	+	P005-000270	SCREW	1		
25	+	125381-08660	PUMP, PRIMING	1		
26	+	P005-000250	RETAINER	1		
27	+	P005-001900	SCREW	4		
28	+	P005-001000	ROLLER, GUIDE	1		

PB-251(37), 37009053-, Repair Kit
 P014-000030-10Hb, 2010/05/31

Key	Lv	Part no.	Part description	Quantity	Note1	Note2
		P005-001660	DIAPHRAGM/GASKET KIT	1		
7-13		P005-000200	GASKET, METERING	1		
7-14		P005-001780	DIAPHRAGM	1		
7-21		P005-000510	DIAPHRAGM, PUMP	1		
7-22		P005-000520	GASKET, PUMP	1		
		P005-001670	REBUILD KIT	1		
7-28		P005-001000	ROLLER, GUIDE	1		
7-17		P005-000010	STRAINER	1		
7-8		P005-000940	SPRING, METER. LEVER	1		
7-9		125323-08260	ARM, VALVE	1		
7-10		125338-13930	PIN, METERING ARM	1		
7-11		125337-08260	VALVE, INLET NEEDLE	1		
7-13		P005-000200	GASKET, METERING	1		
7-14		P005-001780	DIAPHRAGM	1		
7-21		P005-000510	DIAPHRAGM, PUMP	1		
7-22		P005-000520	GASKET, PUMP	1		
		P021-012350	GASKET KIT	1		
1-5		V100-000190	GASKET,CYL	1		
1-16		100242-42030	GASKET, CRANKCASE	1		
3-16		V103-000390	GASKET,INTAKE	1		
3-13		V103-000400	GASKET,INTAKE	1		
3-9		130016-42031	GASKET, INTAKE	1		
3-19		V104-000820	GASKET,EXHAUST	1		
3-24		V104-000830	GASKET,EXHAUST	1		

