


# CS 4400

Cylinder, Crankcase, Piston(Sr/Nr 36020671 and after)



Cylinder, Crankcase, Piston(Sr/Nr 36020671 and after)

Key	Lv	Part no.	Part description	Quantity
4		130516-35430	SPRING, TENSION	1
5		P021-004060	CRANKCASE SET	1
6	+	900162-05022	BOLT, H.S. 5*22	4
6		900162-05022	BOLT, H.S. 5*22	4
7		130510-38330	ADAPTER, INTAKE	1
8		100000-38932	PISTON KIT	1
9	+	100011-38930	RING, PISTON	2
10	+	100013-35430	PIN, PISTON	1
11	+	100015-03931	CIRCLIP, PISTON PIN	2
14	+	100012-35430	BEARING, NEEDLE	1
12		100142-39130	KEY, WOODRUFF	1
13		P021-007290	CRANKSHAFT ASY	1
15	+	900888-36201	BEARING, BALL 6201	2
16	+	V505-000010	SEAL,OIL 12	2
18	+	437063-38330	GEAR, WORM	1
19		890611-39331	LABEL, MODEL	1
20		P021-006830	COVER, CYLINDER ASY	1
17	+	163890-38330	BOLT, 5	3
21	+	101579-38330	PLATE, WIND PROOF	1
22	+	900580-00004	PUSH, RING	1
26		900238-05016	SCREW 5*16	3
27		433000-19831	CATCHER KIT, CHAIN	1

# CS 4400

28	+	900220-05018	SCREW 5*18	1
30		100918-38330	CAP, CUSHION	2
31		100915-33930	SCREW	2
32		100921-38330	CUSHION	2
33		P021-003110	COVER, ENGINE	1
23	+	100215-03930	PIN, DOWEL	2
34	+	436018-38330	PIN, DOWEL	2
35	+	433011-19830	STUD, GUIDE BAR	2
37		436005-38332	TANK, OIL (BS)	1
34	+	436018-38330	PIN, DOWEL	1
36	+	436019-38330	GASKET, OIL TANK	1
38	+	900162-04016	BOLT, H.S. 4*16	3
39	+	436114-13930	VALVE, CHECK	1
40		436001-39232	CAP, OIL	1



# CS 4400

Cylinder, Crankcase, Piston(Sr/Nr 36020671 and after)


Key	Lv	Part no.	Part description	Quantity
41	+	900721-00025	O-RING 25	1
44	+	A365-000050	CONNECTOR,CAP	1
45		433045-38332	COVER	1
46		890157-39130	LABEL, SWITCH	1
47		890345-39230	LABEL,CAUTION	1
48		V150-001740	PLATE,EYE	2
49		V341-000090	WASHER,SQUARE	1
50		X505-000180	LABEL,CAUTION	1

# CS 4400

PartsList Master - -

Page 1 of 3

Air Cleaner, Muffler



Air Cleaner, Muffler

Key	Lv	Part no.	Part description	Quantity
1		130000-38330	INSULATOR KIT	1
1		130000-38331	INSULATOR ASY, INTAKE	1
2	+	130366-38330	CUSHION	1
2	+	V420-001130	CUSHION	1
3	+	130020-33330	NUT	2
4	+	130010-38330	GASKET, INTAKE	1
5		130110-38330	PIPE, IMPULSE	1
6		130405-38331	BRACKET, AIR CLEANER	1
7		130310-38330	FILTER, AIR	1
7		130310-38331	FILTER, AIR	1
8		130301-38331	ELBOW, CARBURETOR	1
8		130301-38332	ELBOW, CARBURETOR	1
9		900162-05050	BOLT, H.S. 5*50	2
10		130430-38330	CUSHION	1
11		123000-38331	CARBURETOR ASSY	1
11		123000-38332	CARBURETOR ASSY	1
11		123000-39333	CARBURETOR WT-416C	1
12		129010-33330	GROMMET	1
13		900220-04006	SCREW 4*6	1
14		162010-38330	LEAD, GROUND	1
14		162010-38331	LEAD, GROUND	1
14		162010-38332	LEAD, GROUND	1

# CS 4400

PartsList Master - -

Page 2 of 3

15		163810-38330	BRACKET, SWITCH	1
15		163804-38930	BRACKET, SWITCH	1
15		163804-38931	BRACKET, SWITCH	1
15		163804-38932	BRACKET, SWITCH	1
15		163804-38935	BRACKET, SWITCH	1
18	+	178810-14531	GROMMET, CHOKE	1
18	+	178810-14532	GROMMET	1
18	+	178810-14533	GROMMET	1
18	+	178810-14534	GROMMET	1
25	+	163413-38930	PLATE, SWITCH	1
26	+	163810-38931	BRACKET, SWITCH	1
26	+	163810-38932	BRACKET, SWITCH	1
26	+	163810-38933	BRACKET, SWITCH	1
16		163400-38330	SWITCH, IGNITION	1

# CS 4400

PartsList Master - -

Page 3 of 3

## Air Cleaner, Muffler


Key	Lv	Part no.	Part description	Quantity
17		178510-38330	ROD, CHOKE	1
17		178510-38331	ROD, CHOKE	1
17		A241-000100	KNOB, CHOKE	1
18		178810-38330	GROMMET, CHOKE	1
19		178011-38331	ROD, THROTTLE	1
20		145600-38330	MUFFLER ASSY	1
20		145600-38331	MUFFLER ASY	1
20		145600-38332	MUFFLER ASY	1
20		145600-38333	MUFFLER ASY	1
20		P021-008610	MUFFLER ASY	1
21	+	900105-04006	BOLT, H.S. 4*6	1
22	+	145711-35430	PLATE (BL)	1
22	+	145711-60631	STAY, MUFFLER	1
23	+	900105-05014	BOLT, H.S. 5*14	2
24	+	145510-35431	GASKET, MUFFLER	1
31		C483-000000	BOOT,CONNECTOR	1

# CS 4400

PartsList Master --

Page 1 of 3

## Starter, Magneto



## Starter, Magneto

Key	Lv	Part no.	Part description	Quantity
4		900605-00008	WASHER, SPRING 8	1
5		159017-31730	PLUG, SPARK RCJ-6Y	1
6		159011-03432	COIL, SPARK PLUG	1
7		159012-01620	CAP, SPARK PLUG	1
9		156626-38330	COIL, IGNITION	1
9		156626-38331	COIL, IGNITION	1
9		156626-38332	COIL, IGNITION	1
9		A411-000030	COIL,IGNITION	1
9		A411-000031	COIL,IGNITION	1
10		900162-04030	BOLT, H.S. 4*30	2
11		156800-38930	ROTOR, MAGNETO	1
11		156800-38931	ROTOR, MAGNETO	1
11		A409-000080	ROTOR,MAGNETO	1
12		900500-00008	NUT 8	1
13		177234-35430	SPRING, RETURN	2
14		900603-00005	WASHER 5	2
15		177247-04630	SPACER, RATCHET	2
16		177218-19830	PAWL, STARTER	2
17		900162-05014	BOLT, H.S. 5*14	2
17		V203-000090	BOLT,5	2
18		101535-38930	COVER, FAN	1
18		A172-000060	COVER,FAN	1

# CS 4400

PartsList Master - -

Page 2 of 3

18		A172-000061	COVER,FAN	1
18		A172-000062	COVER,FAN	1
19		177200-38931	STARTER,ASSY	1
19		177200-38332	STARTER ASY	1
19		177200-38333	STARTER ASY	1
19		177200-38334	STARTER ASY	1
19		177200-38335	STARTER ASY	1
20	+	900238-05012	SCREW 5*12	1
21	+	177214-02830	WASHER	1
22	+	177226-38330	ROPE, STARTER	1
23	+	177215-38330	DRUM, STARTER	1
24	+	177221-38330	PLATE, STARTER	1
25	+	177220-35430	SPRING, REWIND	1
26	+	177228-35430	GRIP, STARTER (BL)	1

# CS 4400

PartsList Master - -

Page 3 of 3

## Starter, Magneto


Key	Lv	Part no.	Part description	Quantity
27	+	177227-37930	GUIDE, ROPE	1
29	+	900296-03014	SCREW 3*14	1
30		900238-05018	SCREW 5*18	4
31		X502-000010	LABEL,ECHO	1

# CS 4400

PartsList Master --

Page 1 of 3

## Handle



## Handle

Key	Lv	Part no.	Part description	Quantity
5		900253-04014	SCREW 4*14	1
6		351155-35430	COVER, HANDLE (BL)	1
7		178090-37930	LOCKOUT, T. CONTROL	1
8		178010-38330	TRIGGER, THROTTLE	1
8		178010-38331	TRIGGER, THROTTLE	1
8		C450-000000	TRIGGER, THROTTLE	1
9		178043-35430	SPRING, THR.RETURN	1
10		900345-40030	PIN, SPRING 4*30SUS	1
11		351111-19830	GRIP, HANDLE	1
12		351103-38330	HANDLE, REAR	1
12		351101-38330	HANDLE ASSY, REAR	1
12		351101-38331	HANDLE ASSY, REAR	1
12		351101-38332	HANDLE ASY, REAR	1
31	+	132019-39330	GROMMET, FUEL	1
32	+	132021-02960	CONNECTOR, PIPE	1
32	+	132012-39330	PIPE, W/GROMMET	1
33	+	437210-11131	PIPE 3*5*90 NBR	1
33	+	132013-26630	CLIP	1
34	+	131328-40630	COVER, VENT	1
35	+	131300-40630	VALVE, CHECK	1
35	+	131300-56430	VALVE, CHECK	1
13		178302-12330	LATCH, THROTTLE	1

# CS 4400

PartsList Master - -

Page 2 of 3

14		131004-37931	CAP ASSY, FUEL TANK	1
14		131004-37932	CAP ASY, FUEL	1
15	+	131051-19830	LINK	1
15	+	A365-000050	CONNECTOR,CAP	1
16	+	900720-00022	O-RING 22	1
17		132115-04920	GROMMET	1
18		132010-38330	PIPE, FUEL	1
18		132010-38331	PIPE	1
19		131205-30830	STRAINER, FUEL	1
19		131205-19830	STRAINER, FUEL	1
20		132013-26630	CLIP	1
21		131314-35430	VALVE, CHECK	1
22		100921-38330	CUSHION	2
23		100915-32530	BOLT	2

# CS 4400

PartsList Master - -

Page 3 of 3

## Handle


Key	Lv	Part no.	Part description	Quantity
24		100918-38330	CAP, CUSHION	2
25		100910-38330	CUSHION	2
26		351606-38330	HANDLE, FRONT	1
27		900268-05020	SCREW 5*20	2
27		91145-05020	BOLT HS TAPPING	2
28		900253-05016	SCREW	2
28		91145-05016	BOLT HS TAPPING	2

# CS 4400

PartsList Master --

Page 1 of 2

Auto-Oiler



# CS 4400

PartsList Master - -

Page 2 of 2

## Auto-Oiler


Key	Lv	Part no.	Part description	Quantity
5		437229-38331	PIPE	1
8		437002-38330	AUTO-OILER ASSY	1
9		900238-04016	SCREW 4*16	2
9		900223-04016	SCREW	2
10		175310-38330	PLATE, SEAL	1
11		132013-26630	CLIP	2
11		132013-26630	CLIP	1
12		132115-12330	GROMMET	1
13		437210-38330	PIPE, OIL	1
14		436205-14730	STRAINER, OIL	1

CS 4400

PartsList Master - -

Page 1 of 4

Clutch, Sprocket, Tools(Sr/Nr 36020670 and before)



Clutch, Sprocket, Tools(Sr/Nr 36020670 and before)

Key	Lv	Part no.	Part description	Quantity
5		433201-39330	LEVER ASSY, BRAKE	1
5		433201-39331	LEVER ASSY, BRAKE	1
5		433201-39332	LEVER ASY, BRAKE	1
6	+	900330-30240	PIN 3*24	1
7	+	433167-39130	SPACER	2
8	+	900560-00005	NUT, LOCK 5	1
8	+	900562-50005	LOCKNUT 5	1
9	+	433114-38330	SPRING	1
9	+	433114-38331	SPRING	1
10	+	900209-05030	SCREW, 5*30	1
10	+	91318-05032	SCREW	1
11	+	433171-39330	WEIGHT, BRAKE	1
12	+	900238-04018	SCREW 4*18	2
13	+	900500-00004	NUT 4	2
14		V203-000040	BOLT,5	1
14		V203-000041	BOLT,5	1
15		433014-60930	TENSIONER, CHAIN	1
15		C309-000030	TENSIONER,CHAIN	1
16		V651-000010	GEAR,BEVEL	1
16		V651-000011	GEAR,BEVEL	1
17		V355-000030	COLLAR,8	1
17		V355-000270	COLLAR,8	1
18		V651-000000	GEAR,BEVEL	1
18		V651-000001	GEAR,BEVEL	1
19		900220-04006	SCREW 4*6	1
20		433013-35431	PLATE, GUIDE (INNER)	1
22		433012-38330	PLATE, SPROCK. GUARD	1
25		433005-38930	GUARD, SPROCKET	1
23		P021-000480	SPROCKET GUARD KIT	1
23		P021-000481	SPROCKET GUARD KIT	1
25		433005-38931	GUARD, SPROCKET	1
25		433005-38932	GUARD, SPROCKET	1
23		P021-001290	GUARD,SPROCKET SET	1
23		P021-001291	GUARD,SPROCKET SET	1
21	+	900220-03006	SCREW 3*6	1

# CS 4400

PartsList Master - -

Page 2 of 4

22	+	C305-000000	PLATE, SPROCKET GUARD	1
----	---	-------------	-----------------------	---

# CS 4400

PartsList Master - -

Page 3 of 4

Clutch, Sprocket, Tools(Sr/Nr 36020670 and before)

Key	Lv	Part no.	Part description	Quantity
22	+	C305-000001	PLATE,SPROCKET GUARD	1
25	+	433005-38933	GUARD, SPROCKET	1
25	+	P021-010160	GUARD, SPROCKET KIT	1
14	++	V203-000110	BOLT,5	1
38	+	900253-04010	SCREW 4*10	1
55	+	V162-000020	PLUG	1
24		433019-12330	NUT, FLANGE 8	2
26		175000-35431	CLUTCH ASSY	1
27	+	175062-35430	SPACER	3
28	+	175019-19830	PLATE, CLUTCH	3
29	+	175016-35430	HUB, CLUTCH	1
30	+	175018-19830	SPRING, CLUTCH	1
31	+	175002-19830	SHOE, CLUTCH	1
32	+	900105-04006	BOLT, H.S. 4*6	6
26		175000-59530	CLUTCH ASY	1
27	+	175016-59530	HUB, CLUTCH	1
28	+	175018-59530	SPRING, CLUTCH	1
29	+	175002-59530	SHOE, CLUTCH	1
30	+	175022-59530	SPRING,FLAT	3
31		175019-59530	PLATE, CLUTCH	1
33		175012-14630	BEARING, NEEDLE	1
34		175105-35430	DRUM, CLUTCH	1
34		A556-000170	DRUM,CLUTCH	1
35		175114-12530	SPROCKET, RIM .325	1
36		175019-38330	PLATE, CLUTCH	1
37		433310-38330	COVER, BRAKE	1
38		900253-04010	SCREW 4*10	2
39		433122-35430	SPRING, BRAKE	1
40		433209-35430	STOPPER, BRAKE	1
41		433115-38330	WASHER 5.2*12*14	1
42		433208-35431	LEVER, BRAKE	1
43		900330-40088	ROLLER 4*8.8	1
44		433142-35430	ADJUSTER, BRAKE	1
45		433123-35430	BAND, BRAKE	1
46		900342-25012	PIN, SPRING 2.5*12	1
47		880200-38330	BUMPER, SPIKED KIT	1

# CS 4400

PartsList Master - -

Page 4 of 4

Clutch, Sprocket, Tools(Sr/Nr 36020670 and before)


Key	Lv	Part no.	Part description	Quantity
48	+	900105-05012	BOLT, H.S. 5*12	2
49		895410-02830	WRENCH, W/S. DRIVER	1
50		895811-00130	DRIVER, SCREW 125	1
51		890316-39130	LABEL, CAUTION	1
52		898548-14531	SCABBARD, CHAIN	1
53	+	898568-14530	ROPE	1
54		X502-000000	LABEL,ECHO	1
55		898510-39130	BAG, TOOL	1
61		P021-007060	CLUTCH ASY W/PLATE	1
62	+	A552-000060	HUB,CLUTCH	1
63	+	V451-000500	SPRING,TENSION	3
64	+	P021-007050	CLUTCH SHOE SET	1
65	+	175019-39430	PLATE, CLUTCH	1
66		V304-000090	WASHER,CIRCULAR 6	1

# CS 4400

PartsList Master --

Page 1 of 3

Clutch, Sprocket, Tools(Sr/Nr 36020671 and after)



Clutch, Sprocket, Tools(Sr/Nr 36020671 and after)


Key	Lv	Part no.	Part description	Quantity
5		433201-39332	LEVER ASY, BRAKE	1
6	+	900330-30240	PIN 3*24	1
7	+	433167-39130	SPACER	2
8	+	900562-50005	LOCKNUT 5	1
9	+	433114-38331	SPRING	1
10	+	91318-05032	SCREW	1
11	+	433171-39330	WEIGHT, BRAKE	1
12	+	900238-04018	SCREW 4*18	2
13	+	900500-00004	NUT 4	2
15		C309-000030	TENSIONER,CHAIN	1
16		V651-000011	GEAR,BEVEL	1
17		V355-000270	COLLAR,8	1
18		V651-000001	GEAR,BEVEL	1
19		900220-04006	SCREW 4*6	1
20		433013-35432	PLATE, GUIDE (INNER)	1
23		P021-001292	GUARD, SPROCKET SET	1
21	+	900220-03006	SCREW 3*6	1
22	+	C305-000001	PLATE, SPROCKET GUARD	1
25	+	P021-010161	GUARD, SPROCKET KIT	1
14	++	V203-000110	BOLT,5	1
38	+	900253-04010	SCREW 4*10	1
24		433019-12330	NUT, FLANGE 8	2

# CS 4400

PartsList Master - -

Page 2 of 3

60		P021-006060	DRUM,CLUTCH SET	1
33	+	175012-00831	BEARING, NEEDLE	1
34	+	A556-000171	DRUM,CLUTCH	1
36		175019-38330	PLATE, CLUTCH	1
37		433310-38330	COVER, BRAKE	1
38		900253-04010	SCREW 4*10	2
39		433122-35430	SPRING, BRAKE	1
40		433209-35430	STOPPER, BRAKE	1
41		433115-38330	WASHER 5.2*12*14	1
42		433208-35431	LEVER, BRAKE	1
43		900330-40088	ROLLER 4*8.8	1
44		433142-35430	ADJUSTER, BRAKE	1
45		C328-000060	BAND,BRAKE	1
46		900342-25012	PIN, SPRING 2.5*12	1



# CS 4400

PartsList Master - -

Page 3 of 3

Clutch, Sprocket, Tools(Sr/Nr 36020671 and after)


Key	Lv	Part no.	Part description	Quantity
47		880200-38330	BUMPER, SPIKED KIT	1
48	+	900105-05012	BOLT, H.S. 5*12	2
49		895410-02830	WRENCH, W/S. DRIVER	1
50		895811-00130	DRIVER, SCREW 125	1
52		898548-14531	SCABBARD, CHAIN	1
53	+	898568-14530	ROPE	1
54		X502-000000	LABEL,ECHO	1
55		898510-39130	BAG, TOOL	1
61		P021-007060	CLUTCH ASY W/PLATE	1
62	+	A552-000060	HUB,CLUTCH	1
63	+	V451-000500	SPRING,TENSION	3
64	+	P021-007050	CLUTCH SHOE SET	1
65	+	175019-39430	PLATE, CLUTCH	1
66		V304-000090	WASHER,CIRCULAR 6	1

# CS 4400

PartsList Master - -

Page 1 of 3

Carburetor(Sr/Nr 613855 and before)



Carburetor(Sr/Nr 613855 and before)

Key	Lv	Part no.	Part description	Quantity
		123000-38331	CARBURETOR ASSY	1
		123000-38332	CARBURETOR ASSY	1
1	+	123130-02960	SCREW	5
2	+	123142-03930	COVER, M. DIAPHRAGM	1
3	+	123141-03930	DIAPHRAGM, METERING	1
4	+	123140-03930	GASKET, M. DIAPHRAGM	1
5	+	123123-03930	LEVER, METERING	1
5	+	123123-38330	LEVER, METERING	1
6	+	123139-03930	SCREW, M. LEVER PIN	1
7	+	123138-03930	PIN, METERING LEVER	1
8	+	123122-11130	SPRING, METER. LEVER	1
9	+	123137-19830	VALVE, INLET NEEDLE	1
10	+	123132-37330	VALVE, CHOKE	1
11	+	123114-03930	SCREW	3
11	+	123114-03930	SCREW	1
11	+	123114-38830	SCREW	1
12	+	123136-10630	BALL, CHOKE FRICTION	1
13	+	123135-10630	SPRING, CHOKE FRIC.	1
14	+	123119-22130	SPRING, NEEDLE	1
15	+	123120-38330	NEEDLE, HIGH SPEED	1
16	+	123118-38330	NEEDLE, IDLE	1
17	+	123121-22130	SPRING, NEEDLE	1

# CS 4400

PartsList Master --

Page 2 of 3

18	+	123117-38330	SHAFT, THROTTLE	1
19	+	123113-37530	SPRING, THROTTLE RTN	1
20	+	123126-10631	SCREEN, INLET	1
21	+	123116-10530	VALVE, THROTTLE	1
22	+	123127-03930	CLIP, THROTTLE SHAFT	1
23	+	123150-38330	LEVER, THROTTLE	1
24	+	123131-35430	SHAFT, CHOKE	1
25	+	123146-17330	PLUG, CUP	1
26	+	123169-10630	RING, RETAINING	1
27	+	123168-10631	SCREEN	1
28	+	123146-10631	PLUG, WELCH	1
29	+	123112-15030	DIAPHRAGM, FUEL PUMP	1
30	+	123125-15030	GASKET, FUEL PUMP	1
31	+	123124-38330	COVER, FUEL PUMP	1

# CS 4400

PartsList Master - -

Page 3 of 3

Carburetor(Sr/Nr 613855 and before)


Key	Lv	Part no.	Part description	Quantity
32	+	123110-03930	SCREW, PUMP COVER	1
33	+	123178-15030	PLUG, FRICTION	1
34	+	123133-04260	SPRING, IDLE ADJUST	1
35	+	123134-04260	SCREW, IDLE ADJUST	1
36	+	123114-38830	SCREW	2

# CS 4400

PartsList Master --

Page 1 of 2

Carburetor(Sr/Nr 36000001 and after)



Carburetor(Sr/Nr 36000001 and after)

Key	Lv	Part no.	Part description	Quantity
		123000-39333	CARBURETOR WT-416C	1
1	+	123130-02960	SCREW	4
2	+	123142-03930	COVER, M. DIAPHRAGM	1
3	+	123141-03930	DIAPHRAGM, METERING	1
4	+	123140-03930	GASKET, M. DIAPHRAGM	1
5	+	123123-03930	LEVER, METERING	1
6	+	123122-39330	SPRING, METER. LEVER	1
7	+	123137-19830	VALVE, INLET NEEDLE	1
8	+	123139-03930	SCREW, M. LEVER PIN	1
9	+	123138-03930	PIN, METERING LEVER	1
10	+	123146-10631	PLUG, WELCH	1
12	+	123120-03661	NEEDLE	2
13	+	P003-000010	LIMITER CAP	2
15	+	123114-38830	SCREW	3
16	+	123132-37330	VALVE, CHOKE	1
17	+	123135-10630	SPRING, CHOKE FRICT.	1
18	+	123136-10630	BALL, CHOKE FRICTION	1
24	+	123117-39330	SHAFT, THROTTLE	1
25	+	123113-37530	SPRING, THROTTLE RTN	1
26	+	123126-10631	SCREEN, INLET	1
27	+	123116-10530	VALVE, THROTTLE	1
28	+	123127-15030	RING	1

# CS 4400

PartsList Master - -

Page 2 of 2


29	+	123150-38330	LEVER, THROTTLE	1
30	+	123131-35430	SHAFT, CHOKE	1
31	+	123112-15030	DIAPHRAGM, FUEL PUMP	1
32	+	123125-15030	GASKET, FUEL PUMP	1
33	+	123124-38330	COVER, FUEL PUMP	1
34	+	123110-03930	SCREW, PUMP COVER	1
35	+	123133-04260	SPRING, IDLE ADJUST	1
36	+	123134-04260	SCREW, IDLE ADJUST	1
37	+	123178-15030	PLUG, FRICTION	1

# CS 4400

PartsList Master - -

Page 1 of 3

Chain Brake Asy(Sr/Nr 36020670 and before)



Chain Brake Asy(Sr/Nr 36020670 and before)

Key	Lv	Part no.	Part description	Quantity
		433100-38930	BRAKE ASSY, CHAIN	1
		433100-38931	BRAKE ASY, CHAIN	1
		433100-38932	BRAKE ASY, CHAIN	1
		433100-38933	BRAKE ASY, CHAIN	1
		433100-38934	BRAKE ASY, CHAIN	1
		433100-38935	BRAKE ASY, CHAIN	1
		433100-38936	BRAKE ASY, CHAIN	1
		P021-010130	BRAKE,ASM CHAIN	1
5	+	433201-39331	LEVER ASSY, BRAKE	1
5	+	433201-39332	LEVER ASY, BRAKE	1
6	++	900330-30240	PIN 3*24	1
7	++	433167-39130	SPACER	2
8	++	900560-00005	NUT, LOCK 5	1
8	++	900562-50005	LOCKNUT 5	1
9	++	433114-38331	SPRING	1
10	++	900209-05030	SCREW, 5*30	1
10	++	91318-05032	SCREW	1
11	++	433171-39330	WEIGHT, BRAKE	1
12	++	900238-04018	SCREW 4*18	2
13	++	900500-00004	NUT 4	2
25	+	433005-38930	GUARD, SPROCKET	1
23	+	P021-000480	SPROCKET GUARD KIT	1

# CS 4400

PartsList Master - -

Page 2 of 3

23	+	P021-000481	SPROCKET GUARD KIT	1
25	+	433005-38931	GUARD, SPROCKET	1
25	+	433005-38932	GUARD, SPROCKET	1
23	+	P021-001290	GUARD, SPROCKET SET	1
21	++	900220-03006	SCREW 3*6	1
22	++	C305-000000	PLATE, SPROCKET GUARD	1
22	++	C305-000001	PLATE, SPROCKET GUARD	1
25	++	433005-38933	GUARD, SPROCKET	1
25	++	P021-010160	GUARD, SPROCKET KIT	1
14	+++	V203-000110	BOLT,5	1
38	++	900253-04010	SCREW 4*10	1
55	++	V162-000020	PLUG	1
37	+	433310-38330	COVER, BRAKE	1
38	+	900253-04010	SCREW 4*10	2

# CS 4400

PartsList Master - -

Page 3 of 3

Chain Brake Asy(Sr/Nr 36020670 and before)


Key	Lv	Part no.	Part description	Quantity
39	+	433122-35430	SPRING, BRAKE	1
40	+	433209-35430	STOPPER, BRAKE	1
41	+	433115-38330	WASHER 5.2*12*14	1
42	+	433208-35431	LEVER, BRAKE	1
43	+	900330-40088	ROLLER 4*8.8	1
44	+	433142-35430	ADJUSTER, BRAKE	1
45	+	433123-35430	BAND, BRAKE	1
45	+	C328-000060	BAND,BRAKE	1
46	+	900342-25012	PIN, SPRING 2.5*12	1
66	+	V304-000090	WASHER,CIRCULAR 6	1

CS 4400

PartsList Master - -

Page 1 of 3

Chain Brake Asy(Sr/Nr 36020670 and before)



Chain Brake Asy(Sr/Nr 36020670 and before)

Chain Brake Assy (S/N 50020070 and before)				
Key	Lv	Part no.	Part description	Quantity
		433100-38930	BRAKE ASSY, CHAIN	1
		433100-38931	BRAKE ASY, CHAIN	1
		433100-38932	BRAKE ASY, CHAIN	1
		433100-38933	BRAKE ASY, CHAIN	1
		433100-38934	BRAKE ASY, CHAIN	1
		433100-38935	BRAKE ASY, CHAIN	1
		433100-38936	BRAKE ASY, CHAIN	1
		P021-010130	BRAKE,ASM CHAIN	1
5	+	433201-39331	LEVER ASSY, BRAKE	1
5	+	433201-39332	LEVER ASY, BRAKE	1
6	++	900330-30240	PIN 3*24	1
7	++	433167-39130	SPACER	2
8	++	900560-00005	NUT, LOCK 5	1
8	++	900562-50005	LOCKNUT 5	1
9	++	433114-38331	SPRING	1
10	++	900209-05030	SCREW, 5*30	1
10	++	91318-05032	SCREW	1
11	++	433171-39330	WEIGHT, BRAKE	1
12	++	900238-04018	SCREW 4*18	2
13	++	900500-00004	NUT 4	2
25	+	433005-38930	GUARD, SPROCKET	1
23	+	P021-000480	SPROCKET GUARD KIT	1

# CS 4400

PartsList Master - -

Page 2 of 3

23	+	P021-000481	SPROCKET GUARD KIT	1
25	+	433005-38931	GUARD, SPROCKET	1
25	+	433005-38932	GUARD, SPROCKET	1
23	+	P021-001290	GUARD, SPROCKET SET	1
21	++	900220-03006	SCREW 3*6	1
22	++	C305-000000	PLATE, SPROCKET GUARD	1
22	++	C305-000001	PLATE, SPROCKET GUARD	1
25	++	433005-38933	GUARD, SPROCKET	1
25	++	P021-010160	GUARD, SPROCKET KIT	1
14	+++	V203-000110	BOLT, 5	1
38	++	900253-04010	SCREW 4*10	1
55	++	V162-000020	PLUG	1
37	+	433310-38330	COVER, BRAKE	1
38	+	900253-04010	SCREW 4*10	2

# CS 4400

PartsList Master -

Page 3 of 3

Chain Brake Asy(Sr/Nr 36020670 and before)

Key	Lv	Part no.	Part description	Quantity
39	+	433122-35430	SPRING, BRAKE	1
40	+	433209-35430	STOPPER, BRAKE	1
41	+	433115-38330	WASHER 5.2*12*14	1
42	+	433208-35431	LEVER, BRAKE	1
43	+	900330-40088	ROLLER 4*8.8	1
44	+	433142-35430	ADJUSTER, BRAKE	1
45	+	433123-35430	BAND, BRAKE	1
45	+	C328-000060	BAND,BRAKE	1
46	+	900342-25012	PIN, SPRING 2.5*12	1
66	+	V304-000090	WASHER,CIRCULAR 6	1