


Flymo

P35 9645141 **P40** 9645142 **P50** 9645143
P50S 9645148





P35 9645141 P40 9645142 P50 9645143
P50S 9645148

NO.	PART NO.	DESCRIPTION	QUANTITY	COMMENTS APPLICATION	KEY NO.	PART NO.	DESCRIPTION	QUANTITY	COMMENTS APPLICATION
303-10/7		COVER CLUTCH	1	P35	34A	303-49/5	SHAFT REAR ROLLER	1	P40.
303-11/5		COVER CLUTCH	1	P40	34B	303-50/3	SHAFT REAR ROLLER	1	P50, P50S.
303-12/3		CLUTCH COVER	1	P50, P50S.	35	303-51/1	REAR ROLLER DRUM R/H	1	P35.
303-13/1		SCREW	4		35A	303-52/9	REAR ROLLER DRUM R/H	1	P40.
303-14/9		KEY	1		35B	303-53/7	REAR ROLLER DRUM R/H	1	P50.
303-15/6		ALLEN SCREW	1		35C	304-88/1	REAR ROLLER DRUM R/H	1	P50S.
303-16/4		CLUTCH BODY	1	P35, P40, P50.	36	303-54/5	REAR ROLLER DRUM L/H	1	P35.
304-55/0		CLUTCH BODY	1	P50S.	36A	303-59/4	REAR ROLLER ASSY COMPLETE	1	P35.
303-17/2		SPACER	1	P35, P40.	36B	303-55/2	REAR ROLLER DRUM L/H	1	P40.
303-18/0		SPACER	1	P50.	36C	303-60/2	REAR ROLLER ASSY COMPLETE	1	P40.
304-85/7		SPACER	1	P50S.	36D	303-56/0	REAR ROLLER DRUM L/H	1	P50.
303-19/8		CLUTCH SHOE	4		36E	303-61/0	REAR ROLLER ASSY COMPLETE	1	P50.
3-20/6		BEARING BALL	1	P35, P40, P50.	36F	304-89/9	REAR ROLLER DRUM L/H	1	P50S.
16-35/2		BEARING BALL	1		36G	304-90/7	REAR ROLLER ASSY COMPLETE	1	P50S.
303-21/4		CLUTCH SPRING	1		37	161-01/8	REAR ROLLER RETAINING COLLAR	2	
303-22/2		CLUTCH HOUSING AND SHAFT	1	P35.	38	303-57/8	GRUB SCREW	2	
303-23/0		CLUTCH HOUSING AND SHAFT	1	P40.	39	161-03/4	REAR ROLLER RATCHET L/H	1	
303-24/8		CLUTCH HOUSING AND SHAFT	1	P50.	40	161-02/6	REAR ROLLER RATCHET R/H	1	
303-26/3		KEY	1	P35, P40, P50, P50S	41	303-58/6	GRUB SCREW	2	
16-96/4		REAR ROLLER PAWL	2		42	303-62/8	CHAIN GUARD	1	
16-97/2		REAR ROLLER PAWL SPRING	2		43	303-63/6	CHAIN GUARD RETAINING SCREWS	2	
303-27/1		WASHER	4		44	303-64/4	CLUTCH CENTRE BOLT	1	
303-28/9		HANDLE UPPER	1	P35.	45	303-65/1	WASHER	1	
303-30/5		HANDLE UPPER	1	P35, P50, P50S.	46	303-66/9	CLUTCH COLLAR	1	
303-31/5		HANDLE LOWER	1	P35.	47	303-67/7	BEARING BALL	1	
303-32/1		HANDLE LOWER	1	P40.	48	303-68/5	CLUTCH PLATE WITH 14T SPROCKET	1	
303-33/9		HANDLE LOWER	1	P50, P50S.	49	303-69/3	CLUTCH LINING	1	
303-34/7		BOLT HANDLE ASSEMBLE	4		50	303-70/1	BEARING BALL	1	
20-70/1		SCREW	2		51	303-71/9	CLUTCH MOUNTING PLATE	1	
70-28/4		WASHER	2		52	303-72/7	BOLT	2	
40-04/8		NUT	2		53	303-73/5	CLUTCH ACTUATING LEVER ASSY	1	
303-38/8		THROTTLE LEVER	1	P35, P40.	54	303-74/3	CLUTCH ACTUATING LEVER BRACKET	1	
304-84/0		THROTTLE LEVER	1	P50, P50S.	55	303-75/0	CLUTCH ACTUATING LEVER	1	
303-39/6		THROTTLE CABLE OUTER	1	P50, P50S. NLA USE 304-84/0	56	303-76/8	BOLT	1	
4-82/4		THROTTLE CABLE OUTER	1	P50, P50S	57	303-77/6	SPRING	1	
303-40/4		THROTTLE CABLE INNER	1	P35, P40.	58	303-78/4	SPROCKET 9T COUNTER- SHAFT KEYED	1	
304-82/2		THROTTLE CABLE INNER	1	P50, P50S. NLA USE 304-84/0	58A	304-62/6	SPROCKET 9T x 1/2" THREADED	1	
303-41/2		CLUTCH LEVER	1		58B	304-63/4	SPROCKET 13T x 3/8" THREADED	1	
303-42/0		CLUTCH CABLE ASSEMBLY	1		59	303-79/2	SPROCKET 40T CLUTCH	1	P35, P40, P50.
303-43/8		CLUTCH LEVER BOLT	1		59A	304-75/8	SPROCKET 43T	1	
303-44/6		HANDLE GRIP	2		60	303-80/0	SPROCKET 27T REAR ROLLER	1	
303-45/3		HANDLE BOLT	4		61	303-81/8	WASHER	1	
303-46/1		BOLT & NUT	9		62	303-82/6	NUT	2	
16-36/0		BEARING HOUSING	1	P35, P40, P50.					
304-87/3		BEARING HOUSING	1	P50S.					
16-35/2		BEARING BALL	2						
303-47/9		SPACER	1						
303-48/7		SHAFT REAR ROLLER	1	P35.					

Flymo
P35 9645141 P40 9645142 P50 9645143
P50S 9645148

KEY No.	PART No.	DESCRIPTION	QUANTITY	COMMENTS APPLICATION	KEY No.	PART No.	DESCRIPTION	QUANTITY	COMMENTS APPLICATION
63	303-83/4	SPROCKET 10/18T KEYED	1		95	304-10/5	SPRING	2	P35,P40,P50
63A	304-64/2	SPROCKET 9-18T THREADED	1		96	304-11/3	CIRCLIP	2	P35,P40,P50
63B	304-65/9	SPROCKET 9-26T x 3/8" THREADED	1		97	304-12/1	FRONT ROLLER ADJUSTER STUD	2	
64	303-84/2	WASHER	1		98	304-13/9	CUTTING CYLINDER	1	P35
65	303-85/9	NUT	1	P35,P40,P50.	98A	304-14/7	CUTTING CYLINDER	1	P40
66	303-86/7	CHAIN 55 PITCH	1		98B	304-15/4	CUTTING CYLINDER	1	P50
66A	304-66/7	CHAIN 75 PITCH x 3/8"	1		98C	304-92/3	CUTTING CYLINDER	1	P50S
67	303-87/5	CHAIN 48 PITCH (40T SPROCKET)	1		99	304-16/2	CYLINDER BLADE SINGLE	6	P35
67A	304-67/5	CHAIN 60 PITCH (43T SPROCKET)	1		99A	304-17/0	CYLINDER BLADE SINGLE	6	P40
68	303-88/3	CHAIN 40 PITCH	1		99B	304-18/8	CYLINDER BLADE SINGLE	6	P50,P50S
69	303-89/1	LINK 1/2" PITCH	1		100	304-19/6	FRONT ROLLER BRACKET ASSY	1	P35
69A	304-68/3	LINK 3/8" PITCH	1		100A	304-20/4	FRONT ROLLER BRACKET ASSY	1	P40
70	303-90/9	CHAIN TENSIONER BRACKET	1	NLA USE 303-97/4	100B	304-21/2	FRONT ROLLER BRACKET ASSY	1	P50
71	303-91/7	CHAIN TENSIONER SHOE	1	NLA USE 303/98/2	101	304-22/0	LOCKNUT	2	
72	303-92/5	LOCKNUT	1		102	304-23/8	SHAFT FRONT ROLLER	1	P35
73	303-93/3	CHAIN ADJUSTER SPRING	1	NLA USE 304-56/8	102A	304-24/6	SHAFT FRONT ROLLER	1	P40
73A	303-94/1	CHAIN TENSIONER COMPLETE ASSY	1		102B	304-25/3	SHAFT FRONT ROLLER	1	P50
74	303-95/8	BOLT	2		103	304-26/1	WASHER	2	
75	303-96/6	BOLT	3		104	304-27/9	NUT	2	
76	303-97/4	CHAIN ADJUSTER BRACKET	1		105	15-71/7	ROLLER WOOD	3	P35,P40,P50
77	303-98/2	CHAIN ADJUSTER SHOE	1		106	304-28/7	WASHER	2	P35,P40,P50
77A	304-56/8	CHAIN ADJUSTER SPRING	1		107	304-29/5	SPACER	4	P35,P40,P50
77B	304-57/6	CHAIN ADJUSTER COMPLETE ASSY	1		108	304-30/3	WASHER	4	P35,P40,P50
78	303-99/0	NUT	2		109	3043-12/2	BRACKET LEFT HAND	1	
79	16-48/5	RETAINER UPPER	2		109A	3043-18/9	BRACKET RIGHT HAND	1	
80	304-00/6	LOCKNUT	4		110	304-32/9	GRASS CATCHER	1	P35
81	304-01/4	REEL ADJUSTER STUD	2		110A	304-33/7	GRASS CATCHER	1	P40
82	304-02/2	LOCKNUT	2		110B	304-34/5	GRASS CATCHER	1	P50
82A	304-03/0	REEL ADJUSTER ASSY	1		110C	305-11/0	GRASS CATCHER	1	P50S
83	16-81/6	PIVOT BOLT & LOCKNUT	2		111	304-35/2	GRASS THROWER CAST ASSY	1	P35
84	16-74/1	BEARING HOUSING L/H	1		111A	304-71/7	GRASS THROWER STEEL ASSY	1	P35
85	16-61/8	NIPPLE GREASE	2		111B	304-36/0	GRASS THROWER CAST ASSY	1	P40
86	16-57/6	BEARING SINGLE SEAL	2		111C	304-72/5	GRASS THROWER STEEL ASSY	1	P40
87	16-60/0	BEARING HOUSING R/H	1		111D	304-37/8	GRASS THROWER CAST ASSY	1	P50,P50S
88	304-04/8	CHAIN GUARD MOUNTING STUD	2		111E	304-73/3	GRASS THROWER STEEL ASSY	1	P50,P50S
89	304-05/5	WASHER	2		112	304-38/6	GRASS THROWER BRACKET	2	
90	304-06/3	BOTTOM BLADE ASSEMBLY	1	P35	113	304-39/4	WASHER	2	
90A	16-80/8	BOTTOM BLADE ASSY C/W BLADE	1	P40	114	304-40/2	BOLT	2	
90B	20-80/0	BOTTOM BLADE ASSEMBLY	1	P50	115	304-41/0	CHASSIS	1	P35
90C	304-91/5	BOTTOM BLADE ASSEMBLY	1	P50S	115A	304-42/8	CHASSIS	1	P40
91	304-07/1	BOTTOM BLADE	1	P35	115B	304-43/6	CHASSIS	1	P50
91A	16-85/8	BOTTOM BLADE	1	P40	116	304-45/1	CLUTCH HOUSING CAST	1	
91B	20-75/0	BOTTOM BLADE	1	P50	117	304-46/9	CLUTCH SHAFT	1	P35
91C	201-13/7	BOTTOM BLADE	1	P50S	117A	304-47/7	CLUTCH SHAFT	1	P40
92	16-76/6	SCREW	10		117B	304-48/5	CLUTCH SHAFT	1	P50,P50S
93	304-08/9	FRONT ROLLER ADJUSTER	2		118	304-50/1	CLUTCH COVER	1	P35,P40,P50
94	304-09/7	WASHER	2		118A	304-55/0	CLUTCH BODY	1	P50S
					119	304-51/9	CLUTCH SPIGOT	1	P35,P40,P50
					119A	305-13/6	CLUTCH SPIGOT	1	P50S
					120	304-52/7	BRACKET RIGHT HAND	1	P35,P40,P50
					120A	305-14/4	BRACKET RIGHT HAND	1	P50S

Flymo

P35 9645141 **P40** 9645142 **P50** 9645143
P50S 9645148

MODELS P35,40,50

THE ORIGINAL CUTTING CYLINDER AND CLUTCH SHAFT HAD A KEYED SHAFT AND THE SPROCKET WAS LOCATED BY A NUT AND WASHER. THEY HAVE SINCE BEEN MODIFIED. THE CUTTING CYLINDER NOW HAS A LEFT HAND THREAD AND A THREADED SPROCKET. THE CLUTCH SHAFT HAS A RIGHT HAND THREAD AND A THREADED SPROCKET. THE KEYED AND THREADED SPROCKETS ARE NOT INTERCHANGEABLE WITH ORIGINAL PARTS FITTED AND THE FOLLOWING PARTS ARE REQUIRED TO COMPLETE THE CONVERSION TO THE CURRENT MODEL.

KEY No.	PART No.	DESCRIPTION	QUANTITY	COMMENTS APPLICATION
118	304-50/1	CLUTCH COVER		
115	304-51/9	CUTCH SPIGOT		
116	304-45/1	CLUTCH HOUSING		
117	304-46/9	CLUTCH SHAFT		P35
117	304-47/7	CLUTCH SHAFT		P40
117	304-48/5	CLUTCH SHAFT		P50,P50S
32	16-35/2	BEARING		
58A	304-62/6	9T THREAD SPROCKET		

PRODUCT VARIANT

9645141-01 GB

9645142-01 GB

9645143-01 GB

9645148-01 GB

