

spare parts list and drawing

5.958-380


/

K 380M/390M

/

1.2 PIECE PARTS

200740



1	9.001-175.0 HANDLE VERS. 3 /	1
2	9.001-174.0 SIDE PART VERS. 2 + 3 /	1
3	9.011-460.0 SCREW	1
4	9.011-462.0 SCREW	1
5	9.001-151.0 SPARE PARTS SET VERS. 1 + 2 /	1

spare parts list and drawing

5.958-380


/

K 380M/390M

/

1.2 PIECE PARTS

200740



1	9.001-175.0	HANDLE	1
	VERS. 3 /		
2	9.001-174.0	SIDE PART	1
	VERS. 2 + 3 /		
3	9.011-460.0	SCREW	1
4	9.011-462.0	SCREW	1
5	9.001-151.0	SPARE PARTS SET	1
	VERS. 1 + 2 /		

spare parts list and drawing

5.958-380


/

K 380M/390M

/

2.1 CYLINDER HEAD

200740



1	9.001-103.0	SPARE PARTS SET	1
2	9.001-110.0	MOULDED PART	3
3	6.388-216.0	HOSE	1
	TO ORDER AS CUT GOODS		
4	5.731-040.0	FILTER	1
5	9.001-149.0	VENTILSET	3
14	7.311-569.0	SQUARE NUT	1
17	9.036-322.0	SUPPORTING DISK	3
18	6.362-875.0	GROOVED RING	3
20	9.001-105.0	ZYLINDERKOPFSET	1
24	9.081-404.0	SEAL RING	1
25	9.001-104.0	SPARE PARTS SET	1
26	9.042-018.0	LID	1
27	7.306-042.0	CHEESE HEAD SCREW	4
28	9.011-283.0	VALVE	1
29	9.081-409.0	GASKET	1

spare parts list and drawing

5.958-380


/

K 380M/390M

/

2.1 CYLINDER HEAD

200740



27	7.306-042.0	CHEESE HEAD SCREW	4
28	9.011-283.0	VALVE	1
29	9.081-409.0	GASKET	1
30	9.036-309.0	SUCTION CONNECTION	1
32	9.001-108.0	INJECTOR	1
34	9.047-026.0	SPRING	1
35	9.001-107.0	CAGE	1
38	9.001-106.0	JOINING PIECE	1
42	6.389-870.0	CONNECTION	1
43	6.414-252.0	STRAINER	1

spare parts list and drawing

5.958-380


/

K 380M/390M

/

2.2 PISTON

200740



2	9.047-023.0	SPRING	3
3	9.001-102.0	PISTON	3
4	9.081-373.0	GASKET	1
5	9.001-101.0	HOUSING	1
6	6.365-386.0	GROOVED RING	3
7	7.306-042.0	CHEESE HEAD SCREW	4

spare parts list and drawing

5.958-380


/

K 380M/390M

/

3.1 MOTOR

200740



0	9.001-093.0	MOTOR	1
1	6.964-090.0	FAN HOUSING	1
2	7.304-395.0	HEXAGONAL HEAD SCREW	1
3	9.039-102.0	BLOWER WHEEL	1
4	6.964-092.0	FAT	1
5	6.964-096.0	END PLATE	1
6	9.078-004.0	ROTARY SHAFT SEAL	1
7	7.401-136.0	BALL BEARING	1
8	9.086-153.0	OVAL HEAD SCREW	4
9	9.086-169.0	SCREW	1
10	9.039-090.0	SWASH PLATE	1
11	7.312-233.0	SERRATED LOCK WASHER	1

spare parts list and drawing

5.958-380


/

K 380M/390M

/

3.2 MOTOR

200740



0	9.001-145.0	MOTOR	1
	/ 1.141-466.0		
1	6.964-090.0	FAN HOUSING	1
2	6.304-103.0	HEX SCREW	1
3	6.964-040.0	BLOWER WHEEL	1
4	6.964-092.0	FAT	1
5	6.964-096.0	END PLATE	1
6	9.078-004.0	ROTARY SHAFT SEAL	1
7	7.401-136.0	BALL BEARING	1
8	9.086-153.0	OVAL HEAD SCREW	4
9	6.304-110.0	CHEESE HEAD SCREW	1
10	9.039-091.0	SWASH PLATE	1

spare parts list and drawing

5.958-380


/

K 380M/390M

/

4.1 TRIGGER GUN

200740



0	9.001-125.0	PISTOL	1
1	9.036-408.0	TOKEN TRAY	1
2	6.964-044.0	MOULDED PART	1
3	9.011-402.0	SET OF GASKETS	1
4	6.964-002.0	SPRING	1
5	6.964-048.0	LEVER	1
6	6.303-122.0	OVAL HEAD SCREW	8
7	9.011-397.0	PIPE	1
8	6.362-898.0	GASKET	1
9	5.031-068.0	JOINING PIECE	1
10	5.332-349.0	PRESSURE SPRING	1
11	2.880-296.0	SPARE PARTS KIT	1
12	9.082-051.0	HIGH PRESSURE HOSE	1
	/ 1.141-362.0 / -373.0 / -465.0		
12	9.082-055.0	HIGH PRESSURE HOSE	1
	/ 1.141-369.0		

spare parts list and drawing

5.958-380


/

K 380M/390M

/

4.1 TRIGGER GUN

200740



/ 1.141-362.0 / -373.0 / -465.0

12 9.082-055.0 HIGH PRESSURE HOSE

1

/ 1.141-369.0

12 9.082-057.0 HIGH PRESSURE HOSE

1

13 6.363-115.0 GASKET

1

spare parts list and drawing

5.958-380


/

K 380M/390M

/

4.2 TRIGGER GUN

200740



0	9.001-095.0	PISTOL	1
	/ 1.141-468.0		
1	9.036-408.0	TOKEN TRAY	1
2	6.964-044.0	MOULDED PART	1
3	9.011-402.0	SET OF GASKETS	1
4	6.964-002.0	SPRING	1
5	6.964-048.0	LEVER	1
6	6.303-122.0	OVAL HEAD SCREW	8
7	9.011-397.0	PIPE	1
8	6.362-898.0	GASKET	1
9	9.036-607.0	JOINING PIECE	1
10	5.332-349.0	PRESSURE SPRING	1
11	2.880-296.0	SPARE PARTS KIT	1
12	9.082-057.0	HIGH PRESSURE HOSE	1

spare parts list and drawing

5.958-380


/

K 380M/390M

/

4.2 TRIGGER GUN

200740



12 9.082-057.0 HIGH PRESSURE HOSE

1

spare parts list and drawing

5.958-380


/

K 380M/390M

/

4.3 JET PIPE

200740



1	9.011-419.0 JET PIPE / 1.141-354.0 / -370.0 / -377.0 / -378.0 / -464.0 / -467.0 / -468.0	1
2	6.903-276.0 WASH BRUSH / 1.141-469.0 / -472.0 / -475.0	1
4	2.883-111.0 SPARE PARTS KIT	5
5	4.760-392.0 JET PIPE / 1.141-351.0	1
6	9.011-383.0 JET PIPE / 1.141-474.0 / -475.0	1
7	9.011-421.0 ROTARY NOZZLE / 1.141-315.0 / -354.0 / -363.0 / -365.0 / -369.0 / -370.0 / -372.0 / -378.0 / -454.0 / -463.0 / -464.0 / -466.0 / -467.0 / -468.0 / -469.0 / -470.0 / -471.0 / -472.0 / -475.0	1
8	9.036-402.0 HANDLES	1
9	9.036-403.0 PIPE	1
10	6.303-122.0 OVAL HEAD SCREW	4
11	6.362-534.0 GASKET	1
12	4.762-238.0 NOZZLE CAP	1
13	4.762-065.0 ROTATING BRUSH	1

spare parts list and drawing

5.958-380


/

K 380M/390M



/

4.3 JET PIPE

200740



- | | | | |
|--|-------------|----------------|---|
| 11 | 6.362-534.0 | GASKET | 1 |
| 12 | 4.762-238.0 | NOZZLE CAP | 1 |
| 13 | 4.762-065.0 | ROTATING BRUSH | 1 |
| / 1.141-370.0 / -377.0 / -465.0 / -468.0 | | | |



spare parts list and drawing


5.958-380

/

K 380M/390M

/ 5.0 ELECTRIC CONTROL BOX

200740



1	9.001-100.0	COVER	1
2	7.303-031.0	SCREW	1
3	9.085-023.0	CAPACITOR	1
4	9.036-348.0	HOUSING	1
5	6.362-870.0	GASKET	1
6	9.048-011.0	BUSH	1
7	9.086-153.0	OVAL HEAD SCREW	2
8	9.085-031.0	SWITCH	1
9	9.084-055.0	CABLE	1
	/ 1.141-315.0 / -351.0 / -362.0 / -363.0 / -369.0 / -370.0 / -372.0 / -373.0 / -377.0 / -378.0 / -451.0 / -463.0 / -464.0 / -465.0 / -466.0 / -467.0 / -468.0 / -469.0 / -470.0 / -471.0 / -472.0 / -475.0		
9	9.084-059.0	CABLE	1
	/ 1.141-474.0		
9	9.084-065.0	CABLE	1
	/ 1.141-354.0 / -454.0		
9	9.084-070.0	CABLE	1
	/ 1.141-352.0 / -452.0		

spare parts list and drawing


5.958-380

/

K 380M/390M

/ 5.0 ELECTRIC CONTROL BOX

200740



/ 1.141-354.0 / -454.0		
9	9.084-070.0 CABLE	1
/ 1.141-352.0 / -452.0		
15	9.036-351.0 SWITCH KNOB	1