




# Débroussailleuse DBC260L




2008/03  
DBC260L 1/4



# Débroussailleuse DBC260L



2008/03  
DBC260L 3/4



# Débroussailleuse DBC260L



Item	Parts_No.	Parts_Description	Qty	Unit
1	6271501501	SPACER	1	PC.
2	6197005001	HANGER ASS'Y	1	PC.
2		INC. 3	0	
3	140059360	SCREW & WASHER ASS'Y	1	PC.
4	6255070000	CONTROL LEVER ASSY	1	PC.
004-1	6255070001	CONTROL LEVER ASSY	1	PC.
5	6214016000	HANDLE SET	1	PC.
5		INC. 6 7	0	
6	6214016030	SCREW	4	PC.
7	22705000	NUT M5	4	PC.
8	6251056000	PIPE	1	PC.
9	6259549600	CAUTION LABEL	1	PC.
10	6258064000	PROTECTOR ASSY	1	PC.
10		INC. 11 14-16	0	
11	6258065000	PROTECTOR ASSY	1	PC.
11		INC. 12 13	0	
12	100069790	BOLT M6X30	2	PC.
13	6258509400	PROTECTOR CLAMP	1	PC.
14	140059380	SCREW ASSEMBLY	2	PC.
15	6258053001	PROTECTOR COMPLETE	1	PC.
16	21805000	NUT M5	2	PC.
17	119059490	SOCKET HEAD BOLT M5X14 (WSW)	1	PC.
18	6191500401	SHAFT	1	PC.
19	6243006002	CASEGEAR ASSY	1	PC.
19		INC. 20-33	0	
20	31424000	INNER SNAP RING	1	PC.
21	6193006120	OUTER SNAP RING	1	PC.
22	6212500300	BALL BEARING #609ZZ	1	PC.
23	119059890	SOCKET HEAD BOLT M5X25	1	PC.
24	6253011012	OIL BOLT M6X9	1	PC.
25	6218500200	GUARD	1	PC.
26	140059390	SCREW ASSEMBLY	2	PC.
27	600069990	BALL BEARING 626ZZ	1	PC.
28	600109910	BALL BEARING 6000DDU	1	PC.
29	31426000	INNER SNAP RING	1	PC.
30	6218501601	RECEIVE WASHER	1	PC.
31	6218003001	CLAMP COMPL. WASHER	1	PC.
32	6258505001	NUT	1	PC.
33	6243008002	CUTTER SHAFT SET	1	PC.
34	6255070000	CONTROL LEVER ASSY	1	PC.
34		INC. 35-37 39-44	0	
034-1	6255070001	CONTROL LEVER ASSY	1	PC.
034-1		INC. 35-37 39-44	0	
35	6195006060	TAPPING SCREW M4X20	4	PC.
36	119059720	SOCKET HEAD BOLT M5X20	2	PC.
37	6255070010	WIRE ASSY	1	PC.
37		INC. 38	0	
037-1	6255070011	WIRE ASSY	1	PC.
037-1		INC. 38	0	
38	6255070020	WIRE COMPLETE	1	PC.
038-1	6255070021	WIRE COMPLETE	1	PC.
39	6195006030	LEVER	1	PC.
40	6195006050	SPRING	1	PC.
41	6195013010	LEVER	1	PC.

# Débroussailleuse DBC260L



42	6415011160	NUT	2	PC.
43	6195006150	TOP	1	PC.
44	S135994451	CARBURETOR GASKET	1	PC.
45	S135173092	CARBURETOR INSULATOR	1	PC.
46	S135993842	CARBURETOR GASKET	1	PC.
47	119059640	SOCKET HEAD BOLT M5X25	2	PC.
48	5267007000	WIRE COMPLETE	1	PC.
49	S199513670	INSULATOR	1	PC.
50	S135994490	INSULATOR GASKET	1	PC.
51	119059730	SOCKET HEAD BOLT M5X20	2	PC.
52	S198113530	RUBBER	1	PC.
53	650149661	SPARK PLUG	1	PC.
54	S110213770	CYLINDER	1	PC.
55	5263501200	MUFFLER GASKET	1	PC.
56	S135043271	EXHAUST MUFFER	1	PC.
57	119059550	SOCKET HEAD BOLT	2	PC.
58	S199513451	INSULATOR IGNITION COIL	1	PC.
59	450399-7	MUFFLER COVER	1	PC.
60	450397-1	CYLINDER COVER	1	PC.
61	140059360	SCREW & WASHER ASS'Y	2	PC.
62	736309870	LABEL	1	PC.
63	424079-1	PLUG CAP	1	PC.
64	654009931	PLUG CAP SPRING	1	PC.
65	119049970	SOCKET HEAD BOLT	2	PC.
66	S150053510	IGNITION COIL ASSY	1	PC.
66		INC. 67	0	
67	S185603500	WIRE COMPLETE	1	PC.
68	5265009000	REWIND STARTER ASS'Y	1	PC.
68		INC. 69-77	0	
69	5315001030	STOPPER	1	PC.
70	5215002110	STARTER KNOB	1	PC.
71	5215002030	SPIRAL SPRING	1	PC.
72	5265007030	REEL	1	PC.
73	5265007050	DAMPER SPRING	1	PC.
74	5265007040	CAM PLATE	1	PC.
75	5195002060	SET SCREW	1	PC.
76	5195018000	PULLEY	1	PC.
77	5265007110	STARTER ROPE	1	PC.
78	5269500600	MODEL LABEL	1	PC.
79	140059330	SCREW M5X20(WSW)	4	PC.
80	S110993460	CYLINDER GASKET	1	PC.
81	S115113650	PISTON RING	2	PC.
82	S115313750	PISTON	1	PC.
83	S115323041	PISTON PIN	1	PC.
84	S198343210	CLIP	2	PC.
85	S042709008	NEEDLE ROLLER BEARING	1	PC.
86	5262004000	CRANKSHAFT COMPLETE	1	PC.
87	S150103600	FLYWHEEL COMPLETE	1	PC.
88	S020109107	NUT	1	PC.
89	5928500300	WASHER	2	PC.
90	5928500000	CLUTCH SHOE	2	PC.
91	5928500600	SPRING	1	PC.
92	200089911	WASHER M8	2	PC.
93	5928500400	CLUTCH BOLT	2	PC.
94	6252022000	CLUTCH DRUM COMPLETE	1	PC.

# Débroussailleuse DBC260L



95	450395-5	CLUTCH CASE	1	PC.
96	119059730	SOCKET HEAD BOLT M5X20	3	PC.
97	31512000	OUTER SNAP RING	1	PC.
98	424123-4	BUFFER RUBBER	1	PC.
99	318249-1	PIPE HOLDER	1	PC.
100	424082-2	BUFFER RUBBER	1	PC.
101	119059900	SOCKET HEAD BOLT M5X12	1	PC.
102	119059730	SOCKET HEAD BOLT M5X20	2	PC.
103	318250-6	PIPE HOLDER	1	PC.
104	424083-0	BUFFER RUBBER	1	PC.
105	345882-6	STAND	1	PC.
106	266020-6	TAPPING SCREW 4X12	4	PC.
107	851209880	TUBE COMPLETE	1	PC.
107-1	851209881	TUBE COMPLETE	1	PC.
108	561059990	HOSE CLAMP	1	PC.
109	5236503900	FILTER	1	PC.
110	424080-6	BUFFER RUBBER	2	PC.
111	450400-8	FUEL TANK	1	PC.
112	424081-4	BUFFER RUBBER	1	PC.
113	5266008000	CAP FUEL TANK ASSY	1	PC.
113		INC. 114 115	0	
113-1	5266008001	CAP FUEL TANK ASSY	1	
113-1		INC. 114 115	0	
114	5266010000	CAP FUEL TANK ASSY	1	PC.
114-1	5266010001	CAP FUEL TANK ASSY	1	
115	5256067000	STRAP	1	PC.
116	5261003000	CRANKCASE ASSY	1	PC.
116		INC. 117-121	0	
117	119059570	SOCKET HEAD BOLT M5X30	3	PC.
118	S050209070	OIL SEAL	1	PC.
119	600129790	BALL BEARING	2	PC.
120	S110993450	CRANK CASE GASKET	1	PC.
121	440129940	OIL SEAL	1	PC.
122	5266009000	CARBURETOR	1	PC.
122		INC. 123-130 132-137	0	
123	5246001210	SWIVEL	1	PC.
124	5426005030	WASHER	1	PC.
125	5266009020	SCREW	2	PC.
126	5266009030	CABLE BRACKET	1	PC.
127	5316005120	RING	1	PC.
128	5926002040	PUMP GASKET	1	PC.
129	5246001040	PUMP DIAPHRAGM	1	PC.
130	5266002010	PUMP BODY ASSEMBLY	1	PC.
130		INC. 131	0	
131	5016004010	INLET SCREEN	1	PC.
132	5236046040	METERING DIAPHRAGM GASKET	1	PC.
133	5266009010	METERING DIAPHRAGM ASSY	1	PC.
134	5236046060	AIR PURGE BODY ASS'Y	1	PC.
135	5246001150	PRIMER PUMP	1	PC.
136	5236046050	PRIMER PUMP COVER	1	PC.
137	5236046010	PUMP COVER SCREW	4	PC.
138	5263005000	AIR CLEANER PLATE ASSY	1	PC.
139	5253503900	GASKETCARBURETOR	1	PC.
140	5013502400	AIR CLEANER PLATE ASSY	1	PC.
141	5263501300	AIR FILTER	1	PC.

# Débroussailleuse DBC260L



142	43105603	PAN HEAD SCREW M5X60	2	PC.
143	450403-2	AIR CLEANER COVER	1	PC.
144	140059360	SCREW & WASHER ASS'Y	1	PC.
145	6197004000	BAND ASSY	1	PC.
146	6218020001	STRING HEAD AY	1	PC.
147	6119019001	TOOL KIT	1	PC.
147		INC. 148	0	
148	717049990	HEX. WRENCH	1	PC.
A01	6197004000	BAND ASSY	1	PC.
A02	6218020001	STRING HEAD AY	1	PC.
A03	6119019001	TOOL KIT	1	PC.
A03		INC. 148	0	
A04	717049990	HEX. WRENCH	1	PC.