


# GRASS TRIMMER

3002  
3001  
3000



**LZTR450 Exploded View and Spare Parts List**

<b>Parts No.</b>	<b>Parts Name</b>	<b>Quantity</b>
LZETR450-1	Right shell	1
LZETR450-2	Capacitor	1
LZETR450-3	Swivel button	1
LZETR450-4	Swivel spring	1
LZETR450-5	Right label	1
LZETR450-6	Motor assembly	1
LZETR450-7	Anti-vibration washer	1
LZETR450-8	Protection shield	1
LZETR450-9	Blade	1
LZETR450-10	Protection board	1
LZETR450-11	Anti-loose nut	1
LZETR450-12	sheath	1
LZETR450-13	Protection wheel	1
LZETR450-14	Screw M8	1
LZETR450-15	Trimmer head seat	1
LZETR450-16	Copper sheath	1
LZETR450-17	Trimmer head spring	1
LZETR450-18	Trimmer line seat	1
LZETR450-19	Nylon trimmer line	1
LZETR450-20	Trimmer head cover	1
LZETR450-21	Screw ST2.9*6	1
LZETR450-22	Screw ST2.9*6	1
LZETR450-23	Swivel head	1
LZETR450-24	Wire post	1
LZETR450-25	Warning label	1
LZETR450-26	Assistance handle	1
LZETR450-27	Nut	1
LZETR450-28	Screw	1
LZETR450-29	Extention tube	1
LZETR450-30	Right handle shell	1
LZETR450-31	Elastic wire	1
LZETR450-32	Handle spring	1
LZETR450-33	Power switch button	1
LZETR450-34	Safety spring	1
LZETR450-35	Safety spring	1
LZETR450-36	Power cord	1
LZETR450-37	Wire Sheath	1
LZETR450-38	Power switch	1
LZETR450-39	Screw ST2.9x16-F-H	5
LZETR450-40	Wire tie clamp	1
LZETR450-41	Left handle shell	1
LZETR450-42	Left shell	1
LZETR450-43	Left label	1
LZETR450-44	Inductor	1
LZETR450-45	Wire connection terminal	1
LZETR450-46	Heat shrink tube	1
LZETR450-47	Elastic wire	1
LZETR450-48	Extention tube	1

