


REPAIR PARTS

36" RIDING MOWER MODEL 3560-004

NOTE. ALWAYS USE ORIGINAL EQUIPMENT PARTS. Use of service/replacement parts other than original equipment parts may void your warranty.

ALL UNNUMBERED ITEMS ARE INTERCHANGEABLE WITH OPPOSITE SIDE.




36 RIDING MOWER MODEL 3560-004

ALWAYS GIVE THE FOLLOWING INFORMATION WHEN ORDERING REPAIR PARTS
 1. THE PART NUMBER 2. THE PART NAME 3. QUANTITY DESIRED 4. THE MODEL NUMBER (As shown on Model Plate)
 SEND PART ORDERS AS PER INSTRUCTIONS ON THE FRONT PAGE
 YOUR UNIT IS RIGHT HAND OR LEFT HAND (WHICH AS YOU STAND BEHIND IT)
 DO NOT USE KEY NUMBERS WHEN ORDERING REPAIR PARTS - ALWAYS USE PART NUMBERS
 All replacement parts will be supplied in original production colors or in a neutral color
 A handling fee is applicable to small parts orders

Key No.	Part No.	Description	Key No.	Part No.	Description
1	54873	Trough, Oil Drain	43	49276	Spring, Main Drive
2	Engine	§See Footnote Below	44	54965	Foot Pad, L.H.
3	48812	Gas Tank	45	50570	Main Frame
4	42258	Gas Line	46	41529	Locknut, 3/16 Thd.
5	41008	Clip, Gas Line	47	40974	Shoulder Bolt, Parking Brake
8		Gasket, Muffler (Engine Part)	48	43968	Spring, Parking Brake
9	57908	Muffler	49	32377	Wave Washer
10		Engine Part	50	50980	Arm, Parking Brake
11	173063	Screw, Hex Hd. 5/16-18 x 3/4 In.	51	50562	Spring, Clutch Pedal
12	33200	Key, Engine Pulley	52	121222	Pin, Cotter, 3/32 x 3/4 In.
13	55796	Pulley, Engine	53	55722	Brake Pedal Assembly
14	120383	Lockwasher, Split, 7/16 In.	54	53979	Rubber Pad, Brake Pedal
15	123567	Screw, Hex Hd. 7/16-20 x 1 In.	55	55025	Retainer, Pad, Brake Pedal
16	50653	Belt Guide, Blade Drive	56	43856	Shaft, Brake Clutch Pedal
17	49896	Belt Guide, Trans. Drive Belt	57	54715	Rod, Brake
18	120393	Flatwasher, 5/16 In.	58	54723	Bracket, Brake Rod
19	271184	Nut, Hex. Keps. 5/16-18 Thd.	59	20507	Shoulder Bolt
20	271190	Nut, Hex. Keps. 3/4-16 Thd.	60	9413447	Locknut, Hex 5/16-18 Thd.
21	138485	Washer, Ext. Lock, 5/16 In.	61	54888	Retainer, Wire
22	50947	Screw, Hex Hd. 5/16 x 1 1/4 In.	62	45602	Washer
23	137185	Pin, Cotter, 1/8 x 1 In.	63	54618	Foot Pad, R.H.
24	58256	Shift Bracket	64	55511	Ground Wire
25	57157	Washer	65	41105	Wheel
26	56255	Screw, Nylock, 1/4-28 x 3/4 In.	66	120228	Screw, Hex Hd. 5/16-18 x 3/8 In.
27	138489	Washer, Ext. Lock, 3/4 In.	67	122017	Screw, Hex Hd. 5/16-18 x 1 In.
28	58284	Knob, Gear Shift	68	53788	Bracket, Axle
29	55526	Shift Lever	69	40394	Hub Cap
30	54758	V. Belt	70	36626	"E" Ring
31	55520	Pulley, Transaxle	71	42815	Flatwasher
32	3021	Key, Woodruff, No. 606	72	642	Flatwasher
33	22053	Retaining Ring	73	35410	Spring, Brake Return
34	9413534	Locknut, Hex. 3/8-16 Thd.	74	54713	Bracket, Stabilizer
35	39659	Pin, Retainer	75	122007	Screw, Hex Hd. 5/16-18 x 3/4 In.
36	43980	Rod, Clutch	76	35498	Screw, Hex Wa. Tap, 5/16-18 x 1/4 In.
37	35374	Pulley, Idler	77	Transaxle	1-Partless 4 speed, Model 900
38	274517	Flatwasher, 25-64 In.	78	180117	Screw, Hex Hd. 5/16-18 x 2 1/4 In.
39	53762	Idler Arm	79	39628	Key, 3/16 x 3/16 x 2 1/2 In.
40	45892	Carriage Bolt, 3/16 x 1 1/2 In.	80	41106	Tire
41	41890	Shoulder Bolt	81	24167	Valve Stem
42	4107	Washer	82	54767	Heat Shield, Muffler
			83	120238	Jam Nut, 1/3 Thd.

*Standard Hardware Items - May Be Purchased Locally
 †Contact Tecumseh, Peerless, authorized service dealer for parts and warranty
 ‡Contact Engine Manufacturer's authorized service dealer (See Engine Manual) for parts and warranty

36 RIDING MOWER MODEL 3560-004




36 RIDING MOWER MODEL 3560-004

Key No.	Part No.	Description	Key No.	Part No.	Description
1	274872	Screw, Hex Wa. Hd. 1/20 x 1/2 In.	44	995346	Screw, Taplite 1/4-20 x 1/2 In.
2	55832	Foam Pad, Hood Top	45	56220	Spring, Seat
3	50988	Gas Gauge	46	300284	Clip, Seat Spring
4	49050	Screw, Plastite 1/4-10 x 1/4 In.	47	56235	Cover, Rear Console
5	55834	Foam Pad, Hood R.H.	48	52470	Fender Assembly
6	53954	Hood	49	446363	Flatwasher, 5/16 In.
7	55040	Edging, Hood	50	122017	Screw, Hex Hd. 5/16-18 x 1 In.
8	54886	Pad, Vibration	51	56226	Console Assembly
9	138536	Lockwasher, Int. Thrst. 5/16 In.	52	55537	Bulkhead, Console
10	53446	Pin, Hood Latch	53	35287	Screw, Taplite, No. 8-32 x 1/4 In.
11	120394	Flatwasher, 13/32 In.	54	44008	Shaft, Steering
12	8482	Shoulder Bolt	55	44009	Pinion Gear
13	57159	Latch, Hood	56	454585	Roll Pin
14	55833	Foam Pad, Hood, L.H.	57	44011	Shoulder Bolt, Sector Gear
16	53402	Grille	58	48543	Sector Gear
17	9413534	Locknut, 1/8-18 Thd.	59	120369	Nut, Hex, 1/4-24 Thd.
18	56258	Bracket, Grille Support, L.H.	60	120382	Lockwasher, Split, 1/4 In.
19	120233	Screw, Hex Hd. 1/4-16 x 1 In.	61	36625	"E" Ring
20	120228	Screw, Hex Hd. 5/16-18 x 1/2 In.	62	56190	Drag Link
21	50720	Shoulder Bolt, Axle Pivot	63	124925	Nut, 1/4-24 Thd.
22	122201	Screw, Hex Hd. 1/4-16 x 2 1/4 In.	64	21275	Ball Joint
23	56261	Bracket, Deck Hanger	65	49447	Arm, Steering
24	9413447	Locknut, Hex, 3/16-18 Thd.	66	50546	Bearing, Spindle
25	56260	Bracket, Grille Support, R.H.	67	56400	Front Axle Assembly
26	39492	Retaining Ring	68	56362	Bracket, Front Axle Support
27	50117	Lever, Throttle Control	69	274654	Locknut, Hex, 1/4-20 Thd.
28	45174	Locknut, Wide Flange, 1/4-20 Thd.	70	2483	Spring Washer
29	9424215	Locknut, Hex, 1/4-20 Thd.	71	39573	Screw, Hex Hd, Lock, 1/4-24 x 1 In.
30	120383	Flatwasher	72	43954	Bracket, Deck Guide Support
31	53951	Dash Assembly	73	301258	Bracket, Deck Guide
32	54902	Bearing, Steering	74	49930	Upstop Bolt
33	456836	Spring Pin, 1/4 x 2 1/4 In.	75	55518	Spindle, Right
34	301251	Steering Wheel	76	55565	Tie Rod
35	120854	Screw, Hex Hd. 1/4-20 x 1/4 In.	77	55519	Spindle, Left
36	55387	Bracket, Support, Gas Tank	78	642	Flatwasher, 1/4 In.
37	57500	Seat	79	41108	Tire
38	20807	Shoulder Bolt	80	38878	Bearing
39	50807	Knob, Throttle Control Lever	81	24167	Valve Stem
40	70878	Decal, Lower Dash	82	38829	Wheel w/Bearing
41	57407	Seat Bracket	83	40394	Hub Cap
42	120838	Lockwasher, Split, 5/16 In.	85	57215	Screw, Plastite, 5/16-9 x 1/4 In.

*Standard Hardware Items May Be Purchased Locally.

36 RIDING MOWER MODEL 3560-004



ALL UNNUMBERED
ITEMS ARE INTERCHANGEABLE
WITH OPPOSITE SIDE


NOTE: ALWAYS USE ORIGINAL
EQUIPMENT PARTS. Use of
service replacement parts other
than original equipment parts may
void your warranty.

36 RIDING MOWER MODEL 3560-004

Key No.	Part No.	Description	Key No.	Part No.	Description
1	56180	Hairpin Cotter	57	57329	Lever, Height Adjust
3	47816	Pull Pin	58	56924	Hand Grip, Height Adjust Lever
5	120228	*Screw, Hex Hd, 5/16-18 x 3/4 In.	59	46478	Hand Grip, Deck Engage Lever
6	9413447	Locknut, 5/16-18 Thd	60	300188	Lever, Deck Engage
7	9413534	Locknut, 3/8-16 Thd	61	122040	*Screw, Hex Hd, 5/16-18 x 1 1/2 In.
9	57340	Pivot Bracket	62	57337	Bracket, Height Adjust
10	300341	Lift Cable	63	120393	*Flatwasher
11	57196	Pivot Rod	66	271184	*Nut, Hex, Keps, 5/16-18 Thd
12	57327	Lift Support Plate	67	300583	Spring
14	20864	Retaining Ring	72	126216	*Carriage Bolt, 5/16-18 x 3/4 In.
15	57325	Carriage Bolt, 3/8-16 x 2 In.	74	68543	Decal, Height Adjust
16	300841	Idler Pulley, Drive	75	122007	*Screw, Hex Hd, 5/16-18 x 3/4 In.
17	58170	V-Belt	77	57314	Skid Bar
18	300844	Belt Retainer	78	57588	Wire Assembly, Deck Switch
19	300491	Bracket, Blade Throwout Idler	81	120385	Flatwasher
21	300180	Shoulder Bolt	82	57322	Shoulder Bolt
22	35410	Spring	83	57360	Pivot Bracket
23	57478	Switch, Lockout	84	57818	Chute Guard
28	86424	Quill Assembly, (Incl. Nos. 29-37)	85	120834	Screw, Hex Hd, 5/16-18 x 1/2 In.
29	51445	Flange Nut, 7/16-20 Thd.	86	121222	Cotter Pin, 3/32 x 3/4 In.
30	56365	Flatwasher	87	49320	Support, Cable Pulley
31	56390	Pulley	88	49332	Pin, 3/8 x 1 In.
32	51449	Spacer	89	39298	Pulley, Nylon
33	49562	Bearing	90	159943	Screw, Pan Hd, No. 10-24 x 3/4 In.
34	50818	Spacer, Tube	91	121954	Screw, Hex Hd, 1/4-20 x 2 In.
35	65547	Quill Casting	92	271166	Keps Nut, No. 10-24 Thd.
36	50816	Dust Shield, Quill	93	41601	Rivet, Brake Pad
37	56425	Saddle and Shaft Assembly	94	41471	Brake Pad
38	57328	Belt Guard, L.H. Pulley	95	996416	Flatwasher, 3/4 In.
39	57444	Retainer, Wire	96	57328	Clutch Cable
40	58169	Mower Deck	97	52456	Retainer, Cable
42	300345	Screw, Taprite, 5/16-18 x 1 1/4 In.	98	57321	Spring
43	56821	Blade, 18 In.	99	57318	Retainer, Belt
44	2483	Spring Washer	100	8260	Hairpin Cotter
45	39573	Screw, Hex Hd, Lock, 3/8-24 x 1 In.	101	120396	Flatwasher
46	23783	Shoulder Bolt	102	9424215	Locknut, 1/4-20 Thd.
47	52584	Wheel Assembly, Deck	103	57334	Spring, Discharge Chute
48	58167	Pivot Tube Assembly	104	57317	Rod, Pivot
49	51984	Support, Pivot Tube	105	57324	Screw, Latch
50	300703	Clevis, Lift Cable	106	300318	Rod, Brake Release
51	39527	Pin, Clevis	107	180077	Screw, Hex Hd, 5/16-18 x 3/4 In.
52	120372	*Nut, Square, 1/4-20 Thd.	108	300179	Bracket, Idler
55	57319	Spring, Height Adjust Lever	109	44108	Locknut, Wide Flange, 5/16-18 Thd
58	995338	Screw, Taprite, 1/4-20 x 3/4 In.	110	300181	Brake Bracket Assembly
			111	136624	Rivet, Brake Pad

Standard Hardware Items - May Be Purchased Locally

36 RIDING MOWER MODEL 3560-004



Key No.	Part No.	Description	Key No.	Part No.	Description
1	39463	Ammeter	21	45877	Nut, Lockout Switch Part
2	300670	Key, Ignition	22	45878	Lockwasher (Lockout Switch Part)
3	48140	Locknut (Switch Part)	23	41204	Switch, Lockout
4	138557	Lockwasher (Switch Part)	24	48851	Wire Assembly Deck Switch
5	300687	Switch, Ignition	25	42071	Wire Assembly Bypass
6	49211	Fuse	26	0424215	Locknut Hex 5-20 Thd
7	301557	Wire Harness Assembly	27	16745	Screw Hex Hd 20 x 1/2 In
8	120375	Nut, Hex 5-20 Thd	28	138485	Lockwasher Ext. Tooth 5-16 In
9	120380	Lockwasher Spl. 3/16 In	29	120368	Locknut Hex 5-16 24 Thd
10	120392	Lockwasher 3/16 In	30	53710	Spind
11	56360	Bracket, Battery Hold Down	31	19734	Bracket, Switch Mounting
12	271184	Nut, Kept 5-16 18 Thd	32		Engine Part
13	271172	Nut, Kept 5-20 Thd	33	51888	Retainer Wire
14	40892	Cap, Battery	34	41482	Wire Clip Press
15	55511	Ground Wire	35	56188	Lead Wire Headlight
16	52936	Battery	36	50668	Screw Hex We Hd No 10-14 x 1/2 In
17	126203	Carriage Bolt 20 x 1/2 In	37	52571	Beret Headlight
18	126216	Carriage Bolt 5-16 18 x 1/2 In	38	52572	Barb Headlight
19	40234	Battery Rod	39	52570	Lens Headlight
20	56835	Nut, Hex 15-32/32 Thd			