


36" RIDING MOWER MODEL 3560-3200




-14-

15

Key No.	Part No.	Description	Key No.	Part No.	Description	Key No.	Part No.	Description
1	48812	Gas Tank	28	9413534	Locknut, Hex, 3/8-16 Thd.	54	43956	Shaft, Brake-Clutch Pedal
2	41008	Clip, Gas Line	29	28928	Shoulder Bolt	55	49654	Rod, Brake
3	41007	Gas Line	30	53858	Arm, Drive Idler	56	49653	Pivot Block
4	Engine	See Footnote Below	31	43953	Spacer	57	29483	Knob, Gear Shift
5	23700	Pipe Plug, 1/4 In.	32	43980	Rod, Clutch	58	9426210	Screw, Hex Wa. Hd. Taptime, No. 8-18 x 3/8 In.
6	45566	Oil Drain Tube	33	49276	Spring, Main Drive	59	41482	Press Clip
7	9413447	Locknut, Hex, 5/16-18 Thd.	34	122207	Screw, Hex Hd, 3/8-16 x 3 In.	60	43991	Belt Guide, Transaxle Pulley
8	120638	Lockwasher, Split, 5/16 In.	35	40223	Pulley, Backside Idler	61	120228	Screw, Hex Hd, 5/16-18 x 3/8 In.
9	180020	Screw, Hex Hd, 1/4-20 x 3/4 In.	36	39314	Retainer, Drive Belt, Backside Idler	62	49651	Bracket, Axle, L.H.
10	120380	Flatwasher, Split, 1/4 In.	37	49649	Spacer, Backside Idler	63	180080	Screw, Hex Hd, 5/16-18 x 1 1/2 In.
11	173063	Screw, Hex Hd, 5/16-18 x 3 1/2 In.	38	120394	Flatwasher, 3/8 In.	64	122007	Screw, Hex Hd, 5/16-18 x 3/4 In.
12	Engine Part		39	50737	V-Belt	65	49652	Bracket, Stabilizing
13	49993	Muffler	40	52199	Pulley, Transaxle	66	41105	Wheel
14	Gasket, Muffler (Engine Part)		41	431787	Key, Woodruff, No. 61	67	24167	Valve Stem
15	122040	Screw, Hex Hd, 5/16-18 x 1 1/2 In.	42	52317	Foot Pad, Left	68	41106	Tire
16	50653	Belt Guide, Blade Drive	43	53787	Main Frame	69	Transaxle	Peerless Model 601 See Warranty Page 22
17	40394	Hub Cap	44	42815	Flatwasher	70	40124	"U" Bolt
18	49896	Belt Guide, Transmission Drive Belt	45	52316	Foot Pad, Right	71	49650	Bracket, Axle, R.H.
19	271184	Nut, Hex, Keps, 5/16-18 Thd.	46	50980	Arm, Parking Brake	72	39395	Spring, Brake Return
20	120386	Nut, Hex, Keps, 5/16-18 Thd.	47	43958	Spring, Parking Brake	73	39628	Key, 3/16 x 3/16 x 2 1/2 In.
21	123567	Screw, Hex Hd, 7/16-20 x 1 In.	48	40974	Shoulder Bolt, Parking Brake	74	642	Flatwasher
22	120383	Lockwasher, Split	49	68585	Decal, Parking Brake	75	36625	"E" Ring, 3/4 In.
23	52418	Pulley, Engine	50	50562	Spring, Clutch Pedal	76	41529	Nut, Hex Jam, 3/8-16 Thd.
24	33200	Key, Engine Pulley	51	121222	Pin, Cotter, 3/32 x 3/4 In.	77	47498	Funnel, Oil Fill
25	120918	Screw, Hex Hd, 3/8-16 x 1 1/2 In.	52	52640	Brake Pedal Assembly			
26	35374	Pulley, Idler	53	53549	Rubber Pad, Brake Pedal			
27	39659	Belt Retainer						

Replacement engines and parts are obtainable from Engine Manufacturer's authorized Service Stations who are also to be contacted in regard to the Engine Warranty. See your Engine Manual for location of these stations.


36" RIDING MOWER MODEL 3560-3200



36" RIDING MOWER MODEL 3560-3200

Key No.	Part No.	Description	Key No.	Part No.	Description	Key No.	Part No.	Description
1	995346	Screw, Taprite, 1/4-20 x 1/2 In.	27	44009	Pinion Gear	53	9413534	Locknut, 3/8-16 Thd.
2	120228	Screw, Hex Hd, 5/16-18 x 3/8 In.	28	454565	Roll Pin	54	47852	Bracket, Grille Support, R.H.
3	52332	Spring, Seat	29	39580	Bearing, Steering	55	39829	Wheel w/Bearing
4	49339	Clip, Spring	30	36625	"E" Ring	56	50719	Bracket, Deck Hanger
5	50352	Locknut, 1/4-20 Thd.	31	44500	Bracket, Deck Guide	57	68584	Decal, Hanger, L.H.
6	9413447	Locknut, Hex, 3/16-18 Thd.	32	43964	Bracket, Deck Guide Support	58	68583	Decal, Hanger, R.H.
7	52656	Seat	33	39573	Screw, Hex Hd Lock, 3/8-24 x 1 In.	59	24167	Valve Stem
8	20507	Shoulder Bolt	34	24833	Spring Washer	60	50720	Shoulder Bolt, Axle Pivot
9	51072	Seat Bracket	35	44010	Sector Gear	61	39979	Bearing
10	120638	Lockwasher, Split	36	44011	Shoulder Bolt, Sector Gear	62	49447	Arm, Steering
11	49636	Fender, R.H.	37	120369	Nut, Hex, 3/8-24 Thd.	63	50546	Bearing, Spindle
12	49637	Fender, L.H.	38	120382	Lockwasher, Split, 3/8 In.	64	44062	Front Axle Assembly
13	446363	Flatwasher, 5/16 In.	39	44059	Drag Link Assembly	65	43988	Bracket, Front Axle Support
14	122017	Screw, Hex Hd, 5/16-18 x 1 In.	40	44060	Drag Link	66	274654	Locknut, Hex, 1/4-20 Thd.
15	53634	Console Assembly	41	124925	Nut, Hex, 3/8-24 Thd.	67	642	Flatwasher
16	9424215	Locknut, Hex, 1/4-20 Thd.	42	21275	Ball Joint	68	48844	Spindle, Right
17	35287	Screw, Taprite, No. 8-32 x 3/8 In.	43	46176	Side Panel, Hood, R.H.	69	48762	Tie Rod Assembly
18	48900	Screw, Hex Wash, Hd, 1/4-20 x 1 In.	44	44843	Pad, Vibration	70	48764	Tie Rod
19	39486	Knob, Throttle Control Lever	45	48835	Hood	71	41108	Tire
20	47083	Steering Wheel	46	49050	Screw, Plastite, 1/4-10 x 3/8 In.	72	48845	Spindle, Left
21	456836	Roll Pin	47	51578	Gas Gauge	73	9422616	Screw, No. 10-16 x 1/2 In.
22	39432	Bearing, Steering	48	46295	Side Panel, Hood, L.H.	74	46192	Nut, Tinnerman, No. 10-16
23	50077	Dash Assembly	49	40394	Hub Cap	75	120834	Screw, Hex Hd, 5/16-18 x 1/2 In.
24	50117	Lever, Throttle Control	50	54475	Grille	76	68542	Decal, Caution
25	39492	Retaining Ring	51	120233	Screw, Hex Hd, 3/8-16 x 1 In.	77	39239	Speed Nut
26	44008	Shaft, Steering	52	47851	Bracket, Grille Support, L.H.	78	49930	Upstop Bolt

36" RIDING MOWER MODEL 3560-3200




36" RIDING MOWER MODEL 3560-3200

Key No.	Part No.	Description
1	46478	Hand Grip
2	53693	Lever, Clutch
3	9424215	Locknut, 1/4-20 Thd.
4	46581	Spring, Clutch Lever
5	8260	Hairpin Cotter
6	9413447	Locknut, 5/16-18 Thd.
7	53247	Quadrant
8	46563	Shoulder Bolt
9	52636	Spring, Clutch Lever
10	120392	Flatwasher, 1/4 In.
11	53055	Idler Arm Assy. (Incl. Nos. 12 & 13)
12	41471	Brake Pad
13	41601	Rivet, Brake Pad
14	36410	Spring
15	9413534	Locknut, 3/8-16 Thd.
16	52695	Belt Retainer
17	52694	Pulley, Idler
18	122168	Screw, Hex Hd, 3/8-16 x 1 1/2 In.
19	47516	Shoulder Bolt
20	47517	Bracket, Idler Arm
21	45877	Nut (Lockout Switch Part)
22	45878	Lockwasher (Lockout Switch Part)
23	41204	Switch, Lockout
24	41482	Clip, Press
25	48851	Wire Assembly

Key No.	Part No.	Description
26	47816	Pull Pin
27	49059	Bar Hitch
28	49058	Lock Bracket
29	120228	Screw, Hex Hd, 5/16-18 x 3/8 In.
30	120918	Screw, Hex Hd, 3/8-16 x 1 1/2 In.
31	50613	Pivot Bracket
32	68542	Decal, Caution
33	53697	Push Nut
34	53815	Pin, Pivot
35	48676	Lift Support, Plate Assembly
36	122007	Screw, Hex Hd, 5/16-18 x 3/4 In.
37	996416	Flatwasher, 3/8 In.
38	51921	Skid
39	49878	V-Belt
40	51450	Quill Assembly (Incl. Nos. 41-49)
41	51445	Nut
42	446248	Flatwasher, 11/16 In.
43	51451	Pulley
44	51449	Spacer
45	49562	Bearing
46	50818	Spacer
47	50088	Quill Housing
48	50616	Dust Shield
49	51447	Saddle & Shaft Assembly
50	53696	Shoulder Bolt

Key No.	Part No.	Description
51	46365	Cover, Pulley, L.H.
52	39573	Screw, Hex Hd, 3/8-24 x 1 In.
53	46367	Baffle, L.H.
54	2483	Formed Washer
55	39311	Blade, 18 In.
56	68543	Decal, Height Adjust
57	122017	Screw, Hex Hd, 5/16-18 x 1 In.
58	50634	Cover, Pulley, R.H.
59	46364	Screw, Hex Hd, 5/16-18 x 2 1/4 In.
60	120696	Mower Deck
61	51943	Lift Cable
62	53037	Clevis, Lift Cable
63	39404	Square Nut, 1/4-20 Thd.
64	120372	Cotterpin, 3/32 x 3/4 In.
65	121222	Pin, Clevis
66	39522	Support, Pivot Tube
67	51985	Pivot Tube Assy.
68	52613	Wheel Axle
69	23763	Wheel
70	52584	Cotterpin
71	120123	Chute Extension
72	50993	Hand Grip
73	20250	Lever, Height Adjust
74	49131	Spring
75	53246	Decal, Danger
76	68902	Decal, Blade Engage
77	68900	Decal, Height Adjust
78	68901	Decal, Height Adjust

36" RIDING MOWER MODEL 3560-3200



Key No.	Part No.	Description
1	39463	Ammeter
2	40997	Switch w/ Knob, Headlight
3	40778	Knob, Headlight Switch
4	44745	Switch, Ignition w/Keys
5	138557	Lockwasher (Switch Part)
6	48140	Locknut (Switch Part)
7	49643	Key, Ignition
8	45333	Ignition Light
9	52791	Wire Harness Assembly
10	49211	Fuse
11	997208	Wing Nut, Nylock, 1/4-20 Thd.
12	120386	Flatwasher, 1/4 In.
13	40243	Bracket, Battery, Hold-Down
14	271172	Nut, Keps, 1/4-20 Thd.
15	40892	Cap, Battery
16	52936	Battery
17	126203	Carriage Bolt, 1/4-20 x 5/8 In.
18	126216	Carriage Bolt, 5/16-18 x 3/4 In.
19	271184	Nut, Keps, 5/16-18 Thd.
20	40234	Battery Rod

Key No.	Part No.	Description
21	45877	Nut (Lockout Switch Part)
22	45878	Lockwasher (Lockout Switch Part)
23	41204	Switch, Lockout
24	48851	Wire Assembly, Deck Switch
25	42071	Wire Assembly, By-Pass
26	120368	Locknut, Hex, 5/16-24 Thd.
27	138485	Washer, Shakeproof
28	9424215	Locknut, hex, 1/4-20 Thd.
29	121900	Screw, Hex Hd, 1/4-20 x 1 In.
30	49734	Bracket, Switch Mounting
31	53716	Solenoid
32	9413447	Locknut, Hex, 5/16-18 Thd.
33		Engine Part
34	41482	Wire Clip, Press
35	52800	Lead Wire, Headlight
36	50668	Screw, Hex Wa. Hd, No. 10-14 x 1/2 In.
37	52573	Socket, Headlight
38	52571	Bezel, Headlight
39	52570	Lens, Headlight
40	52572	Bulb, Headlight