


# REPAIR PARTS

## 36" RIDING MOWER MODEL 3560-5400



**36" RIDING MOWER MODEL 3560-5400**

ALWAYS GIVE THE FOLLOWING INFORMATION WHEN ORDERING REPAIR PARTS:

1. The PART NUMBER; 2. The PART NAME; 3. QUANTITY DESIRED; 4. The MODEL NUMBER (As shown on Model Plate)

SEND PART ORDERS AS PER INSTRUCTIONS ON THE FRONT PAGE

YOUR UNIT IS RIGHT HAND (RH) OR LEFT HAND (LH) AS YOU STAND BEHIND IT.

DO NOT USE KEY NUMBERS WHEN ORDERING REPAIR PARTS. ALWAYS USE PART NUMBERS.

All replacement parts will be supplied in current production colors or in a neutral color.


A handling fee is applicable to small parts orders.

Key No.	Part No.	Description	Key No.	Part No.	Description
1	53950	Muffler	43	24187	Valve Stem
2	48074	Tube, Exhaust	44	41106	Tire
3	44856	Clamp, Exhaust Tube	45	122077	Screw, Hex Hd, 5/16-18 x 2 1/2 In.
4		Gasket, Muffler (Engine Part)	46	Transaxle	†Peerless 4 speed, Model 900
5	120638	Lockwasher, Split, 5/16 In.	47	35410	Spring, Brake Return
6	9421705	Screw, Hex Soc. Hd, 5/16-18 x 3/4 In.	48	842	Flatwasher
7	41008	Clip, Gas Line	49	36625	"E" Ring
8	42258	Gas Line	50	42815	Flatwasher
9	48812	Gas Tank	51	40394	Hub Cap
10	54873	Trough, Oil Drain	52	9413447	Locknut, Hex, 5/16-18 Thd.
11	Engine	§See Footnote Below	53	53788	Bracket, Axle
12	56430	Spacer, Engine Pulley	54	446363	Flatwasher, 3/8 In.
13	56432	Key, Engine Pulley	55	122017	Screw, Hex Hd, 5/16-18 x 3/4 In.
14	120386	Flatwasher, 1/4 In.	56	4107	Washer
15	271184	Nut, hex, Keps, 5/16-18 Thd.	57	41890	Shoulder Bolt
16	56433	Pulley, Engine	58	9413534	Locknut, Hex, 3/8-16 Thd.
17	56431	Pilot Washer	59	39659	Belt Retainer
18	120383	Lockwasher, Split, 7/16 In.	60	43980	Rod, Clutch
19	181882	Screw, Hex Hd, 7/16-20 x 4 In.	61	35374	Pulley, Idler
20	49896	Belt Guide, Trans. Drive Belt	62	274517	Flatwasher, 25/64 In.
21	50653	Belt Guide, Blade Drive	63	53762	Idler Arm
22	271190	Nut, Hex Keps, 3/8-16 Thd.	64	45882	Carriage Bolt, 3/8-16 x 1 1/2 In.
23	138489	Washer, External Lock, 3/8 In.	65	49278	Spring, Main Drive
24	50947	Screw, Tapite, 3/8-16 x 1 1/4 In.	66	54955	Foot Pad, L.H.
25	50968	Belt Guard Assy.	67	54751	Main Frame
26	120228	Screw, Hex Hd, 5/16-18 x 3/4 In.	68	41529	Locknut, 3/8-16 Thd.
27	137186	Pin, Cotter, 1/8 x 1 In.	69	54888	Retainer, Wire
28	56256	Shift Bracket	70	45602	Washer
29	50618	Washer, 1/2 In.	71	54618	Foot Pad, R.H.
30	56255	Screw, Nylock, 1/4-28 x 3/4 In.	72	138485	Washer, Ext. Lock, 5/16 In.
31	54569	Washer, 1/4 In.	73	20507	Shoulder Bolt
32	55514	Knob, Gear Shift	74	54723	Bracket, Brake Rod
33	55526	Shift Lever	75	54715	Rod, Brake
34	54758	V-Belt	76	40974	Shoulder Bolt, Parking Brake
35	55520	Pulley, Transaxle	77	43968	Spring, Parking Brake
36	3021	Key, Woodruff, No. 806	78	50980	Arm, Parking Brake
37	22053	Retaining Ring	79	50562	Spring, Clutch Pedal
38	54713	Bracket, Stabilizer	80	121222	Pin, Cotter, 3/32 x 3/4 In.
39	122007	*Screw, Hex Hd, 5/16-18 x 3/4 In.	81	55722	Brake Pedal Assy.
40	35498	Screw, Hex Wa. Tap, 5/16-18 x 3/4 In.	82	53979	Rubber Pad, Brake Pedal
41	39628	Key, 3/16 x 3/16 x 2 1/2 In.	83	55025	Retainer, Brake Pad
42	41105	Wheel	84	43956	Shaft, Brake-Clutch Pedal

†Contact Tecumseh/Peerless authorized service dealer for parts and warranty.

§Contact Engine Manufacturer's authorized service dealer (See Engine Manual) for parts and warranty.

36" RIDING MOWER MODEL 3560-5400




### 36" RIDING MOWER MODEL 3560-5400

Key No.	Part No.	Description	Key No.	Part No.	Description
1	40394	Hub Cap	50	54885	Pad, Vibration
2	52272	Seat	51	55045	Edging, Hood
3	20507	Shoulder Bolt	52	53954	Hood
4	56193	Seat Bracket	53	49050	Screw, Plastite, ¼-10 x ¾ In.
5	120638	*Lockwasher, Split, 5/16 In.	54	50988	Gas Gauge
6	120834	*Screw, Hex Hd, 5/16-18 x 1½ In.	55	138538	Lockwasher, Int. 5/16 In.
7	995346	*Screw, Taptite, ¼-20 x ½ In.	56	53446	Pin, Hood, Latch
8	52332	Spring, Seat	57	120394	*Flatwasher, 13/32 In.
9	53744	Clip, Seat Spring	58	55020	Latch, Hood
10	54668	Bracket, Seat Spring	59	8482	Shoulder Bolt
11	120228	*Screw, Hex Hd, 5/16-18 x ¾ In.	60	50352	Locknut, Wide Flange, ¼-20 Thd.
12	54680	Fender Assembly, R.H.	61	53402	Grille
13	120708	*Screw, Hex Hd, ¼-20 x ½ In.	62	56260	Bracket, Grille Support, R.H.
14	54676	Rail, Side, R.H.	63	9413534	Locknut, ¾-16 Thd.
15	120375	*Nut, Hex, ¼-20 Thd.	64	56259	Bracket, Grille Support, L.H.
16	9424215	Locknut, Hex, ¼-20 Thd.	65	120233	*Screw, Hex Hd, ¾-16 x 1 In.
17	54678	Brace, R.H.	66	50720	Shoulder Bolt, Axle Pivot
18	120392	*Flatwasher, 9/32 In.	67	122201	*Screw, Hex Hd, ¾-16 x 2¾ In.
19	54672	Tailgate	68	56261	Bracket, Deck Hanger
20	8260	Hairpin Cotter, 3/32 x 1½ In.	69	69762	Decal, Shift Pattern
21	54675	Rail, Rear	70	21275	Ball Joint
22	54679	Brace, L.H.	71	124925	Nut, Hex, ¾-24 Thd.
23	446363	*Flatwasher, 5/16 In.	72	56190	Drag Link
24	122017	*Screw, Hex Hd, 5/16-18 x 1 In.	73	36625	"E" Ring
25	55630	Body Assembly	74	44011	Shoulder Bolt, Sector Gear
26	54677	Rail, Side, L.H.	75	48643	Sector Gear
27	995338	*Screw, Taptite, ¼-20 x ¾ In.	76	49447	Arm, Steering
28	54681	Fender Assembly, L.H.	77	120382	*Lockwasher, Split, ¾ In.
29	50559	Screw, Hex Hd, ¼-20 x ½ In.	78	120369	*Nut, Hex, ¾-24 Thd.
30	9413447	Locknut, Hex, 3/16-18 Thd.	79	60546	Bearing, Spindle
31	55541	Bracket, Console	80	56400	Front Axle Assembly
32	55546	Console Assembly	81	56362	Bracket, Front Axle Support
33	54902	Bearing, Steering	82	274654	Locknut, ¼-20 Thd.
34	44009	Pinion Gear	83	2483	Spring Washer
35	454565	Roll Pin	84	55518	Spindle, Right
36	44008	Shaft, Steering	85	49930	Upstop Bolt
37	39492	Retaining Ring	86	39573	Screw, Hex Hd, Lock, ¾-24 x 1 In.
38	50117	Lever, Throttle Control	87	43964	Bracket, Deck Guide Support
39	35287	Screw, Taptite, No. 8-32 x ¾ In.	88	44500	Bracket, Deck Guide
40	274672	Screw, Hex Hd, ¼-20 x ¾ In.	89	39829	Wheel w/Bearing
41	69763	Decal, Dash	90	55666	Tie Rod
42	50607	Knob, Throttle Control Lever	91	55519	Spindle, Left
43	53951	Dash Assembly	92	642	Flatwasher
44	456836	Roll Pin	93	39830	Tire
45	55633	Steering Wheel	94	39979	Bearing
46	55387	Bracket, Support	95	24167	Valve Stem
47	120854	*Screw, Hex Hd, ¼-20 x ¾ In.			
48	45174	Locknut, Wide Fl., ¼-20 Thd.			
49	120386	Flatwasher, 5/16 In.			

\*Standard Hardware Items - May Be Purchased Locally.


36" RIDING MOWER MODEL 3560-5400



**36" RIDING MOWER MODEL 3560-5400**

Key No.	Part No.	Description	Key No.	Part No.	Description
1	47816	Pull Pin	44	996425	Flatwasher
2	56180	Cotter Pin	45	55724	Pin, Pivot
3	49059	Bar Hitch	46	48676	Lift Support, Plate Assembly
4	49058	Lock Bracket	47	996416	Flatwasher, 3/8 In.
5	9413447	Locknut, 5/16-18 Thd.	48	48044	V-Belt
6	9413634	Locknut, 3/8-16 Thd.	49	51323	Belt Guard Assembly
7	50613	Pivot Bracket	50	56424	Quill Assembly
8	120918	Screw, Hex Hd, 3/8-16 x 1 1/2 In.	51	51445	Nut
9	120228	Screw, hex Hd, 5/16-18 x 3/8 In.	52	56365	Flatwasher
10	48851	Wire Assembly	53	56390	Pulley
11	56546	Retainer, Wire	54	51449	Spacer
12	41482	Clip, Press	55	49562	Bearing
13	41204	Switch, Lockout	56	50818	Spacer
14	45877	Nut (Lockout Switch Part)	57	55547	Quill Housing
15	45878	Lockwasher (Lockout Switch Part)	58	50616	Dust Shield
16	47516	Shoulder Bolt	59	56425	Saddle & Shaft Assembly
17	47517	Bracket, Idler Arm	60	46365	Cover, Pulley, L.H.
18	56635	Nut, Hex	61	122007	Screw, Hex Hd, 5/16-18 x 3/4 In.
19	35410	Spring	62	122017	Screw, Hex Hd, 5/16-18 x 1 In.
20	52695	Belt Retainer	63	50634	Screw, Taptite, 5/16-18 x 7/8 In.
21	52694	Pulley, Idler	64	51264	Baffle
22	122168	Screw, Hex Hd, 3/8-16 x 1 3/4 In.	65	120854	Screw, Hex Hd, 1/4-20 x 3/8 In.
23	53696	Shoulder Bolt	66	55655	Baffle, L.H.
24	52636	Spring, Clutch Lever	67	50002	Spacer, Blade
25	41471	Brake Pad	68	54884	Blade, 18 In.
26	41601	Rivat, Brake Pad	69	2483	Formed Washer
27	46563	Shoulder Bolt	70	47665	Screw, hex Hd, 3/8-24 x 1 1/4 In.
28	120392	Flatwasher, 1/4 In.	71	51985	Support, Pivot Tube
29	53055	Idler Arm Assy. (Incl. Nos. 25 & 26)	72	52613	Pivot Tube Assembly
30	9424215	Locknut, 1/4-20 Thd.	73	23763	Wheel Axle
31	46478	Hand Grip	74	52584	Wheel
32	53694	Lever, Clutch	75	120123	Cotterpin
33	46561	Spring, Clutch Lever	76	50993	Chute Extension
34	56799	Mower Deck	77	120696	Screw, Hex Hd, 5/16-18 x 2 1/4 In.
35	68901	Decal, Height Adjust	78	53246	Spring
36	53520	Quadrant	79	50027	Lever, Height Adjust
37	53697	Push Nut	80	20250	Hand Grip
38	68900	Decal, Blade Engage	81	39522	Pin, Clevis
39	46364	Cover, Pulley, R.H.	82	8260	Hairpin Cotter
40	68902	Decal, Caution	83	120372	Square Nut, 1/4-20 Thd.
41	274517	Flatwasher, 25/64 In.	84	39404	Clevis, Lift Cable
42	51318	Idler Guard Assembly	85	55880	Lift Cable
43	20864	E-Ring			

### 36" RIDING MOWER MODEL 3560-5400



Key No.	Part No.	Description	Key No.	Part No.	Description
1	39463	Ammeter	20	138485	Washer, Shakeproof
2	49643	Key, Ignition	21	187745	Screw, Hex Hd, 1/4-20 x 3/4 In.
3	48140	Locknut (Switch Part)	22	9424216	Locknut, Hex, 1/4-20 Thd.
4	138557	Lockwasher (Switch Part)	23	53716	Solenoid
5	52583	Switch, Ignition w/Keys	24	58635	Nut, Hex, 15/32-32 Thd.
6	49211	Fuse	25	45877	Nut (Lockout Switch Part)
7	56349	Wire Harness Assembly	26	46878	Lockwasher (Lockout Switch Part)
8	126203	Carriage Bolt, 1/4-20 x 5/8 In.	27	41204	Switch, Lockout
9	271172	Nut, Keps, 1/4-20 Thd.	28	43038	Wire Assembly, Deck Switch
10	55511	Ground Wire	29	42071	Wire Assembly, By-Pass
11	126216	Carriage Bolt, 5/16-18 x 3/4 In.	30	49734	Bracket, Switch Mounting
12	120392	Flatwasher, 9/32 In.	31		Engine Part
13	120380	Lockwasher, Split, 1/4 In.	32	54888	Retainer, Wire
14	120375	Nut, Hex, 1/4-20 Thd.	33	41482	Wire Clip, Press
15	52936	Battery	34	56189	Lead Wire, Headlight
16	271184	Nut, Keps, 5/16-18 Thd.	35	50668	Screw, Hex Wa. Hd, No. 10-14 x 1/2 In.
17	40892	Cap, Battery	36	52571	Bezel, Headlight
18	54740	Bracket, Battery, Hold-Down	37	52572	Bolt, Headlight
19	120368	Nut, Hex, 5/16-24 Thd.	38	52570	Lens, Headlight