


LIGHT GROUND ENGAGING TRACTOR MODEL 3583-1200




LIGHT GROUND ENGAGING TRACTOR MODEL 3583-1200

ALWAYS GIVE THE FOLLOWING INFORMATION WHEN ORDERING REPAIR PARTS:
 1. THE PART NUMBER 2. THE PART NAME 3. QUANTITY DESIRED 4. THE MODEL NUMBER - (As shown on Model Plate)
 SEND PART ORDERS AS PER INSTRUCTIONS ON THE FRONT PAGE
 YOUR UNIT IS RIGHT HAND (RH) OR LEFT HAND (LH) AS YOU STAND BEHIND IT.
 DO NOT USE KEY NUMBERS WHEN ORDERING REPAIR PARTS, ALWAYS USE PART NUMBERS
 All replacement parts will be supplied in current production colors or in a neutral color.
 A handling fee is applicable to small parts orders.

Key No.	Part No.	Description	Key No.	Part No.	Description	Key No.	Part No.	Description
1	47063	Steering Wheel	20	68564	Decal, Deck Hanger, L.H.	39	49400	Tire, Rear
2	485836	Roll Pin, 1/4 x 2 1/4 In.	21	52554	Spacer	40	52908	Hub, Rear Wheel
3	63228	Shaft, Steering Wheel	22	36825	"E" Ring	41	181868	Bolt, Wheel
4	454565	Roll Pin, 1/4 x 1 1/4 In.	23	52407	Bearing, Front Spindle	42	9413447	Locknut, Hex, 5/16-18 Thd.
5	52426	Pinion	24	52717	Front Axle Assembly	43	44446	Spacer
6	52405	Bushing	25	52289	Front Spindle Assembly, R.H.	44	52648	Bracket, Stabilizer
7	21970	Flatwasher, 1 In.	26	52576	Tie Rod Assembly	45	120638	Lockwasher, Split
8	21682	Flatwasher, 3/4 In.	27	642	Flatwasher	46	35488	Screw, Hex Washer Tap, 5/16-18 x 3/4 In.
9	27184	Locknut, Keys, 5/16-18 Thd.	28	49613	Bushing	47	122007	Screw, Hex Hd, 5/16-18 x 3/4 In.
10	180177	Screw, Hex Hd, 1/2-13 x 1 1/2 In.	29	24167	Valve Stem	48	122083	Screw, Hex Hd, 5/16-18 x 2 3/4 In.
11	52406	Eccentric, Steering Adjust	30	49401	Wheel, Front	49	120366	Washer
12	22285	Sector Gear	31	49389	Tire, Front	50	52928	Key
13	9414074	Washer	32	120382	Lockwasher, Split, 3/8 In.	51	Transaxle	Peerless, Model 801
14	52376	Locknut, 1/2-13 Thd.	33	120369	Nut, Hex, 3/8-24 Thd.	52	20607	Shoulder Bolt
15	124925	Drag Link Assembly	34	52390	Front Spindle Assembly, R.H.	53	52398	Bracket, Brake
16	21275	Nut, hex Jam, 3/8-24 Thd.	35	273326	Zerk, Grease, 1/2-28 Thd.			
17	52539	Ball Joint Assembly	36	52403	Bolt, Front Axle Pivot			
18	66593	Bracket, Deck Hanger	37	52906	Lug Nut, 7/16-20 Thd.			
19		Decal, Deck Hanger, R.H.	38	49402	Wheel, Rear			

LIGHT GROUND ENGAGING TRACTOR MODEL 3583-1200



06/02/2004 09:15 +44129726855
 Feb 05 04 01:11p MURRAY, Inc.

ANNE CAMPBELL
 6153736798

PAGE 03/09
 P.5

LIGHT GROUND ENGAGING TRACTOR MODEL 3583-1200

Key No.	Part No.	Description	Key No.	Part No.	Description	Key No.	Part No.	Description
1	52796	Bulkhead, Hood	20	33200	Key, ¼ x ¼ x 1½ In.	40	45892	Carriage Bolt, ¾-16 x 1½ In.
2	52775	Baffle, Engine	21	120383	Lockwasher, Split, 7/16 In.	41	52402	Rod, Clutch
3	995338	Screw, Taprite, ¼-20 x ¾ In.	22	123567	Screw, Hex Hd., 7/16-20 x 1 In.	42	41529	Jamnut, ¾-16 Thd.
4	120854	Screw, Hex Hd., ¼-20 x ¾ In.	23	52842	V-Belt	43	45602	Washer
5	120380	Lockwasher, Split, ¼ In.	24	52658	Pulley, Inout	44	120229	Screw, Hex Hd., 5/16-18 x ¾ In.
6	41482	Press Clip	25	3021	Key, Woodruff, No. 606	45	29170	Spring
7	Engine	See Footnote Below	26	22053	Retaining Ring	46	138485	Washer, Shakeproof
8	9413447	Locknut, Hex, 5/16-18 Thd.	27	120228	Screw, Hex Hd., 5/16-18 x ¾ In.	47	52885	Bracket, Shift Lever
9	52077	Exhaust Tube	28	52647	Hitch, Tractor	48	271184	Locknut, Keps, 5/16-18 Thd.
10	35287	Screw, Hex Washer Hd., No. 8-32 x ¾ In.	29	51297	Spring, Clutch	49	52859	Shift Lever
11	50861	Clip, Cable	30	52385	Brake Rod	50	52860	Stud, Gear Shift
12	35258	Screw, Taprite, No. 10-24 x ¾ In.	31	120393	Washer	51	29483	Knob, Shift Lever
13	52404	Tube, Oil Drain	32	48253	Washer	52	20507	Shoulder Bolt
14	47828	Cap, Oil Drain Tube	33	121222	Cotter Pin	53	52856	Link, Shift
15	271190	Nut, Keps, ¾-16 Thd.	34	41890	Shoulder Bolt	54	123216	Screw, Hex Hd., ¼-28 x ½ In.
16	52482	Belt Guide	35	9413534	Locknut, Hex, ¾-16 Thd.	55	996425	Flatwasher, ½ In. I.D.
17	52401	Belt Guide	36	39659	Belt Retainer	56	120386	Flatwasher
18	122040	Screw, Hex Hd., 5/16-18 x 1½ In.	37	35374	Pulley, Idler	57	48148	Screw, Taprite, 3/8-16 x 1 In.
19	60792	Pulley, Engine	38	274517	Washer			
			39	52411	Idler Arm			


06/02/2004 09:15 +44129726855
 Feb 05 04 01:11p MURRAY, Inc.

ANNE CAMPBELL
 6153736798

PAGE 04/09
 P.6

Replacement engines and parts are obtainable from Engine Manufacturer's authorized Service Stations who are also to be contacted in regard to the Engine Warranty. See your Engine Manual for location of these stations.

LIGHT GROUND ENGAGING TRACTOR MODEL 3583-1200



06/02/2004 09:15 +441279726865
Feb 05 04 01:11p MurrRay, Inc.

ANNE CAMPBELL
6153736798

PAGE 06/09
P. 7

LIGHT GROUND ENGAGING TRACTOR MODEL 3583-1200


Key No.	Part No.	Description	Key No.	Part No.	Description	Key No.	Part No.	Description
1	52804	Grille	20	52086	Cable, Choke	40	52676	Foot Pad, L.H.
2	52272	Seat	21	138489	Washer, Shakeproof, 3/8 In.	41	52676	Foot Pad, R.H.
3	50352	Locknut, Flange, 1/4-20 Thd.	22	124925	Jam Nut	42	122017	Screw, Hex Hd, 5/16-18 x 1 1/4 In.
4	9424215	Locknut, Hex, 1/4-20 Thd.	23	44843	Pad, Fuel Tank	43	52357	Guide Support, Rear Mower Deck
5	50788	Lanyard, Hood	24	52536	Tank, Fuel	44	44500	Guide, Rear, Mower Deck
6	36149	Shoulder Bolt	25	49050	Screw, Plastic	45	52568	Brace, Fender Support
7	48900	Screw, Hex Wa. Hd, 1/4-20 x 1 In.	26	47345	Clamp, Fuel Line	46	995338	Screw, Hex Hd, 1/4-20 x 3/8 In.
8	50893	Hood Assembly	27	51211	Tubing, Fuel Line	47	53677	Console
9	52569	Gas Gauge	28	41008	Clamp, Fuel Line	48	120388	Flatwasher, 1/4 In.
10	8432	Shoulder Bolt	29	462	Retaining Ring	49	51410	Reflector
11	83447	Latch, Hood	30	51413	Spring, Return	50	51411	Screw, Pan Hd, No. 8-18 x 3/8 In.
12	995346	Screw, Torx, 3/4-20 x 1/2 In.	31	52400	Rod, Brake-Clutch	51	53620	Fender Assembly
13	53446	Pin, Hood Latch	32	66585	Decal, Parking Brake	52	52332	Spring, Seat
14	271166	Nut, Keps, No. 10-24 Thd.	33	48160	Rubber Pad, Pedal	53	49339	Clip, Seat Spring
15	9413447	Locknut, Hex, 5/16-18 Thd.	34	52576	Brake Pedal Assembly	54	52345	Mounting Bracket, Seat
16	52566	Dash Assembly	35	53327	Main Frame	55	120834	Screw, Hex Hd, 5/16-18 x 1/2 In.
17	35291	Screw, Hex Hd, No. 10-24 x 1/2 In.	36	52335	Bracket, Grille, L.H.	56	120838	Lockwasher, Split, 5/16 In.
18	39486	Knob, Throttle Control	37	52334	Bracket, Grille, R.H.	57	20507	Shoulder Bolt
19	52085	Throttle Control	38	120228	Screw, Hex Hd, 5/16-18 x 3/4 In.	58	53905	Tab, Hood Latch
			39	52380	Bracket, Axle Support, Front	59	45174	Wide Flange Nut

06/02/2004 09:15 +441279726865
Feb 05 04 01:11p MurrRay, Inc.

ANNE CAMPBELL
6153736798

PAGE 06/09
P. 8


LIGHT GROUND ENGAGING TRACTOR MODEL 3583-1200



LIGHT GROUND ENGAGING TRACTOR MODEL 3583-1200

Key No.	Part No.	Description	Key No.	Part No.	Description
1	49330	V-Belt	48	120386	Flatwasher, 5/16 In.
2	120918	Screw, Hex Hd, 3/8-16 x 1 1/2 In.	48	53571	Chute, Discharge
3	51134	Pulley, Idler	49	271184	Keps Nut, 5/16-18 Thd.
4	49318	Belt Retainer	50	49316	Brake Lever Assembly (Includes Items 6 & 7)
5	9413534	Locknut, 3/8-16 Thd.	51	68882	Decal, Height Adjust
6	41471	Pad, Brake	52	68542	Decal, Caution
7	41601	Rivet	53	122007	Screw, Hex Hd, 5/16-18 x 3/4 In.
8	52112	Clutch-Brake Arm Assembly	54	51566	Skid, R.H.
9	51183	Eyebolt	55	126358	Carriage Bolt, 5/16-18 x 1 In.
10	9413447	Locknut, 5/16-18 Thd.	56	53037	Lift Cable
11	35410	Spring	57	49309	Mower Deck
12	49331	Spring, Clutch	58	50634	Screw, Hex Washer Hd., Taptite, 5/16-18 x 3/4 In.
13	120228	Screw, Hex Hd, 5/16-18 x 3/8 In.	59	52911	Belt Guard, L.H.
14	122017	Screw, Hex Hd, 5/16-18 x 1 In.	60	51438	Quill Assembly
15	50683	Brake Rod	61	51445	Locknut, Flange, 7/16-20 Thd.
16	45877	Nut, Switch	62	446248	Flatwasher, 11/16 In. I.D.
17	47517	Bracket, Idler Arm	63	51442	Pulley, Quill
18	45878	Washer, Switch	64	51441	Spacer
19	41204	Switch	65	49562	Bearing
20	48851	Wire Assembly	66	50818	Spacer Lube
21	41482	Press Clip	67	51439	Saddle and Shaft Assembly
22	47516	Shoulder Bolt	68	50088	Quill Casting
23	48676	Lift Support Plate	69	50616	Dust Shield
24	53697	Push Nut	70	120393	Flatwasher
25	53815	Pin, Pivot	71	49321	Skid, L.H.
26	50613	Bracket, Pivot	72	120330	Carriage Bolt, 5/16-18 x 1 1/4 In.
27	49059	Bar Hitch, Straight	73	49312	Blade, 14 1/2 In.
28	8260	Hair Pin Cotter	74	2483	Formed Washer
29	47816	Pin, Clevis, Short	75	39573	Screw, Hex Hd, 3/8-24 x 1 In.
30	49058	Bracket, Lock	76	42424	Support, Pivot Tube
31	52574	Bracket, Up Stop	77	39522	Pin, Clevis
32	53901	Screw, Hex Hd, Special, 1/4-20 x 1 1/2 In.	78	39404	Clevis, Lift Cable
33	46561	Spring, Clutch Lever	79	120372	Nut, Square, 1/4-20 Thd.
34	53694	Clutch Lever	80	49322	Brace, Pivot Tube
35	46478	Hand Grip	81	60092	Angle Bracket
36	53248	Quadrant	82	51299	Pivot Tube Assembly
37	271172	Keps Nut, 1/4-20 Thd.	83	52584	Wheel
38	49326	Clutch Cable	84	23763	Axle, Deck Wheel
39	9424215	Locknut, 1/4-20 Thd.	85	50027	Lever, Height Adjust
40	122052	Screw, Hex Hd, 5/16-18 x 1 3/4 In.	86	20250	Hand Grip, Height Adjust Lever
41	49320	Support, Cable Pulley	87	53246	Spring, Height Adjust Lever
42	49332	Pin, 3/8 x 1 In.	88	120696	Screw, Hex Hd, 5/16-18 x 2 1/4 In.
43	39298	Pulley, Nylon			
44	121222	Cotter Pin, 3/32 x 3/4 In.			
45	52912	Belt Guard, R.H.			
46	68652	Decal, No Step			

LIGHT GROUND ENGAGING TRACTOR MODEL 3583-1200



Key No.	Part No.	Description
1	39463	Ammeter
2	40997	Switch w/ Knob, Headlight
3	40778	Knob, Headlight Switch
4	44745	Switch, Ignition w/Keys
5	138557	Lockwasher (Switch Part)
6	48140	Locknut (Switch Part)
7	49643	Key, Ignition
8	45333	Ignition Light
9	53895	Wire Harness Assembly
10	49211	Fuse
11	997208	Wing Nut, Nylock, 1/4-20 Thd
12	120386	Flatwasher, 3/4 In.
13	40243	Bracket, Battery, Hold-Down
14	271172	Nut, Keps, 1/2-20 Thd.
15	40092	Cap. Battery
16	52936	Battery
17	126203	Carriage Bolt, 1/2-20 x 3/8 In.
18	126216	Carriage Bolt, 5/16-18 x 3/4 In.
19	271184	Nut, Keps, 5/16-18 Thd.
20	40234	Battery Rod

Key No.	Part No.	Description
21	45877	Nut (Lockout Switch Part)
22	45878	Lockwasher (Lockout Switch Part)
23	41204	Switch, Lockout
24	48851	Wire Assembly, Deck Switch
25	42071	Wire Assembly, By-Pass
26	120368	Locknut, Hex, 5/16-24 Thd.
27	138485	Washer, Shakeproof
28	9424215	Locknut, hex, 1/2-20 Thd.
29	121900	Screw, Hex Hd, 1/2-20 x 1 In.
30	49734	Bracket, Switch Mounting
31	53716	Solenoid
32	9413447	Locknut, Hex, 5/16-18 Thd.
33		Engine Part
34	41482	Wire Clip, Press
35	52800	Lead Wire, Headlight
36	50668	Screw, Hex Wa Hd, No. 10-14 x 1 1/2 In.
37	52573	Socket, Headlight
38	52571	Bezel, Headlight
39	52570	Lens, Headlight
40	52572	Bulb, Headlight