


MODEL 425601x53C

REPAIR PARTS CHASSIS AND HOOD




MODEL 425601x53C

REPAIR PARTS CHASSIS AND HOOD

Key No.	Description	Part No.	Key No.	Description	Part No.
16	Screw	26x249	37	Support, Dash	095082E510
19	Deck, Seat	094629E510	38	Bracket, Rear Hanger	1001270E701
22	Screw, Shoulder	009x47	39	Support, Left Grille	690544E700
23	Mat, Left	095408	40	Axle, Hanger	094007E700
24	Mat, Right	095409	41	Support, Right Grille	690543E700
25	Hood	093215E510	42	Rod, Pivot	093137 Z
26	Grille Assembly (Includes Lens)	093149	43	Frame, Right	1001268E701
28	Lens	093139	44	Frame, Left	1001269E701
29	Brace, Grille	093190	45	Container, Battery	690424
30	Pin, Hair	0031x4	46	Plate, Hitch	1001002E700
31	Screw	26x270	47	Plate, Rear	690218E700
32	Screw	26x238	48	Top, Rear Plate	094186E700
33	Bearing, Steering	094219	49	Channel	095081E700
34	Dash	094223	52	Fastener	193x1
35	Plate, Dash	094221E700	53	Supprot, Battery	690482E701
36	Panel, Access	093007E700	—	Instruction Book & Parts List	F-010796L






MODEL 425601x53C

REPAIR PARTS REAR CHASSIS ASSEMBLY

Key No.	Description	Part No.	Key No.	Description	Part No.
1	SEAT	095415	16	SPRING, COMPRESSION	164x30
2	SEAT DECK	094629E510	17	SCREW	26x249
4	CONTAINER, BATTERY	690424	20	BOLT, WING	1001054
5	SCREW, 1/4-20X .63	26x263	21	WASHER	017x47
6	PLATE, LIFT	094886E701	22	COVER, DETENT	094469
7	BOLT, SHOULDER	009X56	24	SCREW	26x284
8	SCREW, 10-24X.500	26x270	25	WASHER	17x207
9	SUPPORT, SEAT	094154E701	26	SPRING - LEAF	094057
10	HINGE, SEAT PIVOT	094156 Z	27	SCREW, 1/4-20X.50	26x229
11	NUT, PUSH CAP	028x23	32	BRACKET, PIVOT SEAT	094153E700
12	SPRING, COMPRESSION	164x31	33	BOLT, 5/16-18X.75	001x45
13	BOLT, SHOULDER	009x55	34	NUT, 5/16-18	015x88
14	WASHER, CUP	094155 Z	35	NUT, #10-24	015x81
15	NUT, 1/4-20	015x89			

MODEL 425601x53C

REPAIR PARTS DRIVE ASSEMBLY



MODEL 425601x53C

REPAIR PARTS DRIVE ASSEMBLY


Key No.	Description	Part No.	Key No.	Description	Part No.
1	Screw	26x249	30	Nut, Adjusting	092132
2	Grip, Parking Brake	091079	31	Nut, Centerlock	015x84
4	Rod, Parking Brake	1001271 Z	32	Pin, Cotter	030x20
5	Bracket, Transaxle – Left	094185E701	33	Washer	017x48
6	Rod, Clutch	1001013 Z	34	Spring, Extension	165x92
7	Latch, Parking Brake	094045 Z	35	Washer	17x148
8	V–Belt, Drive	37x106	36	Arm, Disconnect	1001086 Z
9	Nut, Flange	015x79	37	Capscrew	06x105
10	Pedal, Brake/Clutch	021544	38	Spring, Brake	165x150
11	Assembly, Brake Pedal	1001190E701	39	Locknut, Flange	015x98
12	Screw, Guide	094384	40	Pulley, Idler	690409
14	Bolt, Carriage	002x53	41	Spacer	690369
15	Washer	017x57	42	Bracket, Idler Assembly	1001097E701
16	Pin, Hair	0031x4	43	Bolt, Shoulder	009x49
17	Pedal Assembly, Hydro	1001231E700	44	Link, Clutch	1001007 Z
17a	Pad, Hydro Pedal	094798	45	Nut, Tee	1001014
18	Wheel & Tire Ass’y –Rear 20”	092511–601	46	Pulley, Idler	690410
--	Tire ONLY *	024430	47	Bushing, Pivot	1001012
--	Tube ONLY	407049	48	Arm Assembly, Idler	1001018 Z
19	Washer	17x160	49	Bracket, Transaxle –Right	094184E701
20	Spacer	690554 Z	50	Bolt, Hex	01x155
21	Stem, Valve	024373	51	Bracket, Disconnect	1001214 Z
22	Washer	17x195	52	Rod, Disconnect	1001215 Z
23	E–Ring	0011x3	53	Bracket, Idler Pivot	1001108E701
24	Cap, Hub	094618	54	Bolt, Carriage	002x92
25	Nut, Centerlock	015x88	55	Bolt, Carriage	002x78
26	Transaxle	**	56	Spring, Clutch	165x155
27	Strap, Torque	1001085E701	57	Washer	017x38
28	Screw	26x216	58	Cover, Wheel	334427
29	Rod, Control	1001234 Z	59	Retainer	694003

* When you order a tire, make sure to give the brand name of the tire so that the tread pattern on the tire will match.

** For information on Replacement Parts see the Central Parts Distributor in your area.

MODEL 425601x53C

REPAIR PARTS STEERING



MODEL 425601x53C

REPAIR PARTS STEERING


Key No.	Description	Part No.	Key No.	Description	Part No.
1	Wheel, Steering	095185	24	Washer	017x53 Z
2	Post, Steering	690626	25	Nut, Flange	015x84
3	Insert, Steering Wheel	711326	26	Axle Assembly	776115
4	Bearing	094124	27	Drag Link, Left	095329E701
5	Nut, Flange	15x111	28	Spindle Assembly, Right	094575E701
6	Bolt, Shoulder	009x57	29	Drag Link, Right	095328E701
7	Gear, Pinion	690183	30	Screw	26x249
8	Ring, Snap	011x25	31	Bearing, Wheel	091334
9	Gear, Sector	094121	32	Stem, Valve	024373
10	Bearing	094123	33	Tire *	024380
11	Bolt	001x84	—	Tube	407924
12	Plate, Steering	1001121E701	34	Wheel and Tire Assembly	094581-601
13	Plate, Engine	094006E700	35	Washer	17x195
14	Nut, Flange	015x88	36	Washer	17x192
15	Nut, Flange	15x118	37	Washer	17x113
16	Bracket, Hanger	1001270E701	38	Hub Cap	094618
17	Axle, Hanger	094007E700	39	Screw	26x267
18	Bolt	01x146	40	Bellows	092059
19	Pin, Cotter **	030x49	41	Bolt	0025x3
20	Bearing **	690150	43	Washer	17x146
21	Spindle Assembly, Left	094576E700	44	Cover, Wheel	334429
22	Bolt	01x111	45	Retainer	306669
23	Washer	17x104			

* When you order a tire, make sure to give the brand name of the tire so that the tread pattern on the tire will match.

** These parts are included when ordering Key number 26.

MODEL 425601x53C

REPAIR PARTS MOWER HOUSING SUSPENSION




MODEL 425601x53C

REPAIR PARTS MOWER HOUSING SUSPENSION

Key No.	Description	Part No.	Key No.	Description	Part No.
1	Grip	092698	22	Washer	17x168
2	Handle, PTO	094100 Z	23	Washer	017x57
3	Pad, Switch	094022 Z	24	Pin, Hair	0031x4
4	Bolt	0025x3	25	Washer	017x91 Z
5	Grip	092697	26	Bolt, Carriage	002x85
6	Spring	166x40	27	Lever Assembly, Lift	1001111E701
7	Washer	17x103	30	Pin	094067
8	Lever, Lift	690533	31	Bracket, Rear Suspension	094055E701
9	Lever, PTO	094017 Z	32	Spacer, Lifter	690151
10	Bolt, Shoulder	009x39	33	Bolt, Shoulder	009x53
11	Pin, Cotter	030x20	34	Bracket, Pivot	094015E700
12	Washer	017x57	36	Washer	17x191
13	Link, PTO	094004 Z	37	Nut, Flange	015x84
14	Nut, Flange	015x84	38	Spring	165x131
15	Screw	26x249	39	Nut, Flange	015x68
16	Spring	166x39	40	Bracket, PTO	094005E700
17	Bracket, PTO	094018E701	41	Hanger, Left Deck	094027E700
18	Spring	165x119	42	Hanger, Right Deck	094026E700
19	Crank, PTO	690394E701	43	Rod, Hanger	094158 Z
20	Link, Lift	690212E701	44	Bracket, Suspension	690539E701
21	Link, Lift Handle	690122E700	45	Plate, Stiffening	1001098E701

MODEL 425601x53C

REPAIR PARTS MOWER HOUSING




MODEL 425601x53C

REPAIR PARTS MOWER HOUSING

Key No.	Description	Part No.	Key No.	Description	Part No.
1	Pulley, Jackshaft	094199	33	Bolt, Carriage	002x53
2	Nut, Hex	15x121	34	Mandrell Housing	1001200
3	Belt, Mower Drive	037x88	35	Bracket, Suspension	690539E701
4	Pulley, Idler	690387	36	Adapter, Blade	690411
5	Nut, Flange	015x84	37	Blade	095100E701
6	Spacer, Pulley **	1001197	38	Washer	17x166
8	Link, Lift	690212E701	39	Washer	17x165
9	Pad, Friction	094137	40	Nut	15x100
10	Bolt, Shoulder	009x52	41	Spring	0166x4
11	Bracket, Suspension	094055E701	42	Cap, Push On	028x23
12	Pad Assembly, Left Brake	094049E701	43	Rod, Deflector	094957 Z
13	Knob	094068	44	Deflector Assembly	094707
14	Bolt, Shoulder	009x51	45	Bracket, Deflector Hinge	094956E700
15	Plate, Suspension	094128E700	46	Bracket, Front Hanger	094190E701
16	Spring	166x43	47	Washer	017x45
17	Nut, Flange	015x79	48	Guide, Belt	094781
18	Bracket, Suspension	094192E700	49	Spacer	690369
19	Pin, Hanger	095194	50	Bolt, Axle	094025
20	Washer	017x91	51	Washer	017x91
21	Pin, Hair	0031x4	52	Spring, Extension	165x119
22	Bolt	0025x7	53	Wheel, Gage	092683
23	Cover, Pulley	094051E701	54	Bracket, Right Wheel	1001260E701
24	Bolt, Shoulder	009x39	55	Bracket, Left Wheel	092423E700
25	Arm, Idler	690408E701	57	Screw	26x249
26	Spring	166x41	58	Stiffener	094604E700
27	Pad Assembly, Right Brake	094047E701	59	Housing, Blade *	094814E700
28	Bracket, Brake	094193E701	60	Ring, Locking	031x11
29	Spring	166x42	61	Nut, Flange	015x98
30	Bracket, Suspension	094191E700	1-61	Complete Housing Assembly	7601032
31	Plate	092426E701	62	Guide, Belt	094066
32	Nut, Flange	015x88			

* Includes Key No. 17, 18, 30, 31, 32, 33, 45, 46, 53, 54, 55, and 56.

* * This part is included when ordering Key number 34.




MODEL 425601x53C

REPAIR PARTS ENGINE AND CONTROL ASSEMBLY

Key No.	Description	Part No.	Key No.	Description	Part No.
1	ENGINE	————	31	HEAT SHIELD ASSEMBLY	092550
2	BOLT 3/8 X 1.25	0025x7	31-1	SHIELD, HEAT B/S	092551
9	SCREW	711606	31-2	RIVET, POP	007x93
10	PULLEY, STACK	690439 Z	31-3	BRACKET, RIGHT	092554 Z
12	WASHER	019x35	31-4	BRACKET, LEFT	092555 Z
13	BOLT	01X140	31-5	PLATE, HEAT SHIELD	092552
14	TANK, FUEL –ASSEMBLY	690322	32	MUFFLER, ROUND	690436
16	FUEL CAP	092317	34	MUFFLER ADAPTER	095207
17	TUBING (Must cut to length) *	7601033	38	SCREW	26x263
18	CLAMP, FUEL LINE *	095197	39	GASKET, MUFFLER	091309
19	OIL DRAIN VALVE ASSEMBLY	325547	40	BRACKET, LOCK	1001053
20	CAP, OIL DRAIN VALVE	327422	41	BOLT	009x59
21	THROTTLE, CONTROL	092371	42	SCREW	06X103
22	SCREW	26x201	46	NUT, 1/4-20	15x116
23	PLUG, DASH	093160	56	WASHER	17X170
30	SCREW	06x104			

MODEL 425601x53C

REPAIR PARTS ELECTRICAL SYSTEM



Key No.	Description	Part No.
1	Harness, Light Wire	250x92
	Socket, Light	092372
	Bulb, Light	090084
2	Harness, Chassis Wire	250x87
3	Switch, Ignition	092556
	Key, Ignition	1001304
	Nut, Hex	091489
	Cap, Ignition	091488
4	Switch, Limit	094136
5	Fuse	302031
	Holder, Fuse	407078
6	Solenoid	094613
	Screw, Mounting	26x229
	Locknut	15x116
7	Cable, Battery Ground	024x32
	Screw, Ground Cable	26x213
8	Battery	021075
	Bolt, Carriage	002x82
	Wingnut	014x79
	Boot, Cable	054148
9	Harness, Seat Switch Wire	250x67
10	Switch, Seat Sensor	094159
11	Cable	024x31
12	Ammeter	093156