

PARTS LIST

42817 x 99A

**Read and keep this parts list book for future reference.
This parts list book contains drawings and part numbers
necessary to obtain repair parts.
See the back cover for repair part ordering information.**




Record the following information about your unit. This information is necessary when ordering parts or in case of loss or theft.

WHERE PURCHASED: _____

DATE PURCHASED: Month _____ Day _____ Year _____


MODEL NO.: _____ **DATE OF MANUFACTURE:** _____



MODEL 42817x99A

42" S/D - L/T
 16 HP TEC. DRV ENGINE
 SMIRT-ON-THE-GO
 6-SPEED PEERLESS TRANSALE

**REPAIR PARTS
 CHASSIS & HOOD**



ATTACHMENTS

- | | |
|---------------------|------------------------|
| 24750 Mowing Kit | 24760 Catcher Assembly |
| 24750 Lawn Sweeper | 24830 Vic Wagon |
| 24435 Snow Blade | 24537 Snow Thrower |
| 24028 Wheel Weights | 24536 Top Chain |


MODEL 42817x99A

**REPAIR PARTS
 CHASSIS & HOOD**

Key No.	Description	Part No.	Key No.	Description	Part No.
1	Seat	92040	31	Rod, Pivot	93197Z
2	Plate Assembly, Switch	91963Z	32	Bearing	93155
3	Spring, Compression	164x26	33	Pin, Hair	31x4
4	Spring, Seat	91864	34	Bracket, Right Grille	92346E700
5	Slide, Spring	91822	35	Screw	26x248
6	Bolt, Shoulder	9x38	36	Mat	91901
7	Support, Seat	92394E700	37	Tray, Battery	91896
8	Lockwasher	16x16	38	Cap, Console *	02443F100
9	Bolt, Hex	1x45	39	Bolt	2x64
10	Locknut, Flange	15x88	40	Washer	17x36
11	Bracket, Pivot	92546E700	41	Rod, Battery	56589Z
12	Rod, Pivot	91730 Z	42	Cover, Shift	91905
13	Cap, Push On	26x23	43	Gate, Shift	91892
14	Insert, Front	92546F200	44	Brace, Grille	93190Z
15	Fender, Apron	91724F200	45	Washer	17x36Z
16	Hood	93215F200	46	Bolt, Hex	1x38
17	Grille	93198	47	Strut, Shifter	91910
18	Lens	93199	48	Locknut	15x66
19	Screw	9x47	49	Fender, SOG	92379F200
20	Fender	92326F200	—	Instruction Book	F-94704
21	Console Assembly	92547F200	—	Repair Parts Book	F-94769
22	Screw	26x289	—	Decal, Left Hood	44x4101
23	Dash Panel	93134	—	Decal, Right Hood	44x4100
24	Bearing, Steering	93135	—	Decal, Left Console	44x4008
25	Screw	26x289	—	Decal, Right Console	44x4010
26	Screw	26x270	—	Decal, Top Console - Warning	44x2586
27	Support, Dash	93136E700	—	Decal, Shift Pattern	44x119
28	Insert, Rear	92549F200	—	Plaque, Name (Hood)	280x56
29	Frame Assembly	92516F200	—	Plaque, Name (Grille)	280x57
30	Bracket, Left Grille	92347E700			

MODEL 42817x99A

REPAIR PARTS STEERING



MODEL 42817x99A


**REPAIR PARTS
 STEERING**

Key No.	Description	Part No.
1	Wheel, Steering	92076
2	Nut, Hex	15x118
3	Bolt, Hex	1x66
4	Post, Steering	01860Z
5	Bolt, Hex	1x74
6	Screw	26x249
7	Bracket, Sector	91716E700
8	Gear, Pinion	92007
9	Bearing	91766
10	Bolt, Hex	1x84
11	Locknut, Flange	15x67
12	Spacer	92564
13	Gear, Sector	92318
14	Bracket, Sector	91708E700
15	Kit, Steering Gear	402075
16	Bolt, Hex	1x146
17	Support, Rear Axle	92529E700
18	Rod, Tie	90038E700
19	Pin, Cotter	30x49
20	Bearing	92527
21	Washer	17x57
22	Pin, Cotter	30x20
23	Washer	17x113
24	Spindle Assembly, Right	91828E700
25	Spindle Assembly, Axle & Left	92519 F200
26	Support, Front Axle	92528E700
27	Tire*	91912
—	Tube	407047
28	Stem, Valve	24373
29	Bearing, Wheel	91334
30	Washer	17x115
31	Wheel & Tire Assembly	92287-601
32	Bearing	92097
33	Locknut, Flange	15x113
34	Link, Drag	91749F 200
36	Spacer, Pinion Gear	92280
38	Hub Cap (Optional)	24682

*When you order a tire, make sure to give the brand name of the tire so that the tread pattern on the tire will match.

MODEL 42817x99A

**REPAIR PARTS
 ENGINE MOUNT**




Key No.	Description	Part No.
1	Fuel Cap	01948
2	Fuel Tank	02942
3	Hose Clamp	01174
4	Fuel Line	23715
5	Hose Clamp	23713
6	Screw	202201
7	Support, Deah	03188E701
8	Throttle Control	02371
9	Engine*	08716-20020AA
10	Bolt, Engine Mount	25x7
11	Stack Pulley Assembly	025052
12	Lockwasher	10x03
13	Bolt, Hex	1x140
14	Washer	17x170
15	Pipe, Oil Drain	24000
16	Cap, Oil Drain	21851

F-84889


MODEL 42817x99A

REPAIR PARTS ELECTRICAL SYSTEM

POS	FUNCTION	CIRCUIT (MAKE)
1	OFF	G+L
2	RUN LIGHTS	B+L
3	RUN	NONE
4	START	B+S



1 NO TERMINAL MARKING




Key No.	Description	Part No.
1	Switch, Start Solenoid	91031
2	Locknut	16x98
3	Bolt, Hex	1x382
4	Battery	21076
-	Acid, Battery (Electrolyte)	90668
6	Cable, Battery Ground	24x9
8	Screw	28x248
7	Cable, Red Battery	24x12
9	Cap, Ignition	91488
9	Solenoid	24285
10	Nut, Hex	91480
10	Switch, Ignition	92977
13	Key, Ignition	20729
14	Harness, Chassis Wire	230x49
16	Fuse	54212
16	Holder, Fuse	407078
17	Switch, PTO	91289
18	Screw	28x233
19	Switch, Clutch	24273
20	Screw	25x2
21	Bracket, Light	92372
22	Bulb, Light	90094
23	Harness, Light Wire	250x40
24	Cover, Terminal	54148
25	Ammeter	93158

F-94883

MODEL 42817x99A

REPAIR PARTS MOTION DRIVE



F-94883

MODEL 42817x99A

**REPAIR PARTS
 MOTION DRIVE**


Key No.	Description	Part No.	Key No.	Description	Part No.
1	Grip	65449	53	Washer	17x148
2	Grip, Inner	20476	34	Yoke, Shift	920412
3	Handle, Shift	920315E	36	Bolt, Hex	1x82
4	Bolt, Shoulder	9x39	38	Lockwasher	16x32
5	Pin, Cotter	30x20	37	Washer	17x148Z
6	Washer	17x47Z	39	Pilot, Support	91689
7	Nut, Adjustable	21820	39	Bracket Assembly, Idler	920295E
8	Shifter Assembly	92043E70D	40	Spring, Motion Drive	165x765E
9	Guide, Belt	91754	41	Ring, Retainer	11x7
10	Locknut, Flange	15x34	42	Pulley, Motion Drive	91807
11	Screw	26x249	43	Pulley, Backside Idler	91179
12	Link, Clutch	91877	44	Key, Woodruff	20697
13	Washer, Curved	20x1	45	Transaxle, Complete Peerless Model No. 930-011**	
14	Locknut, Flange	16x87	46	Bolt, Carriage	2x64
16	Washer	17x45	47	Support, Transaxle	91804
16	Link Assembly, Shifter	92085	48	Screw	26x216
17	Screw	26x249	49	Locknut, Flange	15x38
18	Bracket, Support	91899Z	50	Key, Square	21563
19	Nut, Flange	15x79	51	Washer	17x160
20	Bolt, Hex	1x124	52	Spacer, Transaxle	87x100Z
21	Grip	91079	53	Tire (Included with Key No. 54) *	92374
22	Rod, Control	91727Z	—	Tube (Included with Key No. 54)	407049
23	Screw	26x214	54	Wheel and Tire Assembly	92290-60
24	Guide, Bracket	91825Z	55	Valve Stem	24373
25	Frame Assembly	92516F200	56	Washer	17x115
26	Pedal, Clutch/Brake	21544	57	E-Ring	11x3
27	Lever Assembly	91862E70D	58	Washer	17x53Z
28	Belt, Motion Drive	37x61	59	Hub Cap (Optional)	24582
29	Bracket, Lever Support	91719E70D	60	Plate, Belt Guide	92587E70D
30	Latch, Park Brake	91712Z	61	Guide, Belt	20619
31	Spring, Brake Extension	165x82			
32	Rod, Clutch	91808Z			

*When you order a tire, make sure to give the brand name of the tire so that the tread pattern on the tire will match.

**Parts are available from a Tecumseh Authorized Service Center. See the telephone directory.

MODEL 42817x99A

**REPAIR PARTS
MOWER HOUSING SUSPENSION**




MODEL 42817x99A

**REPAIR PARTS
MOWER HOUSING SUSPENSION**

Key No.	Description	Part No.
1	Grip	55449
2	Control, Blade Rotation	01700Z
3	Bolt, Hex	25x3
4	Locknut, Hex	15x07
5	Lever Assembly, Switch	01017E700
6	Bolt, Carriage	0x59
7	Spring, Tension	100x32
8	Bracket, Rear Hanger	02006E700
9	Nut, Flange	16x79
10	Nut, Adjusting	02132
11	Bracket, Adjuster Rod	02109F6
12	Washer	17x124
13	Pin, Hair	31x4
14	Washer	17x122
15	Pin, Pull	00027Z
17	Lever, Lower Blade Control	01707E700
18	Rod, Blade Control	01705Z
19	Plate, Adjuster	01741E701
20	Washer	17x109
21	Bracket, Pivot	020395E
22	Lifter Assembly	02065E700
23	Knob, Steel	01201
24	Grip	01300
25	Spring, Compression	104x21
26	Handle Assembly	010235E
27	Screw	20x40
28	Link, Suspension	02064E700
29	Washer	17x47Z
30	Washer	17x01Z
31	Cover, Lift Lever (Optional)	02157
32	Screw	20x000
33	Nut, Adjusting	21020

MODEL 42817x99A

**REPAIR PARTS
MOWER HOUSING**



MODEL 42817x99A

**REPAIR PARTS
 MOWER HOUSING**

Key No.	Description	Part No.	Key No.	Description	Part No.
1	Nut, Hex	15x100	36	Plate	92426E701
2	Lockwasher	18x33	36	Locknut, Flange	15x69
3	Pulley, Jackshaft	92425	37	Bolt, Carriage	2x53
4	Locknut, Flange	15x84	38	Deflector Assembly, Chute	924655E
5	Spacer	91903	39	Spring, Torsion	168x4
6	Belt, Blade Drive	37x76	40	Bracket, Hinge	91765E701
7	Pulley, Idler	91801	41	Bracket, Front Hanger	92405E701
8	Pin, Cotter	30x20	42	Rod, Deflector	91767Z
9	Locknut, Flange	15x88	43	Cap, Push On	28x23
10	Washer	17x46Z	44	Rod, Hanger	91739Z
11	Brake Assembly, Right	92413E700	45	Washer	17x124
12	Brake Assembly, Left	92411E700	46	Hanger, Front	921195E
13	Spring, Torsion	168x27	47	Washer	17x91Z
14	Bolt, Hex	25x6	48	Rod, Belt Guide	92424E700
15	Bracket Assembly, Brake	92415E700	49	Bolt, Hex	1x189
16	Rod, Brake	92421Z	50	Housing, Jackshaft	90905
17	Rod, Cross Link	92420Z	51	Jackshaft	91922
18	Pin, Hair	31x4	52	Adapter, Blade	92465
19	Nut, Adjustable	92132	53	Blade, 42" (2 required)	92418E701
20	Rod, Adjuster	92134Z	54	Washer, Belleville	17x166
21	Nut, Adjustable	21920	55	Washer	17x155
22	Link, Suspension	92064E700	56	Bracket, Pulley Cover	92418E700
23	Washer	17x103	57	Bracket, Idler Mount	92408E700
24	Bracket, Right	92402E700	58	Indicator, Plastic	92163
25	Nut, Flange	15x79	59	Bracket, Right Wheel	92422E700
26	Bracket, Pivot	920335E	60	Bolt, Shoulder	9x23
27	Bolt, Carriage	9x33	61	Bracket, Left Wheel	92423E700
28	Arm Assembly, Idler	920325E	62	Bracket Assembly, Right Lifter	92409E700
29	Plate, Adjuster	91741E701	63	Screw	28x249
30	Cover, Pulley	92417E700	64	Guide, Belt	91873E700
31	Bolt, Shoulder	9x40	65	Wheel, Gauge	92265
32	Bracket Assembly, Left Lifter	92404E700	66	Washer	17x102
33	Spring, Extension	165x72	67	Housing, Blade	92401E700
34	Bracket, Pivot	92407E700	1-67	Complete Mower Housing Assembly	403347

HOW TO ORDER REPAIR PARTS

Only use a factory repair part. Repair parts, except for the engine or the transmission, are available from the store where the unit was purchased, a service shop recommended by the store, or an authorized service shop found in the yellow pages of the telephone directory.

If you cannot get a repair part or service as described above, call or write to the Central Parts Distributor shown below or write: Customer Service Department, Outdoor Power Equipment, P.O. Box 266, Brentwood, Tennessee 37027. Collect telephone calls will not be accepted. When you order, include the following information: (1) Complete Model Number (see nameplate), (2) Date of Manufacture, (3) Complete Part Number, (4) Description, (5) Quantity.

Repair parts for the engine or the transmission are available from the manufacturer's authorized service center found in the yellow pages of the telephone directory. See the individual engine or transmission warranties.

MURRAY LAWN MOWER CENTRAL PARTS DISTRIBUTORS

BEBCO, INC.
2221 2nd. Ave. South
Birmingham, AL. 35233
(205) 251-4600
1-800-828-8094
Alabama, Florida, Georgia

BILLIQU'S, INC.
1343 South Main St.
Porterville, CA. 93257
(209) 784-4102
1-800-245-5468
Arizona, California, Hawaii, Nevada

BROWN & WISER, INC.
9991 S.W. Avery Street
P.O. Box 1109
Tualatin, OR. 97062
(503) 692-0330
1-800-882-4782
Alaska, Idaho (counties Ada, Adams, Benewah, Boise, Bonner, Bounding, Canyon, Clearwater, Elmore, Gem, Idaho, Kootenai, Latah, Lewis, Nez Perce, Owyhee, Payette, Ravalli, Shoshone, Valley, Washington), *Montana* (counties Flathead, Lake, Lincoln, Mineral, Missoula, Ravalli, Sanders), *Oregon, Washington*

CHILTON AIR COOLED ENGINE
319 4th. Ave. South
P.O. Box 150806
Nashville, TN. 37215
(615) 254-1634
1-800-621-6934
Arkansas (counties Clay, Craighead, Crittenden, Cross, Greene, Jackson, Lawrence, Lee, Mississippi, Monroe, Phillips, Poinsett, Randolph, St. Francis, Woodruff), *Mississippi* (counties Desoto, Panola, Quitman, Tate, Tunica), *Missouri* (counties Dunkin, New Madrid, Pemiscot), *Tennessee, Virginia* (counties Bland, Buchanan, Dickenson, Lee, Russell, Scott, Smyth, Tazewell, Washington, Wise)

ENGINES SOUTHWEST
215 Spring St.
P.O. Box 67
Shreveport, LA. 71161-0067
(318) 222-3671
1-800-388-6995
Arkansas (except these counties: Clay, Craighead, Crittenden, Cross, Greene, Hempstead, Howard, Jackson, Lafayette, Lawrence, Lee, Little River, Miller, Mississippi, Monroe, Nevada, Phillips, Pike, Poinsett, Randolph, Sevier, St. Francis, Woodruff) *Louisiana, Mississippi* (except these counties: Desoto, Panola, Quitman, Tate, Tunica.)

FRANK EDWARDS CO.
110 South 300 West
P.O. Box 2158
Salt Lake City, UT 84101
(801) 972-0128
1-800-368-4553
Colorado, Idaho (counties Benneville, Bearlake, Bingham, Blaine, Booneville, Butte, Camas, Carbon, Cassia, Custer, Franklin, Fremont, Gooding, Jefferson, Jerome, Lemhi, Lincoln, Madison, Minidoka, Oneida, Power, Teton, Twin Falls) *Montana* (all counties except Brown and Wiser), *Utah, Wyoming*

GARDNER, INC.
1160 Chesapeake Ave.
Columbus, OH. 43212
(614) 488-7951
1-800-948-8946
Indiana, Kentucky, Michigan (except upper Peninsula), *Ohio, Western Pennsylvania* with zip codes up to and including 16999, *West Virginia*

GULF COAST ENGINE, INC.
4202 Russell Dr.
P.O. Box 8724
Corpus Christi, TX. 78408
(512) 888-6999
1-800-825-6999
Arkansas (counties Hempstead, Howard, Lafayette, Little River, Miller, Nevada, Pike, Sevier) *New Mexico, Oklahoma, Texas*

OSCAR WILSON ENGINE & PARTS
4158 Shoreline Dr.
Earth City, MO. 63045
(314) 739-1319
1-800-873-6722
Illinois (S. of Hwy. 80), *Iowa, Kansas, Missouri* (all counties except Dunkin, New Madrid, Pemiscot) *Nebraska*

POWER SWEEPER SERVICES
P.R. #2
Totterham, Ont. L0G-1W0
(416) 936-3439 or 2011
1-800-263-3266
Canada

R.B.I. CORPORATION
P.O. Box 9318
Richmond, VA. 23227
(804) 550-2210
1-800-888-7149
Connecticut, Delaware, District of Columbia, Maine, Maryland, Massachusetts, New Hampshire, New Jersey, New York, N. & S. Carolina, Pennsylvania (zip 17000 & up), *Rhode Island, Vermont, Virginia* (all counties except Bland, Buchanan, Dickenson, Lee, Russell, Scott, Smyth, Tazewell, Washington, Wise)

WISCONSIN MAGNETO
4727 N. Teutonia Ave.
P.O. Box 9219
Milwaukee, WI. 53209
(414) 445-2800
1-800-733-7388
Illinois (N. of Hwy. 80), *Michigan* (upper Peninsula), *Minnesota, Wisconsin, North & South Dakota*