


# TRACTOR REPAIR PARTS

40" TRACTOR MODEL NUMBER A4014-040



**NOTE: ALWAYS USE ORIGINAL EQUIPMENT PARTS** Use of service replacement parts other than original parts may void your warranty.

ALL UNNUMBERED ITEMS ARE INTERCHANGEABLE WITH OPPOSITE SIDE

Part No. 311204


## TRACTOR REPAIR PARTS

### 40" TRACTOR MODEL NUMBER A4014-040

Key No.	Part No.	Description	Key No.	Part No.	Description
1	310384	Seat	48	58325	Knob, Height Adjust
2	122188	Screw, Hex, 3/8-16 x 2-1/4 In.	49	304730	Handle, Lift
3	305991	Channel, Seat L. H.	50	301239	Pawl, Height Adjust
4	304480	Channel, Seat R. H.	51	302380	Tie Rod
5	56030	Screw, Hx Hd, Wd Fl 5/16-18 x 3/4 In.	52	121222	Cotter Pin
6	122007	Screw, Hx Hd, 5/16-18 x 3/4 In.	53	308339	Bracket, L. H. Front Hanger
7	120638	Washer, Lock 5/16 In.	54	308345	Assembly, Front Lift Shaft
8	120393	Washer, Flat, 11/32 In.	55	308340	Bracket, R. H. Front Hanger
9	304481	Rod, Seat Support	56	308343	Bracket, Hanger
10	36368	Hair Pin, .073 Dia. x 1.10 In.	57	308342	Assembly, Rear Lift Shaft
11	305520	Seat Spring	58	36625	E-Ring
12	1084	Washer, Flat, 9/32 In.	59	120228	Screw, Hx Hd, 5/16-18 x 5/8 In.
13	180018	Screw, Hx Hd, 1/4-20 x 5/8 In.	60	305381	Support, Shift Plate
14	274517	Flatwasher, 13/32 In.	61	180016	Screw, 1/4-20 x 1/2 In.
15	305379	Fender Support, L. H.	62	306294	Quadrant
16	1502	Nut, Lock, 1/4-20 Thd.	63	51335	Nut, Hx, Wd Fl Lk, 1/4-20 Thd.
17	55273	Nut, Hx, Wd Fl, Lk 5/16-18 Thd.	64	304728	Handle
18	304475	Seat Support	65	120377	Nut, Hx 3/8-16 Thd.
19	304476	Support, Fender & Seat	66	300302	Screw, Hx Hd, Tap #10 x 1/2 In
20	302208	Bracket, Support Engage	67	305380	Fender Support, R. H.
21	35497	Screw, Hx Wshr Hd Tap, 5/16-18 x 1/2 In.	68	310576	Fender
22	306391	Assembly, Engagement Rod	69	995338	Screw, Hx, Wshr Hd, Tap 1/4-20 x 5/8 In.
23	1500	Nut, Hx Ctrk, 1/2-13 Thd.	70	307817	Decal, Shift Indicator
24	304729	Handle, Lift	71	311731	Decal, Lawn Tractor Seat Supp.
25	302197	Clip	72	309574	Decal, 5-Height Of Cut
26	305306	Spring, Tension	73	311729	Decal, Gunsight Clear Back
27	304448	Assembly, Spring Cartridge	74	271190	Nut, Hex Keys, 3/8-16 Thd.
28	305989	Shoulder Bolt, 7/16 In.	75	311724	Decal, Rear Fender Husqvarna
29	1498	Nut, Hx Ctrk, 5/16-18 Thd.	76	50634	Screw, Tap, 5/16-18 x 7/8 In.
30	20507	Shoulder Bolt, 5/16-18 Thd.	77	307818	Decal, PTO Export
31	303227	Cable, Deck Lift	78	305770	Decal, Caution Triangle Europe
32	48306	Pulley	79	310553	Decal, Danger English
33	303230	Assembly, Pulley Bracket			Decal, Danger German
34	305522	Shoulder Bolt, 5/16-18 Thd.			Decal, Danger Dutch
35	126211	Bolt, Carriage, 5/16-18 x 5/8 In.	80	300638	Decal, Export LWA100DBA
36	302205	Assembly, Upper Shaft	81	311775	Operator's Manual (Not Illustrated)
37	302383	Quadrant			Parts Manual (Not Illustrated)
38	9143	Lift Lever	82	311204	
39	300171	Shoulder Bolt, 5/16-18 Thd.			
40	44108	Nut, Hx Wd Fl Lk 5/16-18 Thd.			
41	300310	Clevis Pin			
42	300311	E-Ring			
43	302397	Link			
44	36149	Shoulder Bolt, 5/16-18 Thd.			
45	45602	Washer			
46	58330	Actuator Rod			
47	58326	Spring, Height Adjust			

### TRACTOR REPAIR PARTS

40" TRACTOR MODEL NUMBER A4014-040




## TRACTOR REPAIR PARTS

### 40" TRACTOR MODEL NUMBER A4014-040

Key No.	Part No.	Description	Key No.	Part No.	Description
1	310577	Hood	48	120392	Washer, Flat, 9/32 In.
2	25086	Shoulder Bolt, 5/16-18 Thd.	49	1502	Nut, Hx, Ctrk, 1/4-20 Thd.
3	1498	Nut, Hx, Ctrk, 5/16-18 Thd.	50	302307	Shaft, Steering
4	306858	Lens, Headlight	51	302524	Pin, Dowel
5	305721	Assembly, Foot Pad L. H.	52	302314	Pinion, Steering
6	307437	Heat Shield	53	302498	Bearing, Flange
7	300303	Screw, Hx Hd, Plastite 1/4 Dia. x 3/4 In.	54	50634	Screw, 5/16-18 Thd.
8	305820	Tank, Gas 1.5 Gal W/Sensor	55	2968	Washer, Flat, 1/2 In.
9	12501	Cap, Fuel	56	20864	E-Ring
10	309461	Bracket, Hood L. H.	57	57158	Ball, Joint, 3/8 Thd.
11	56030	Screw, Hx Hd, 5/16 -18 x 3/4 In.	58	300634	Belt Guide
12	309460	Bracket, Hood R. H.	59	307112	Plug, Front Axle
13	312643	Front Axle W/Bearings	60	308115	Foam, Hood Baffle
14	120228	Screw, Hx Hd, 5/16-18 x 5/8 In.	61	307800	Decal, Dash Right Eng/Fr
15	706	Grease Fitting	62	306856	Grille
16	302303	Bearing, Spindle	63	300440	Belt Guide
17	36625	E-Ring	64	312085	Screw, #4-24 x 1/2 In.
18	1499	Nut, Hx, Ctrk, 3/8-16 Thd.	65	306857	Clip, Tinnerman
19	305340	Spindle, R. H.	66	310534	Decal, Reflector
20	120382	Washer, Split, Lock 3/8 In.	67	300302	Screw, #10 x 1/2 In.
21	120369	Nut, Hx, 3/8-24 Thd.	68	311726	Decal, Console Frame, Husqvarna, R. H.
22	302306	Steering Arm, Upper	69	309515	Decal, Dash Chg, Oil, Fuel
23	996416	Washer, Flat, 25/64 In.	70	53652	Screw, Hex Fl, 5/16-18 x 3/4 In.
24	300328	Assembly, Tie Rod	71	138538	Washer, Internal Tooth
25	305339	Spindle, L. H.	72	311793	Decal, Instructions, Console Top, English
26	180134	Screw, Hx Hd, 3/8-16 x 2-1/2 In.	73	311010	Decal, Dash, L. H.
27	306103	Support Bracket, Front Axle	74	307820	Decal, Park Brake Export
28	122207	Screw, Hx Hd, 3/8-16 x 3 In.	75	311725	Decal, Console Frame, Husqvarna, L. H.
29	2483	Washer, Spring	76	311727	Decal, Spoiler Front, Husqvarna
30	55270	Nut, Hx, Wd Fl Lk 5/16-18 Thd.	77	312254	Decal, Hood Stripe, Husqvarna, R. H.
31	642	Washer, Flat, 3/4 In.	78	311722	Decal, Hood Stripe, Husqvarna, R. H.
32	305360	Wheel & Tire Assembly, Front Includes the following parts:	79	311724	Decal, Fender Rear, Hood, Husqvarna
	301140	Tire, Rear	80	311730	Decal, Wheel 4 Steer, Husqvarna
	312739	Wheel/With Bearing	81	312255	Decal, Hood Stripe, Husqvarna, L. H.
	24167	Valve Stem	82	311723	Decal, Hood Stripe, Husqvarna, L. H.
	39979	Bearing	83	311728	Decal, Gunsight Clear Back
33	302907	Drag Link	84	311976	Decal, Instructions, Console Top, French
34	124925	Nut, Hx, Jam, 3/8-24 Thd.	85	311977	Decal, Instructions, Console Top, German
35	306569	Hubcap, Front	86	311971	Decal, Instructions, Console Top, Dutch
36	306669	Clip, Hubcap			
37	305722	Assembly, Foot Pad R. H.			
38	304702	Dash, Lower			
39	45263	Screw, Tap, 5/16-18 x 3/8 In.			
40	995346	Screw, Self-Tap, 1/4-20 x 1/2 In.			
41	305280	Cover			
42	303228	Bushing, Upper Steering			
43	307453	Dash, Upper			
44	303132	Steering Wheel			
45	456378	Pin, , Spring, 1/4 x 2 In.			
46	305850	Screw, Tap, 1/4-20 x 1/2 In.			
47	120854	Screw, Hx Hd, 1/4-20 x 5/8 In.			

### TRACTOR REPAIR PARTS

40" TRACTOR MODEL NUMBER A4014-040



## TRACTOR REPAIR PARTS


### 40" TRACTOR MODEL NUMBER A4014-040

Key No.	Part No.	Description	Key No.	Part No.	Description
1	304406	Tube Assembly, Shift Pivot	39	304367	Knob, Park Brake
2	304024	Tube Assembly, Shift	40	25086	Shoulder Bolt, 5/16-18 Thd.
3	302538	Clip, Shift Lever	41	120385	Washer, 9/16 In.
4	35497	Screw, Hx Hd, Wshr Tap, 5/16-18 x 1/2 In.	42	121223	Cotter Pin
5	304086	Shoulder Bolt	43	304209	Spring, Clutch
6	1502	Nut, Hx, Ctrik, 1/4-20 Thd.	44	304125	Bracket, Brake Rod
7	71046	Nut, Hx, Nylon, Lock 3/8-16 Thd.	45	271184	Nut, Hx, Keps, 5/16-18 Thd.
8	1499	Nut, Hx, Ctrik, 3/8-16 Thd.	46	304212	Rod, Clutch
9	122145	Screw, 3/8-16 x 1-1/4 In.	47	304049	Arm, Idler
10	310442	Main Frame	48	51189	Shoulder Bolt, 3/8-16 Thd.
11		Engine 14 Horsepower B&S	49	274517	Washer, Flat, 13/32 In.
12	305555	Exhaust Tube, L. H.	50	36368	Hairpin
13	46708	Gasket, Muffler	51	304083	Rod, Shift-On-The-Go
14	305554	Exhaust Tube, R. H.	52	57325	Carriage Bolt, 3/8-16 x 2 In.
15	180077	Screw, Hx Hd, 5/16-18 X 3/4 In.	53	40223	Idler Sheave, Backside
16	305553	Muffler	54	304105	Belt Retainer
17	306577	Bracket Muffler	55	304130	Spring, Brake
18	995346	Screw, Hx Hd, Tap 1/4-20 X 1/2 In.	56	45171	Nut, Flange, 3/8-16 Thd.
19	308144	Heat Shield, Muffler	57	22053	Retaining Ring
20	9796	Bracket, Transaxle	58	3021	Key, Woodruff, #606
21	126211	Bolt, Carriage, 5/16-18 X 5/8 In.	59	303109	Pulley
22	55273	Nut, Hx, Wd Fl, Lk 5/16-18 Thd.	60	309546	Shift Link
23	306590	Pulley Assembly, Engine	61	120394	Washer, Flat, 13/32 In.
24	56431	Washer, Pilot	62	302582	Shift Lever, Transaxle
25	120383	Washer, Split, Lock 7/8 In.	63	56255	Screw, Hx Hd, 1/4-28 X 3/4 In.
26	428644	Screw, Hx Hd, 7/16-20 X 5 In.	64	274517	Washer, Flat, 13/32 In.
27	303241	V-Belt, 90 In. Long	65	30289	Washer, Wave
28	310162	Belt Guide	66	73812	Washer
29	57157	Washer, Special	67	995338	Screw, Hex Hd Tap, 1/4-20 x 5/8 In.
30	1498	Nut, Hex, Ctrik, 5/16-18 Thd.	68	57791	Key, Square 1/4
31	120630	Washer, Split, Lock 5/16 In.	69	304246	Spacer, Engine Pulley
32	50947	Screw, Hx Hd Tap, 3/8-16 X 1-1/4 In.	70	121222	Pin, Cotter
33	138489	Washer, 3/8 In.	71	308188	Washer
34	304490	Pad, Clutch/Brake, Molded	72	56472	Deflector
35	308642	Assembly, Clutch/Brake Arm	73	35287	Screw, Hx Wa Hd, #8-32 x 3/8 In.
36	302337	Bracket, Clutch/Brake Arm	74	307174	Nipple, 3/8-18 x 4 In.
37	304208	Lever, Park Brake	75	47828	Cap, Pipe
38	304217	Rod, Parking Brake	76	309436	Push Nut, 5/16 Belt Retainer



# TRACTOR REPAIR PARTS

40" TRACTOR MODEL NUMBER A4014-040



**TRACTOR REPAIR PARTS**


**40" TRACTOR MODEL NUMBER A4014-040**

Key No.	Part No.	Description	Key No.	Part No.	Description
1	123418	Screw, Hx Hd, 1/2-20 x 1/2 In.	33	44108	Nut, Hx, Wd F, Lk 5/16-18 Thd.
2	306570	Hubcap, 8 In.	34	304115	Spacer
3	306669	Clip, Hubcap	35	25177	Washer, Flat, 49/64 In.
4	304259	Wheel & Tire Assembly, Rear	36	308719	Steering Pivot
	58276	Tire	37	3021	Key, Woodruff #606
	12467	Wheel	38	308720	Shaft, Steering Pivot
	24167	Valve Stem	39	421051	Screw, 5/16-24 x 1 In.
5	12280	Hub Assembly	40	12319	Bolt, Shoulder, 3/8-24 Thd.
6	12290	U-Joint Assembly	41	302593	Rod Assembly, Rear Wheel Steer
7	36311	Pin, Grooved, 1/4 x 1-1/2 In.	42	446363	Washer, Flat, 3/8 In.
8	12465	Bracket, Steering Pivot, Outer	43	304127	Bracket, Transaxle Stabilizer
9	12325	Bearing	44	35498	Screw, Hx Hd, Self-Tap, 5/16-18 x 3/4 In.
10	456722	Pin, Spring, 1/4 x 1-1/2 In.	45	120228	Screw, Hx Hd, 5/16-18 x 5/8 In.
11	21682	Washer, Flat	46	451814	Screw, Hx Hd, Self-Tap, 5/16-18 x 5/8 In.
12	12288	Bushing, Shouldered	47	302877	Assembly, Sector Gear
13	12321	Bushing, Shouldered	48	302878	Bushing, Sector Gear
14	12289	Pin, Steering Hinge	49	304296	Screw, Hx Hd, 1/2-20 x 2-3/8 In.
15	12485	Bracket, Steering Pivot, Inner	50	274654	Nut, Hx, Ctrik, 1/2-20 Thd.
16	122017	Screw, Hx Hd, 5/16-18 x 1 In.	51	308341	Plate, 4-Wheel Steer Pivot
17	120393	Washer, Flat, 11/32 In.	52	308399	Nut, Jam, 3/8-24 Thd.
18	1498	Nut, Hx, Ctrik 5/16-18 Thd.	53	304116	Cam Yoke Roller
19	306001	Bracket, Transaxle Mounting	54	302594	Arm, Roller Swing
20	180089	Screw, Hx Hd, 5/16-18 x 2-1/4 In.	55	304122	Shoulder Bolt, Cam Roller
21	304123	Spacer	56	302588	Shoulder Bolt, Cam Follower Arm Pivot
22	306218	Arm, Rear Wheel Steer, L. H.	57	35410	Spring, Clutch/Brake Pedal Return
23	39728	Screw, Self-Tap, 3/8-16 x 3/4 In.	58	120382	Washer, Split Lock
24	308446	Tie Rod, L. H.	59	45602	Washer, Flat
25	308384	Tie Rod End, L. H.	60	3021	Woodruff Key, #606
26	412349	Nut, Hex, Ctrik, 3/8-24 Thd.			
27	124925	Nut, Hex, Jam, 3/8-24 Thd.			
28	304260	Rod End			
29	308447	Tie Rod End, R. H.			
30	306217	Arm, Rear Wheel Steer, R. H.			
31	181646	Screw, Hx Hd, 3/8-24 x 1-3/4 In.			
32		Transaxle, 6-Speed			



# TRACTOR REPAIR PARTS

40" TRACTOR MODEL NUMBER A4014-040



**NOTE: ALWAYS USE ORIGINAL EQUIPMENT PARTS** Use of service/replacement parts other than original parts may void your warranty.

ALL UNNUMBERED ITEMS ARE INTERCHANGEABLE WITH OPPOSITE SIDE


## TRACTOR REPAIR PARTS

### 40" TRACTOR MODEL NUMBER A4014-040

Key No.	Part No.	Description	Key No.	Part No.	Description
1	300917	Pin, Clevis	44	304731	Wheel Bracket, R. H.
2	56180	Hairpin, Cotter	45	303072	Clutch Rod
3	305283	Clevis	46	305284	Clevis, Clutch
4	309615	Lift Rod	47	49332	Pin, Clevis
5	120238	Nut, Hx Jam 1/2-13 Thd.	48	302714	Rod, Brake
6	109527	Nut, Sq. 1/2-13 Thd.	49	304414	Idler Assembly
7	302197	Clip			Includes the following parts:
8	1498	Nut, Hx, Lock 5/16-18 Thd.		305298	Idler Arm
9	180075	Screw, Hx Hd, 5/16-18 x 1 in.		306973	Brake Pad
10	308339	Bracket, Front		41601	Rivet
11	58247	Nut, Adjusting	50	1346	Belt Retainer
12	122017	Screw, Hx Hd, 5/16-18 x 1 in.	51	310326	Idler Pulley
13	310800	Channel, Draw Bar	52	57325	Carriage Bolt, 3/8-16 x 2 in.
14	302963	Rod, Drawbar	53	304420	Shoulder Bolt, 3/8-16 x 3/4 in.
15	307435	Mower Deck	54	302363	Idler Brace
16	122007	Screw, Hx, 5/16-18 x 3/4 in.	55	446363	Washer, Flat 3/8 in.
17	304426	Wheel Bracket, L. H.	56	45171	Nut, Hx, Wd Fl, 3/8-16 Thd.
18	302611	Wheel	57	304118	Brake Spring Assembly
19	23763	Shoulder Bolt, 3/8-16 Thd.	58	1502	Nut, Hx, Ctrk, 1/4-20 Thd.
20	1499	Nut, Hex, Ctrk, 3/8-16 Thd.	59	122027	Screw, Hx, 5/16-18 x 1-1/4 in.
21	302833	Belt Cover, Left Pulley	60	48044	Belt, 82 in. Long
22	120393	Flatwasher, 11/32 in.	61	35410	Spring
23	120228	Screw, Hx Hd, 5/16-18 x 5/8 in.	62	44108	Nut, 5/16 - 18 Thd.
24	56424	Quill Assembly (Incl. Nos. 25-33)	63	300345	Screw, Tap, 5/16-18 x 1-3/8 in.
25	56425	Saddle & Shaft Assembly	64	120376	Nut, Hx, 5/16-18 Thd.
26	50616	Dust Shield	65	304443	Clevis
27	49562	Bearing	66	120382	Washer, Split, Lock 3/8 in.
28	55547	Quill Housing	67	120377	Nut, Hx, 3/8-16 Thd.
29	50818	Spacer Tube	68	304625	Baffle, Deck
30	51449	Spacer	69	304871	Baffle, Deck Front
31	56390	Pulley	70	312302	Lift Rod
32	56365	Washer			
33	1292	Nut, Wd Fl, Lk 7/16-20 Thd.			
34	50634	Screw, Wshr Hd, 5/16-18 x 7/8"			
35	305012	Blade			
36	2483	Washer, Spring			
37	39573	Screw, Hx Hd, 3/8-24 x 1 in.			
38	304102	Toe Guard			
39	180077	Screw, Hx Hd, 5/16-18 x 3/4 in.			
40	304422	Chute Deflector			
41	305124	Spring			
42	302364	Bracket, Chute Mount			
43	304424	Rod, Chute			

# TRACTOR REPAIR PARTS

40" TRACTOR MODEL NUMBER A4014-040



**NOTE: ALWAYS USE ORIGINAL EQUIPMENT PARTS** Use of service/ replacement parts other than original parts may void your warranty.

ALL UNNUMBERED ITEMS ARE INTERCHANGEABLE WITH OPPOSITE SIDE


## TRACTOR REPAIR PARTS

### 40" TRACTOR MODEL NUMBER A4014-040

Key No.	Part No.	Description	Key No.	Part No.	Description
1	308187	Seat Switch	24	303064	Assembly, Light Wire
2	12553	Deck Safety Switch	25	57211	Switch
3	55511	Cable, Battery, Negative	26	57220	Screw, Ph Hd, Tap #12 x 1/4
4	271184	Nut, Hx, Keps, 5/16-18 Thd.	27	53716	Solenoid
5	307056	Sensor, Low Voltage (if so equipped)	28	120368	Nut, Hx, 5/16-24 Thd.
6	57444	Tie Cable	29	138485	Washer, Lock 5/16 In.
7	300626	Key, Ignition Switch	30	271172	Nut, Hx, Keps, 1/4-20 Thd.
8	300193	Nut, Switch	31	1502	Nut, Hx, Ctrk, 1/4-20 Thd.
9	300194	Boot, Switch	32	187745	Screw, 1/4-20 X 3/4 In.
10	305720	Switch, Ignition	33	302257	Battery
11	300334	Switch, Light	34	302912	Bracket, Battery Hold-Down
12	57551	Rod, Battery Hold-Down	35	310067	Wingnut
13	48049	Gas Line, 10" (cut to length)	36	305756	Wiring Harness
14	41008	Clamp, Gas Line (Note: 41008 shown, order replacement part 47345 - Screw Clamp)	37	308201	Boot, Rubber (Battery Cable)
15	307113	Choke Control	38	302031	Fuse, 15A-32V
16	305701	Lamp Holder, 3-Pin (if so equipped)	39	41482	Press Clip
17	57769	Bulb Indicator	40	304739	Miniature Hour Meter (if so equipped)
18	305702	Lamp Holder, 4-Pin (if so equipped)	41	300302	Screw, Hex Tap, #10 x 1/2 In.
19	304439	Knob, Throttle Control	42	305778	Lamp Holder, Low Fuel (if so equipped)
20	307362	Throttle Control	43	159585	Screw, Ph Pn, #8-32 x 3/8 In.
21	159943	Screw, #10-24 X 5/8 In.	44	120622	Nut, Hex, #8-32 Thd.
22	308459	Nut, Hx, Nylon Lock, #10-24 Thd.	45	47435	Hose Clamp
23	52572	Bulb Headlamp	46	305511	Pigtail Connector
			47	160505	Screw, 1/4-20 x 3/8 In.
			48	57547	Seat Switch
			49	305431	Pigtail Wire Assembly


## ACCESSORIES

Contact the dealer where your tractor was purchased for the available accessories. If you are unable to contact the dealer, write to the address on the front cover of this manual. DETAILED MOUNTING AND OPERATING INSTRUCTIONS ARE INCLUDED WITH EACH ACCESSORY.




### 42" SNOW & GRADER BLADE

Rugged, heavy gauge steel blade. Spring loaded blade glides over uneven surfaces. Can be adjusted from seat for straight position, or 35 degrees left or right. Locks in raised position for traveling. Wheel and tire chains are recommended.




### TIRE CHAINS

Tire chains for added traction are available. Specify tire size when ordering.



### TWO STAGE SNOW THROWER

A powerful two stage snow thrower with a 1/4 inch second stage impeller capable of moving more than 70 tons of snow per hour and throwing it accurately in any direction you choose. Driver controlled discharge chute turns a 160 degree arc. Wheel weights and tire chains are recommended.




### REAR MOUNT GRASS CATCHER

For 40-inch side discharge mower decks. Easy-On Easy-Off chute extension. Includes Easy-To-Dump twin grass collection containers with a 6-bushel capacity.

### WHEEL WEIGHT KIT

Wheel weights for added traction are available. Specify tire size when ordering.



### LAWN SWEEPER

Features extra heavy duty wheels and heavy duty basket. Basket is water, shrink and mildew proof with 8 bushel capacity. Dump release and height adjuster can both be operated from the tractor seat.