


# PARTS MANUAL

## Lawn Tractors



**Model E3554-190**

## **SAFETY RULES**

**THESE INSTRUCTIONS ARE FOR YOUR PROTECTION. PLEASE READ THEM CAREFULLY.**

### **IMPORTANT**

**THIS CUTTING MACHINE IS CAPABLE OF AMPUTATING HANDS AND FEET AND THROWING OBJECTS. FAILURE TO OBSERVE THE FOLLOWING SAFETY INSTRUCTIONS COULD RESULT IN SERIOUS INJURY OR DEATH.**

#### **GENERAL OPERATION:**

- Know controls and how to stop quickly.
- Read, understand, and follow all instructions in this manual and on the machine before starting.
- Only allow responsible adults, who are familiar with instructions, to operate the machine.
- Wear safety glasses or eye shields when assembling or operating the machine.
- Do not operate machine when barefooted. Always wear substantial footwear, preferably steel-toed shoes.
- Do not wear loose fitting clothing that could get caught in moving parts.
- Clear the area of objects such as rocks, toys, wire, etc., which could be picked up and thrown by the blade(s).
- Be sure the area is clear of other people before mowing. Stop machine if anyone enters the area.
- Never carry passengers.
- Do not mow in reverse unless absolutely necessary. Always look down and behind before and while backing.
- Be aware of the mower discharge direction and do not point it at anyone. Do not operate the mower without either the entire grass catcher or the guard in place.
- Blow down before turning.
- Never leave a running machine unattended. Always turn off blades, set parking brake, stop engine, and remove keys before dismounting.
- Turn off blade(s) when not mowing.
- Stop engine before removing grass catcher or unclogging chute.
- Mow only in daylight or good artificial light.
- Do not operate the machine while under the influence of alcohol or drugs.
- Watch for traffic when operating near or crossing roadways.
- Use care when mowing around a fixed object to prevent the blade(s) from striking it. Never deliberately run over any foreign object.
- Use extra care when loading or unloading the machine into a trailer or truck.
- Use care when pulling loads or using heavy equipment.
  - a. Use only approved drawbar hitch points.
  - b. Limit loads to those that you can safely control.
  - c. Do not turn sharply. Use care when backing.
  - d. Use counterweight(s), wheel weight or tie chains when supported in attachment by instructions.

#### **SLOPE OPERATION:**

Slopes are a major factor related to loss-of-control and tip-over accidents, which can result in severe injury or death. All slopes require extra caution. If you cannot back up the slope or if you feel uneasy on it, do not mow it.

##### **DO**

- Mow up and down slopes, not across.
- Remove obstacles such as rocks, tree limbs, etc.
- Watch for holes, ruts, or bumps. Uneven terrain could overturn the machine. Fall grass and rock obstacles.
- Use slow speed. Choose a low gear so that you will not have to stop or shift while on the slope.
- Follow the manufacturer's recommendations for wheel weights or counterweights to improve stability.
- Use extra care with grass catchers or other attachments. These can change the stability of the machine.
- Keep all movement on the slopes slow and gradual. Do not make sudden changes in speed or direction.
- Avoid starting or stopping on a slope. If this loss traction, turn off the blade(s) and proceed slowly straight down the slope.

##### **DO NOT**

- Do not turn on slopes unless necessary, and then slowly and gradually downhill, if possible.
- Do not mow near drop-offs, ditches or embankments. The

mower could suddenly turn over if a wheel is over the edge of a cliff or ditch, or if an edge caves in.

- Do not mow on wet grass. Reduced traction could cause sliding.
- Do not try to stabilize the machine by putting your foot on the ground.
- Do not use grass catcher on steep slopes.

#### **III. CHILDREN:**

Traffic accidents can occur if the operator is not alert to the presence of children. Children are often attracted to the machine and the moving activity. Never assume that children will remain where you last saw them.

- Keep children out of the mowing area and under the watchful care of another responsible adult.
- Be alert and turn machine off if children enter the area.
- Before and when backing, look behind and down for small children.
- Never carry children. They may fall off and be seriously injured or interfere with safe machine operation.
- Never allow children to operate the machine.
- Use extra care when approaching blind corners, shrubs, trees, or other objects that may obscure vision.

#### **IV. SERVICE:**

Use extra care in handling gasoline and other fuels. They are flammable and vapors are explosive.

- a. Use only an approved container.
- b. Never remove gas cap or add fuel with the engine running. Allow engine to cool before refueling. Do not smoke.
- c. Never refuel the machine indoors.
- d. Never store the machine or fuel container inside where there is an open flame, such as in a water heater.

Check fuel supply before each use allowing space for expansion as the heat of the engine and/or sun can cause gasoline to expand and overflow the tank.

Use extra care when handling battery acid. Acid contact with skin may cause severe burns. Eye contact may cause blindness.

Use extra care when servicing the battery. Explosive gas is produced in the battery. Do not service the battery while smoking or near an open spark or flame. This may cause the battery to explode causing serious injury.

Never run a machine inside a closed area. Exhaust fumes contain CARBON MONOXIDE, an OBSCURE and DEADLY GAS.

Keep nuts and bolts, especially blade attachment bolts, tight and keep equipment in good condition.

Mower temper with safety devices. Check their operation regularly.

Do not change the engine governor settings or overspeed engine.

Reduce fire hazards. Keep machine free of grass, leaves, or other debris build-up. Clean up oil or fuel spillage. Allow machine to cool before storing.

Stop and inspect the equipment if you strike an object. Repair, if necessary, before restarting.

Never make adjustments or repairs with the engine running.

Grease catcher components are subject to wear, damage, and deterioration, which could expose moving parts or allow objects to be thrown. Frequently check components and replace with manufacturer's recommended parts, when necessary.

Never let blade(s) be sharp and can cut. Wrap the blade(s) or wear gloves, and use extra caution when adjusting them.

Check brake operation frequently. Adjust and service as required.



**LOOK FOR THIS SYMBOL TO POINT OUT IMPORTANT SAFETY PRECAUTIONS. IT MEANS..  
ATTENTION!!! BECOME ALERT!!! YOUR SAFETY IS INVOLVED.**

Record the following information about your unit so that you will be able to provide it in case of loss or theft.

MODEL NUMBER:  -  (Enter complete 6 digit number from model plate on unit)

PURCHASE DATE:  /  /  CODE NO.:  SERIAL NO.:

DEALER'S NAME AND ADDRESS:


CITY:  STATE:

TELEPHONE:

### TOOLS REQUIRED FOR ASSEMBLY

- 2 - 7/16 inch Wrenches (or adjustable wrench)
- 1 - 1/2 inch Wrench (or adjustable wrench)
- 1 - Small Phillips Screwdriver with a 1/4 inch shank
- 1 - Hammer

### HOW TO MEASURE SCREW SIZE ( $5/16 \times 1\frac{1}{2}$ INCH)



### DANGER



This lawn tractor can be dangerous if carelessly used.

Please read your Operator's Manual thoroughly before operating your lawn tractor.

Always wear safety glasses or eye shields while assembling or operating your lawn tractor.

**DO NOT** carry passengers at any time.

Keep your hands, feet, hair and loose clothing away from the discharge area, the underside of the mower deck or any moving parts while the engine is running.

**DO NOT** allow children or young teenagers to operate or be near your lawn tractor while it is operating.

ALWAYS GIVE THE FOLLOWING INFORMATION WHEN ORDERING REPAIR PARTS:  
1. The PART NUMBER; 2. The PART NAME; 3. QUANTITY DESIRED; 4. The MODEL NUMBER (As shown on Model Plate).

SEND PART ORDERS AS PER INSTRUCTIONS ON THE FRONT PAGE.

DO NOT USE KEY NUMBERS WHEN ORDERING REPAIR PARTS. ALWAYS USE PART NUMBERS.


All replacement parts will be supplied in current production colors or in a neutral color.

A handling fee is applicable to small parts orders.

YOUR UNIT IS RIGHT HAND (RH) OR LEFT HAND (LH) AS YOU STAND BEHIND IT.

**13554-190**

**REPAIR PARTS**



**NOTE: ALWAYS USE ORIGINAL EQUIPMENT PARTS.** Use of service/replacement parts other than original equipment parts may void your warranty.

**ALL UNNUMBERED  
ITEMS ARE INTERCHANGEABLE  
WITH OPPOSITE SIDE**

329120E


E3554-190

## CHASSIS &amp; HOOD ASSEMBLY

KEY #	PART #	DESCRIPTION	QTY.
1	332219-879	MAIN FRAME	1
2	310003	FOOT PAD, LH	1
3	310004	FOOT PAD, RH	1
4	309235	FASTENER, RATCHET	12
5	320673-853	BRACKET, GRILLE LH	1
6	320674-853	BRACKET, GRILLE RH	1
7	56922-853	SPKT SUPPORT, FRONT AXLE	1
8	328164	SCREW, 5/16-18X1.0WDFLLK	8
9	55279	NUT, 5/16-18 HXWDFLLK	6
10	327667-853	SHIELD, HEAT SF BBS	1
11	321133-879	BRACKET, KANGER 30"	1
12	60720	BOLT, .625X2.875 SPISH 1/2-20	1
13	274864	NUT, 1/2-20 REGHHDOTRILK	1
14	180188	SCREW, 3/8-16X3.00 HHC	4
15	2465	WASHER, .384DX1.25DX.07 BELL VIL	4
16	1459	NUT, 3/8-16 REGHHDOTRILK	4
17	324998-830	CONSOLE, MOLDED DASH	1
18	58233-030	CONSOLE, REAR COVER	1
19	583346	SCREW, 1/4-20X .50 WAHHTAP	15
20	326766	DASH	1
21	305850	SCREW, 1/4-20X .50PHPTAP	4
22	327663-853	SUPPORT, SF MLD DSH	2
23	327584-853	SUPPORT, SF MLD DSH GAS TANK	2
24	585346	SCREW, 1/4-20X .50 WAHHTAP	8
25	327444	SPNG, FL .755ID,.226 MTNG HOLES	1
26	180020	SCREW, 1/4-20X .76 HHC	4
27	46931	NUT, 1/4-20 WDFL MAC LOCK	4
28	327390	BRNG, FL .580ID,.226 MTG HOLES	1
29	327673-830	STRAP, DASH SUPPORT	1
30	582346	SCREW, 1/4-20X .50 WAHHTAP	2
31	165941	SCREW, 10-24X.63 PHFLTM	2
32	308458	NUT, #10-24 HXHDNYLK	2
33	328024-853	CONSOLE SUPPORT BRKT	2
34	985846	SCREW, 1/4-20X .50 WAHHTAP	2
35	328141	BUMPER, HOOD/DASH TOP & CORNER	2
36	328142	BUMPER, HOOD/DASH SIDE STRIP	2
37	228146	HOOD	1
38	328178	GRILLE	1
39	329144	INSERT, GRILLE	1
40	328236	RIVET, POP 3/16DIA X .76 LG FLG	2
41	306857	CUP, TINNEKMAN VER II HOOD	7
42	326544	PIN, CLEVIS .260 X .48-.61LGT	2
43	326522	BRNG HOOD .605IDX.6260DX1.12FL	2
44	3260	PIN, HAIR .091 DIA X1.06L0	2
45	315899	LANYARD, HOOD 15.00 LG	1
46	49050	SCREW, 1/4-10X .75PHPTAP	1
47	504784	SPRING, HOOD LATCH	1
48	505295	BELT GUARD SF RUBBER 7 X 25.46	2
49	57034	SCREW, 10-24X.63 TRHM	12
50	1801	WASHER, FLAT .200X .56X.040	12
51	308459	NUT, #10-24 HXHDNYLK	12
52	325194	LENS	1
53	301452	FOIL, HEAT REFLECTOR	1
54	333226	RIVET, POP 3/16DIA X1.0LG FLG	2
55	1501	FLATWASHER .200X .58X.040	2
56	333363	ENGLISH OPERATOR MANUAL	1
57	333384	FRENCH OPERATOR MANUAL	1
58	333385	GERMAN OPERATOR MANUAL	1
59	333388	ENGLISH PARTS MANUAL	1
60	329000	ENGLISH GRASS CATCHER MANUAL	1
61	328207	FRENCH GRASS CATCHER MANUAL	1
62	328208	GERMAN GRASS CATCHER MANUAL	1

**E3554-190**

**REPAIR PARTS**



**NOTE: ALWAYS USE ORIGINAL EQUIPMENT PARTS.** Use of service/replacement parts other than original equipment parts may void your warranty.

**ALL UNNUMBERED  
ITEMS ARE INTERCHANGEABLE  
WITH OPPOSITE SIDE**


329120E

KEY #	PART #	DESCRIPTION	QTY.
60	58367-379	SEAT PLATE	1
61	20507	BOLT, .437X.168 HHSH 5/16-18	2
62	1468	NUT, 5/16-18 REGHEXTRILK	2
63	330462	SPRING, SEAT 1.600DX2.25LG	2
64	120372	FLATWASHER, .251X.031.005	2
65	988346	SCREW 1/4-20X .50 WAHTAP	2
66		ASSEMBLY, FENDER	1
66-1	832423-679	FENDER	1
66-2	9239	CLEVIS	1
66-3	489455	SCREW, 5/16-18X .50PUPHMA BISH	1
66-4	201661	WASHER, .344DX1.500X.09 CU ZN	1
66-5	120373	NUT, 5/16-18 SO	1
72	988346	SCREW, 1/4-20X .50 WAHTAP	4
73	100301	SCREW, 5/16-18X1.25 HHC	2
74	446363	WASHER, FLAT .375X .090C08	2
75	55273	NUT, 5/16-18 HXWDFLX	2
76	55023	TRIM STRAP,BLACK-SMALL,W ADH	76IN.
79	53445	PIN, 5/16-18 HOOD LATCH	2
80	271194	NUT, 5/16-18 HEXKEPS	2
82	60653	GUIDE, BELT	1
84	41529	NUT, 3/8-16 HXCTRLKJAM	1
86	271190	NUT, 3/8-16 HEXKEPS	1

\* ORDER INDIVIDUAL PARTS.

E3554-190

REPAIR PARTS



NOTE: ALWAYS USE ORIGINAL EQUIPMENT PARTS. Use of service/replacement parts other than original equipment parts may void your warranty.

ALL UNNUMBERED  
ITEMS ARE INTERCHANGEABLE  
WITH OPPOSITE SIDE


3282830

E3554-190

## STEERING ASSEMBLY

KEY #	PART #	DESCRIPTION	QTY.
1		AXLE FRONT ASSY, SF LONG	1
1-1	312280-879	FRONT AXLE	1
1-2	50546	BEARING, FL .750IDX1.002ODX .75	1
1-4	36625	RING, RETEX .57X.08TRUS133-75	1
1-6	310957	SPINDLE ASSY, LH LONG	1
1-8	327819	ARM ASSY, FRONT STEERING	1
1-7	454565	PIN, SPRING .250DIA X1.25LG HVPL	1
2	302688	TIE ROD, STAMPED 10.31LG W-SEC	1
3	100124	SCREW, 3/8-16X1.25 HHC	2
4	120362	WASHER, REGSP TLK .380X.68X.10	2
5	1438	NUT, 3/8-16 REGHEX CTRLK	2
6	324762	GEAR, SECTOR SP4WS HT	1
7	663208	PLATE SECTOR	2
8	336021	BUSHING, SECTOR GEAR	1
9	181643	SCREW, 3/8-24X1.50 HHC	1
10	845	WASHER, FLAT .380X1.25X.110	2
11	412349	NUT, 3/8-24 HHD CTRLK	1
12	326808	DRAG LINK ASSY 17.59LG	1
12-1	57158	BALL JOINT 3/8 THD SHORT STUD	2
12-2	124925	NUT, 3/8-24 REGHEX JAM	2
12-3	56190	DRAG LINK	1
13	120382	WASHER, REGSP TLK .383X.68X.10	2
14	120069	NUT, 3/8-24 REGHEX	2
15	327395	SHAFT, PIN-SYM	1
16	326692	BARING, FL .50 IDX1.370ODX	1
17	326505	SCR 1/4-20X.75 (TO 30-35 FT#)	2
18	46981	NUT, 1/4-20 WDPL MAC-LOCK	2
19	20864	RING, RETEX .56X.04TRUS133-50	1
20	41029	TIRE & RIM, PU 13X5.0X5 TUR	2
20-1	24167	SEE TIRE TREAD PAGE	1
20-2	35867	VALVE STEM	2
20-3	314416	HUB	2
21	642	BEARING	4
22	36625	WASHER, FLAT .755X1.91X.075	4
23	40394	RING, RETEX .57X.08TRUS133-75	4
24	120124	HUB CAP, 1.500ID X .795LG	2
25	120364	SCREW, 3/8-16X1.25 HHC	1
26	45171	WASHER, FLAT .400X .51X.065	2
		NUT, 3/8-16 HWDFL WHIZ-LOCK ZN	1

\* ORDER INDIVIDUAL PARTS.



**NOTE: ALWAYS USE ORIGINAL EQUIPMENT PARTS.** Use of service/replacement parts other than original equipment parts may void your warranty.


ALL UNNUMBERED  
ITEMS ARE INTERCHANGEABLE  
WITH OPPOSITE SIDE

331231B

E3554-190

## MOWER SUSPENSION ASSEMBLY

KEY #	PART #	DESCRIPTION	QTY
1	321371	BRKT, REAR SUPT RH	1
2	180091	SCREW, 5/16-18X2.50 HHC	2
3	120393	WASHER, FLAT .344X .09X.065	1
4	1498	NUT, 5/16-18 REGHEXCTRKLK	2
5	314702	SPACER, SLEV .344X1.00X .500PM	2
6	321370	BRKT, REAR SUPT LH	1
7	180119	SCREW, 5/16-18X2.00 HHC	2
8	120393	WASHER, FLAT .344X .09X.065	1
9	1498	NUT, 5/16-18 REGHEXCTRKLK	2
10	314702	SPACER, SLEV .344X1.00X .500PM	2
11	66180	PIN, HAIR .091 DIAX1.62LG	1
12	328399	BRKT, LINK LOWER BLKPHOS	1
13	313560	BOLT, .500X .225 HHSH 5/16-18	1
14	1498	NUT, 5/16-18 REGHEXCTRKLK	1
15	320905	BRACKET LIFT BAR 30"	1
16	180077	SCREW, 5/16-18X .75 HHC	2
17	1498	NUT, 5/16-18 REGHEXCTRKLK	2
18	303475	SPRING, TENSION 7.52L.G+17.8MM	1
19	412924	WASHER, FLAT .344X1.18X.082	1
20	1498	NUT, 5/16-18 REGHEXCTRKLK	1
21	9406	CLEVIS, LIFT CABLE	1
22	120372	NUT, 1/4-20 REGSO	1
23	322261	CABLE, CLUTCH 31.31 LG (30°25°)	1
24	328139	LEVER, CLUTCH SF 30° SUB ZINC	1
25	1288	BRKT, CABLE RETAIN	1
26	49306	PULLEY, POWDER METAL	1
27	582395	BOLT, .375X .375 HHSH 1/4-20	1
28	1502	NUT, 1/4-20 REGHEXCTRKLK	1
29	9266	PIN, HAIR .091 DIAX1.66LG	1
30	996426	WASHER, FLAT .515X .08X.064	1
31	22265	WASHER, FLAT .515X1.36X.118PL	1
32	305225	STOP, PTO ENGAGE	1
33	326386	PIN, SPRING 1.67DIAx1.13LG HD	1
34	391624	KNOB, ROUND 1.50DIA OK GRIP	1
35	321295-653	CLEVIS, P.T.O. PULLEY	1
36	48306	PULLEY, POWDER METAL	1
37	300317	PIN, CLEVIS .375DIAx .81 LG	1
38	996416	WASHER, FLAT .351X1.00X.125	1
39	8280	PIN, HAIR .061 DIAX1.86LG	1
40	313926	BRACKET, HEIGHT ADJUST	1
41	180077	SCREW, 5/16-18X .75 HHC	4
42	1498	NUT, 5/16-18 REGHEXCTRKLK	2
43	301238	QUADRANT, HEIGHT ADJUST	1
44	180077	SCREW, 5/16-18X .75 HHC	2
45	1498	NUT, 5/16-18 REGHEXCTRKLK	2
46	322292-852	HANDLE, LIFT SHORT(30° S.F.)	1
47	900171	BOLT, .500X .270 HHSH 5/16-18	1
48	996416	WASHER, FLAT .500X .75X.024	1
49	64106	NUT, 5/16-18 HWDFLCTRKLK	1
50	301299	PAWL, SQUARE	1
51	300171	BOLT, .500X .270 HHSH 5/16-18	1
52	44106	NUT, 5/16-18 HWDFLCTRKLK	1
53	6429	POINTER, HEIGHT ADJ.	1
54	138478	WASHER, EXLK, .195X.41X.03	1
55	35287	SCREW, #8-32X .38 HHWATAP	1
56	303027	ROD ACTUATOR-SHORT	1
57	56326	SPRING, HEIGHT ADJUST	1
58	56325	KNOB, HEIGHT ADJ PUSH BUTTON	1
59	58329	GRIP, .750 OD W/HOLE BLACK	1
60	9149	BRKT, CABLE RETAIN	1
61	48306	PULLEY, POWDER METAL	1
62	69336	BOLT, .375X .375 HHSH 1/4-20	1
63	1502	NUT, 1/4-20 REGHEXCTRKLK	1
64	321420	CABLE, LIFT 21.50 ~ 30°	1
65	300310	PIN, CLEVIS .310DIAx.475LG	1
66	900311	RING, RET E .31X.25TPX5129-31	1
67	48306	PULLEY, POWDER METAL	1
68	300317	PIN, CLEVIS .375DIAx .81 LG	1
69	8280	PIN, HAIR .091 DIAX1.66LG	1
70	120375	NUT, 1/4-20 REGHEX	1
71	9406	CLEVIS, LIFT CABLE	1
72	120372	NUT, 1/4-20 REGSO	1
73	39622	PIN, CLEVIS .312 X .812	1
74	121222	PIN, COTTER .220 DIAx .75LG	1
75	300336	LIFT COVER	1
76	300340	SCREW, #10 X .75 HMPLAST	3



**NOTE: ALWAYS USE ORIGINAL EQUIPMENT PARTS.** Use of service/replacement parts other than original equipment parts may void your warranty.

ALL UNNUMBERED  
ITEMS ARE INTERCHANGEABLE  
WITH OPPOSITE SIDE

333369A

KEY #	PART #	DESCRIPTION	QTY
1		TRANSAXLE 940-007 2WS	1
2	203109	PULLEY, 4.6 OD V4L TIA	1
3	50795	KEY, HI-PRO 606 .76DIAx167WD	1
4	22052	RING, RETEN .58X.025TRUS100-42	1
5	54758	BELT, V 4L 62.00 SF DRIVE	1
6	53768-553	BRACKET, TRANSAXLE	2
7	180077	SCREW, 5/16-18 REGHEXOTRIK	6
8	1405	NUT, 5/16-18 REGHEXOTRIK	6
9	180091	SCREW, 5/16-18X2.00 HHC	4
10	120390	WASHER, FLAT .344X .69X.006	4
11	1498	NUT, 5/16-18 REGHEXOTRIK	4
12	322419	BRKT, TIA TORQ. BLKPHOS	1
13	180087	SCREW, 5/16-18X2.00 HHC	1
14	1496	NUT, 5/16-18 REGHEXOTRIK	1
15	180079	SCREW, 5/16-18X1.00 HHC	1
16	195449	WASHER, .2X.18 3200CB1X.09	1
17	1403	NUT, 5/16-18 REGHEXOTRIK	1
18	321649	LEVER, SHIFT LOW SF FNSFT	1
19	502760	CLAMP, 52501A	2
20	180077	SCREW, 5/16-18X .75 HHC	4
21	1498	NUT, 5/16-18 REGHEXOTRIK	4
22	310556	BRKT, PIVOT BH LEV	1
23	180020	SCREW, 1/4-20X .75 HHC	2
24	3802	NUT, 1/4-20 REGHEXOTRIK	2
25	324788	LEVER, SHIFT UPPER SOP 1/2-13	1
26	510250	SPRING, TORQ .55X.251.006	2
27	187185	PIN, COTTER .125 DIAx1.003	1
28	120238	NUT, 1/2-13 HEXJAM	1
29	655114	KNOB, ROUND 15001A OR GRP	1
30	211200	COVER PLASTIC LP F4930/F4930-B	1
31	311257-553	BRACKET COVER F-6 FDNR SHIFT	1
32	1941	CLAMP, SPRG 1.171D	2
33	511131	SCREW, 1/4-18X44.53 HLCNHW	4
34	321644	ROD, CONNECTING, SHIFT	1
35	187185	PIN, COTTER .125 DIAx1.003	1
36	57158	BALL JOINT 3/8 THD SHORT STUD	1
37	124925	NUT, 3/8-24 REGHEXJAM	1
38	120392	WASHER, REGSP13K.030X.00X.10	1
39	120369	NUT, 3/8-24 REGHEX	1
40	029212	BRKT, SHIFT	1
41	57157	WASHER, .760X.250 SF-TRANSAXLE	1
42	36255	SCREW, 1/4-20X .75 HYLHHC	1


NOV 10 '99

9:47 NO. 003 P.1

E3554-190

## MOTION DRIVE ASSEMBLY


KEY #	PART #	DESCRIPTION	QTY
50	49606	BELT GUIDE	1
51	271184	NUT, 5/16-18 HEXKEPS	1
52	120303	WASHER, FLAT .344X .090X.055	1
53	1498	NUT, 5/16-18 REGHEXOTRIK	2
54	931836	ASSY, PEDAL BRAKE, CLUTCH	1
55	910676	PIN, CLEVIS .500X4.871L6	1
56	2998	WASHER, FLAT .504X .750X.050	1
57	301972	SPACER, SLEV .53 X .5241.62L6	4
58	56180	PIN, HAIR PIN DIA.011.62L6	1
59	48781	PAD, CLUTCH/BRAKE PEDAL	1
60	921866	IDLER ARM SHKT TRACTION	1
61	920989	BOLT, .625X .135 HHSH 5/16-18	1
62	46802	WASHER, FLAT .630X .87X.110	1
63	1498	NUT, 5/16-18 REGHEXOTRIK	1
64	327867	SPRING .24 ODX7.75X.091 TENSION	1
65	90659	RETAINER, BELT	1
66	35374	PULLEY, IDLER V4L .308X .82	1
67	40692	BOLT, 5/8-16X1.50 CARRSN	1
68	1499	NUT, 5/8-16 REGHEXOTRIK	1
69	353175	CLUTCH ROD ASSY, .259 DIA 3.92	1
71	325780	SPRING .3500X2.15 X.055 TENSION	1
72	323210	BRKT, TRCTN BR BLKPHOS	1
73	46624	BOLT, .500X .135 HHSH 5/16-18	1
74	1498	NUT, 5/16-18 REGHEXOTRIK	1
75	933263	ROD, BRAKE 940 BLKPHOS	1
76	913881	SPRING, CLUTCH .625 OD	1
77	50352	NUT, 1/4-20 WDFLK TOPLOCK	1
78	42000	TIRE & RIM, PU 18X6.500X15FWH SEE TIRE TREAD PAGE	2
78-1	84187	VALVE STEM	2
78-2	38182	HUB	2
79	52528	KEY, SQUARE .19750X2.85L6	2
80	642	WASHER, FLAT .765X1.21X.076	4
81	42815	WASHER, FLAT .768X1.63X.07	2
82	90625	RING, RETEX .57X.05TRUS189-76	2
83	40394	HUB CAP, 1.800D X 7.85L6	2



**NOTE: ALWAYS USE ORIGINAL EQUIPMENT PARTS.** Use of service/replacement parts other than original equipment parts may void your warranty.

ALL UNNUMBERED  
ITEMS ARE INTERCHANGEABLE  
WITH OPPOSITE SIDE

333362A




**NOTE: ALWAYS USE ORIGINAL EQUIPMENT PARTS.** Use of service/replacement parts other than original equipment parts may void your warranty.

**ALL UNNUMBERED  
ITEMS ARE INTERCHANGEABLE  
WITH OPPOSITE SIDE**

331113B

KEY #	PART #	DESCRIPTION	QTY
1	ENGINE	10-12HP B&S 3A (SEE ENGINE MANUAL)	1
2	50047	SCREW, 3/8-16X1.25 WAHHTAPBLKP	4
3	128459	WASHER, EXLK .384X.69X.04	1
4	57908	MUFFLER-COMWXPA ROUND	1
5	43708	GASKET, MUFFLER	1
6	54767	SHIELD, HEAT FOR ROUND MUFFLER	1
7	54980	SCREW, 5/16-18X3.50 HHC	2
8	56472	DEFLECTOR SIDE OUT (RS122573)	1
9	95287	SCREW, #8-32X .28 HHWTAP	4
10	314989	TANK, FUEL 1 GAL CLEAR	1
11	300309	SCREW, .25X.75X.51HHWAPLASTITE	4
12	42258	TUBING, .20X.50X BULK GAS LINE	12 IN.
13	47345	CLAMP, FUEL LINE RED	2
14	45704	CAP, GAS 1-1/2-7 THD BLK	1
15	57444	TE, CABLE BLACK NYLON 5.62L	1
16	56534	CONTROL, THROTTLE LF 12HP 20.5	1
17	165841	SCREW, 10-24X.63 PHFLTMA	2
18	308459	NUT, #10-24 MXHDNYLX	2
19	50607	KNOB, ROUND THROTTLE BLACK	1
20	326547	OIL DRAIN VALVE ASSEMBLY	1
21	327422	CAP, OIL DRAIN VALVE ASM YELLOW	1
22	323542-053	CENTER SUPPORT, PLASTIC DASH	1
23	323685	TINNHERMAN CLIP CB114-1024-4	2
24	300309	SCREW, .25X.75X.51HHWAPLASTITE	2
25		SCREW, 10-24X .50 WAHHMA	2
26			
27	274707		



**NOTE: ALWAYS USE ORIGINAL EQUIPMENT PARTS.** Use of service/replacement parts other than original equipment parts may void your warranty.

ALL UNNUMBERED  
ITEMS ARE INTERCHANGEABLE  
WITH OPPOSITE SIDE


321244C

E3554-190

## PRE-PAINTED DECK ASSEMBLY

KEY #	PART #	DESCRIPTION	QTY
1	321982-853	DECK, MOWER 30"	1
2	67318	GUIDE, BELT 5/16-18 THD	1
3	1498	NUT, 5/16-18 REGHEXCTRLK	1
4	317017	BRACKET CHUTE MOUNT	1
5	314702	SPACER, SLEV .344X1.00X .500PM	1
6	120230	BOLT, 5/16-18X1.25 CARRUN	1
7	1498	NUT, 5/16-18 REGHEXCTRLK	1
8	45602	WASHER, FLAT .338X .87X.119	1
9	125215	BOLT, 5/16-18X .75 CARRUN	1
10	1498	NUT, 5/16-18 REGHEXCTRLK	1
11	311237-853	BRACKET, MOUNTING, FRONT	1
12	67072	BOLT, 5/16-18X .63 CARRUN	3
13	120393	WASHER, FLAT .344X .88X.065	3
14	1498	NUT, 5/16-18 REGHEXCTRLK	3
15	311236-853	BRACKET, BAR, TOW, FRONT	1
16	180079	SCREW, 5/16-18X1.00 HHC	2
17	58247	NUT, ADJUST	2
18	1498	NUT, 5/16-18 REGHEXCTRLK	2
19	313372-853	ASSY, TUBE, PIVOT	1
20	310672	SUPPORT, PIVOT TUBE	2
21	180077	SCREW, 5/16-18X .76 HHC	2
22	1498	NUT, 5/16-18 REGHEXCTRLK	2
23	314119-853	ASSY LIFT BRKT	1
24	180077	SCREW, 5/16-18X .76 HHC	2
25	120393	WASHER, FLAT .344X .88X.065	2
26	1498	NUT, 5/16-18 REGHEXCTRLK	2
27	315586	ASSEMBLY, QUILL	1
27-1	314272	QUILL, MACHINED CASTING	1
27-2	314274	TUBE, SPACER, STEEL	1
27-3	313578	BRING, BALL 6204-2AA-CS	2
28	35498	SCREW, 5/16-18X .76 WAHHTAP	5
29	188485	WASHER, EXLK .320X.61X.03	5
30	321146	SPACER, SLEV .790X1.250X .500	1
31	314273	PULLEY ASSEMBLY	1
32	22265	WASHER, FLAT .515X1.38X.110PL	1
33	1600	NUT, 1/2-13 REGHOTRLK	1
34	321144	SHAFT, QUILL 30° MOWER	1
35	318577	SHIELD, DUST, BEARING	1
36	313684	HUB, BLADE ADAPTOR	1
37	325751	BLADE, 30° TD MOWER 1.4 WING	1
38	22265	WASHER, FLAT .515X1.38X.110PL	1
39	1500	NUT, 1/2-13 REGHOTRLK	1
40	122229-853	BRACKET, IDLER ASSEMBLY	1
40-1	313510-853	BRACKET, ARM, IDLER	1
40-2	304973	Brake Pad - Hard - 232AF	1
40-3	41601	RIVET, OVBET 1/8THAX .500 ST	2
41	180113	SCREW, 5/16-18X3.00 HHC	1
42	45602	WASHER, FLAT .338X .87X.119	1
43	321145	SPACER, SLEV .322X .68X2.10	1
44	44108	NUT, 5/16-18 HWDFLCTRLK	1
45	180081	SCREW, 5/16-18X1.25 HHC	1
46	44108	NUT, 5/16-18 HWDFLCTRLK	1
47	35410	SPRING .071 X .82 X 4.37	1
48	302357	LINK	1
49	1498	NUT, 5/16-18 REGHEXCTRLK	1
50	50520	SPACER	1
51	125215	BOLT, 5/16-18X .76 CARRUN	1
52	1498	NUT, 5/16-18 REGHEXCTRLK	1
53	314099-853	BRACKET, BAR, REAR STABIL	2
54	180079	SCREW, 5/16-18X1.00 HHC	4
55	58247	NUT, ADJUST	2
56	1498	NUT, 5/16-18 REGHEXCTRLK	2
57	51940	BOLT .500X .437 HHSH 3/8-16	2
58	1499	NUT, 3/8-16 REGHOTRLK	2
59	320505-853	BRACKET,LIFT BAR 30°	1
60	1498	NUT, 5/16-18 REGHEXCTRLK	2
61	180077	SCREW, 5/16-18X .75 HHC	2

SEE DWG #321244 FOR PARTS  
ASSY OF PAINTED DECK



NOTE: ALWAYS USE ORIGINAL EQUIPMENT PARTS. Use of service/replacement parts other than original equipment parts may void your warranty.

ALL UNNUMBERED  
ITEMS ARE INTERCHANGEABLE  
WITH OPPOSITE SIDE


3256420

E3554-190

FINAL DECK ASSEMBLY

KEY #	PART #	DESCRIPTION	QTY
1		DECK 90° ASSY	1
2	301340	BOLT, 3/8-16X2.50 CARR	1
3	22265	WASHER, FLAT .015X1.50X.110PT	1
4	30059	RETAINER, BELT	1
5	45574	PULLEY, IDLER V4L 9.06X .72	1
6	25210	WASHER, FLAT .005X1.25X.050HTZ	1
7	30059	RETAINER, BELT	1
8	1486	NUT, 3/8-16 REG/HX CTR/LK	1
9	310734	HOOK, S. 10 GA. STEEL	2
10	321147	BELT, V 4L 54.0 - MOG SEC	1
11	47817	PIN, .095X1.750 CLEVIS-SHORT	1
12	06160	PIN, HAIR .091 CHAX1.62L.G	1
13	315914	CHUTE DEFLECTOR 30° DECK	1
14	314975	SPRING, TORSION CHUTE DEFLECTOR	1
15	304424	ROD, PIVOT DECK .312DX7.25	1
16	328035	PULLEY, ENGD.9.40OF16.50X8.000	1
17	25653	KEY, SQUARE .250S0X2.50L.G	1
20	120383	WASHER, REG/SP/LK .005X1.75X.12	1
21	182764	SCREW, 7/16-20X3.25 HHC	1
22	49830	SCREW, 3/8-16X7.50 HHC	1
23	1486	NUT, 3/8-16 REG/HX CTR/LK	2

\* ORDER INDIVIDUAL PARTS.




**NOTE: ALWAYS USE ORIGINAL EQUIPMENT PARTS.** Use of service/replacement parts other than original equipment parts may void your warranty.

ALL UNNUMBERED  
ITEMS ARE INTERCHANGEABLE  
WITH OPPOSITE SIDE

332051C


KEY #	PART #	DESCRIPTION	QTY
1	331453	WIRE HARNESS SF 6-12B&S WIAMM	1
2	41482	PRESS CLIP, 1.380LG. 258ID	2
3	803064	ASSY, LIGHT WIRE 1/4 TURN	1
4	52672	BULB, HEADLAMP	2
5	57444	TIE, CABLE BLACK NYLON 5.62L	2
6	41492	PRESS CLIP, 1.380LG. 258ID	1
7	327354	SWITCH, IGNITION & LIGHTS DELTA	2
8	327234	CUP-IGN (OFF-LIGHT ON-START)	1
9	327238	CAP-IGN INSIDE	1
10	327352	NUT, 5/8-BACME DELTA FOR BOOT	1
11	327350	KEY, IGNITION	1
12	57476	SWITCH, SCR MNT DP NO NO BLK	2
13	500302	SCREW, #10 X .50 WAHTAPP BLK	2
14	53716	SOLENOID	1
15	187745	SCREW, 1/4-20X .75 HXSEMMA	2
16	1084	WASHER, FLAT .281X1.00X.038	1
17	1502	NUT, 1/4-20 REGHEXCTALK	1
18	271172	NUT, 1/4-20 REGHEXKEPS	2
19	271187	NUT, 5/16-24 HKEPS	2
20	57444	TIE, CABLE BLACK NYLON 5.62L	2
21	6511	WIRE, GROUND, 12.5"	1
22	271184	NUT, 5/16-16 HEXKEPS	1
23	57547	SWITCH, SEAT	1
24	180505	SCREW, 1/4-20X .50 WAHTAPP	1
25	302257	BRACKET, CABLE RETAINER	1
26	822176	SCREW, 1/4-20X .75 HXSEMMA	1
27	606346	BATTERY, 12V	1
28	9149	BATTERY BRACKET	1
29	187745	SCREW, 1/4-20X .50 WAHTAPP	1
30	1802	BRACKET, CABLE RETAINER	1
31	180020	SCREW, 1/4-20X .75 HXSEMMA	1
32	271172	NUT, 1/4-20 REGHEXCTALK	1
33	302051	SCREW, 1/4-20X .75 HMC	2
34	302051	NUT, 1/4-20 REGHEXKEPS	2
35	302051	FUSE SPADE TYPE 52V 15A	2
36	302201	INSULATOR, BATTERY BOOT EURO	1
37	322298	SPlicer	1

## WIRING SCHEMATIC



13554-190

REPAIR PARTS



333059A

KEY #	PART #	DESCRIPTION	QTY
1	305002	FOAM HOOD 4X16	2
2	305003	PAD, 16 X 6 FOAM HOOD	2
3	321471	DECAL, DASH PLAIN EXPORT	1
4	024002	DECAL, WARNING, FRENCH/GERMAN	1
5	09524	DECAL, INSTRUCT CONSOLE TOP GER	1
6	08525	DECAL, INSTRUCT CONSOLE TOP FR	1
8	332359	DECAL, CERT DE CONFORMITE 1984	1
9	318010	DECAL, TUV GS	1
10	305770	DECAL, CAUTION TRIANGLE EUROPE	1
11	307363	DECAL, INSTR. CONSOLE TOP ENGL	1
12	310853	DECAL, DANGER ENGLISH	1
13	402214	DECAL, HEIGHT ADJUST	1
14	311294	DECAL, SHIFT REV/NEUTRAL	1
15	331013	DECAL, SHIFTER POSITION	1
16	307003	DECAL, BRAKE/CLUTCH ENG	1


5354-190

REPAIR PARTS



333060A

KEY #	PART #	DESCRIPTION	QTY
1	320853	DECAL, ECO-TRAC HOOD LH .....	1
2	320854	DECAL, ECO-TRAC HOOD RH .....	1
3	402137	NAMEPLATE UNITECH MEDIUM BL .....	2
5	320859	DECAL, CONSOLE RH .....	1
6	320857	DECAL, CONSOLE LH .....	1
7	307846	NAMEPLATE 11/3D WHITE .....	2
8	402138	NAMEPLATE UNITECH SMALL .....	1





KEY #	PART #	DESCRIPTION	QTY
1	310384	SEAT, MICHIGAN, W/SW HOLE	1
2	830847	STEERING WHEEL	1
3		PARTS BAG, ASSY SEAT/STEER	1
3-1	1200393	WASHER, FLAT .344X .50X.065	1
3-2	1206338	WASHER, HVSP TLK .328X .50X.09	4
3-3	180077	SCREW, 5/16-18X .75 HHC	4
3-4	466379	PIN, SPRING.250DIA X2.00LG HVPL	1
		BATTERY ACID PACK, 80 OZ	1

BATTERY ACID MAY BE PURCHASED AT YOUR LOCAL HARDWARE STORES.

330669A



Contact the dealer where your tractor was purchased for the available accessories. If you are unable to contact the dealer, write to the address on the front cover of this manual.

### **30" Standard Lawn Rider**



**Model #5708-17  
Grass Collector (30" decks)**

**5714-00 Mulching Kit (30" Deck)**



**Model #5548-16  
Tow Behind Lawn Sweeper for Grass and Leaves**

**314275 -30" Standard Lift Blade**

### **OTHER ACCESSORIES**

#### **Model**

#### **Description**

**5709-02  
322397**

**Front Weight Box - holds 35 lbs.  
30" Mulching blade**