


MODEL 20101A, 20101X92A, 20101X192A

ACCESSORIES: NONE

INSTRUCTION BOOK & PARTS LIST: 20101A F-97425 ;
20101X92A & 192A F-97414

DESCRIPTION 20" SIDE DISCHARGE PUSH
ENGINE 3.5 HP B&S CLASSIC
COLOR SILVER



MOWER HOUSING PARTS LIST

Key No.	Description	Part No.
1	Engine 095902-3105-01	20101A&92A
--	Book, Engine	F-90409
1	Engine 098902-0866-A1	20101x192A
--	Book, Engine	F-97404
2	Housing	776006
3	Bolt, Engine	25x8
4	Bolt, Axle	9x10
5	Wheel and Tire (use only 7" diamond tread)	20270
6	Washer	10851Z
7	Screw	4x21
8	Washer	17x38Z
9	Deflector, Rear	671912
10	Bolt	1x121

HANDLE PARTS LIST

Key No.	Description	Part No.
1	Handle, Upper (Black)	671918E701
2	Handle, Lower (Black)	671946E701
3	Bracket, Stop Lever	43628 BC
4	Lever, Stop	671924E700
5	Screw	26x220
6	Engine Stop Cable	671947
7	Guide, Rope	43956
8	Locknut	15x116
9	Screw	3x136
10	Fastener, Cable	71372
11	Bolt	1x111
12	Washer	10851 Z
13	Spacer	671914
14	Nut	15x84