

MODEL 20103X25B, 20103x34B, 20103x35B, 20104A, 20104x99A

ACCESSORIES: NONE

INSTRUCTION BOOK AND PARTS LIST:

20103X25B F-98435; 20103x34B F-98445; 20103x35B F-98446; 20104A F-98409; 20104x99A F-98404

DESCRIPTION

ENGINE



COLOR

20" SIDE DISCHARGE PUSH

TECUMSEH CENTURA

20103X25B, 20104X99A BRITE RED

20103X34B, 20103X35B, 20104A PEARL GRAY



MOWER HOUSING PARTS LIST

No.	Description	Part No.
1	Engine TVS90-43757P	20103X25B
	TVS90-46103E	20103X35B
--	Book, Engine	181-657-2
--	Engine LEV100335006B	20104A
		20104X99A
--	Book, Engine	181-657-14
2	Housing *	776006
3	Bolt, Engine	0025x6
4	Bolt, Axle	009x10
5	Wheel and Tire (use only 7" diamond tread)	020270
6	Washer	010851 Z
7	Screw	004x21
8	Washer	017x38 Z
9	Deflector, Rear	671912
10	Bolt	01X121

* All replacement housings are Brite Red.

HANDLE PARTS LIST

Key No.	Description	Part No.
1	Handle, Upper (Black)	672665E701
2	Handle, Lower (Black)	671946E701
3	Bracket, Stop Lever	043628 BC
4	Lever, Stop	671924E700
6	Engine Stop Cable	672557
7	Guide, Rope	043956
8	Locknut	15x116
9	Screw	03x136
10	Fastener, Cable	071372
11	Bolt	01x111
12	Washer	010851 Z
13	Spacer	671914
14	Nut	015x84