


MODEL 20251x4A



- * Parts are available from a Briggs & Stratton Authorized Service Center. See "Engines, Gasoline" or "Gasoline Engines" in the yellow pages of the telephone directory.
- ** All replacement housings will be brite red.

MOWER HOUSING

Key No.	Description	Part No.
1	Engine *	-----
1a	Key, Woodruff	20062
2	Housing, For Non-Folding Handle **	70123A
3	Bolt, Axle	9x10
4	Wheel and Tire	43618
5	Washer	10851 Z
6	Locknut, Flange	15x68
7	Bolt, Engine	25x6
8	Blade	42785E701
9	Washer, Belleville	17x137
10	Washer	17x124
11	Bolt, Hex	1x68
12	Adapter, Blade	42734
13	Deflector, Chute	42919
14	Push-On Cap	28x42
15	Spring	166x5
16	Pin, Pivot	215x11 Z
17	Retainer	42743
18	Deflector, Rear	42746
19	Stop, Rope	42189
20	Bracket, Right Handle	42712E700
21	Bolt	1x38
22	Pin, Hair	31x5
23	Bracket, Left Handle	42713E700
27	Nut	15x82

Key No.	Description	Part No.
28	Hub Cap - Optional	20107
29	Hub Cap - Optional (For Ball Bearing Wheel)	43847
--	Hub Cap - Optional (For Plastic Wheel)	43615
30	Adjuster, Height	401007
31	Locknut, Flange	15x84
32	Grip	42294
--	Parts Bag	70251
--	Instruction Book	F-91406

HANDLE

Key No.	Description	Part No.
1	Handle, Upper - Straight	43838E701
2	Handle, Lower	43841E701
5	Carriage Bolt	2x77
6	Screw	3x136
7	Locknut	15x66
8	Screw	3x105
9	Throttle Control	43833
10	Washer	17x32 Z
11	Screw	26x220
12	Guide, Rope	43676
13	Engine Stop Lever - Straight	43793
14	Bracket, Stop Lever	43628 BC
15	Fastener, Cable	43499
16	Engine Stop Cable, For Folding Handle	43825
17	Wingnut	14x86
19	Screw	26x181
20	Clamp	20073