






KEY NO.	DESCRIPTION	PART NO.
1	Housing	776150
2	Engine *	-----
4	Adjuster, Left Rear Height	672605
5	Nut, Push	28x49
6	Bracket, Left Handle	1101239E700
7	Adjuster, Left Front Height	672601
8	Nut, Flange	15x68
9	Nut, Hex	15x102
10	Washer	17x38
11	Screw	4x21
13	Nut, Flange	15x84
14	Washer, Belleville	17x137
15	Washer	17x124
16	Bolt	1x153
17	Blade	672763E701
18	Adapter, Blade	672503
19	Adjuster, Right Front Height	672600
20	Bolt, Engine	25x6
23	Nut, Flange	15x88
24	Rod, Pivot	215x17 Z
25	Door, Rear (Black)	672610
26	Spring	166x44
27	Guard, Rear	671970
28	Wheel & Tire	672060
29	Bracket, Right Handle	1101238E700
30	Adjuster, Right Rear Height	672604
31	Screw	26x245
71	Washer	17x91 Z
--	Instruction Book	F-010418L



KEY NO.	DESCRIPTION	PART NO.	KEY NO.	DESCRIPTION	PART NO.
1	Handle, Upper (Black)	671918E701	13	Engine Stop Lever	43653E700
2	Handle, Lower (Black)	672874E701	14	Bracket, Stop Lever	43628 BC
3	Bolt	2x77	15	Tie Strap, Cable	71372
4	Knob, Plastic	71294	15A	Fastener, Cable	1101352
7	Locknut	15x116	16	Engine Stop Cable	1101360
12	Guide, Rope	71530			



KEY NO.	DESCRIPTION	PART NO.
1	Frame, Top	71592
2	Frame Assembly	672905
3	Bag, Cloth - Black	1101003
- -	Complete Service Replacement Kit *	24201

* Order from your nearest Central Parts Distributor.