

MODEL 20505X8A, 20505X62A, 20505X92A, 20505X192A

UNIT FULLY ASSEMBLED; 9 POSITION HEIGHT ADJUSTERS
FOLDING HANDLES; MULCH & BAG; MULCHER INSTALLED
EXCEPT MODEL 20505X8A BAGGER IS NOT INCLUDED

DESCRIPTION

ENGINE

COLOR

ACCESSORIES:


20" HI WHEEL

B&S ENGINES

BRITE RED except 20505x62A - ULTRA GREEN

24200 - REPLACEMENT BAGGER

INSTRUCTION BOOK AND PARTS LIST 20505X8A F-97444 ; 20505X62A F-97466 ; 20505X92A, 20505X192A F-97411



MOWER HOUSING PARTS LIST

Key No.	Description	Part No.	Key No.	Description	Part No.	Key No.	Description	Part No.
1	Housing	776004	--	20505x8A & x82A	671921E701	68	Bezel	671926
2	Engine 12H802-0661-01	20505x8A	18	Adapter, Blade	71056	69	Pin, Pivot	215x18Z
--	Book, Engine	F-90410	19	Adjuster, Right Front HT	671972	70	Deflector, Chute	671927
2	Engine 10A902-0478-A1	20505x62A	20	Bolt, Engine	25x6	71	Frame, Top *	71592
--	Book, Engine	F-97404	21	Support, Engine	671989	72	Frame Assembly *	672068
2	Engine 128802-1128-01	20505x92A	22	Washer	17x146	73	Bag, Cloth *	672069
--	Book, Engine	F-90410	23	Nut, Flange	15x79	HANDLE PARTS LIST		
2	Engine 128802-2328-A1	20505x192A	24	Rod, Pivot	215x17 Z	Key No.	Description	Part No.
--	Book, Engine	F-97405	25	Door, Rear	671915	1	Handle, Upper (Black)	671918E701
3	Stop, Rope (Recoil-Start)	42189	26	Spring	166x44	2	Handle, Lower (Black)	671917E701
4	Adjuster, Left Rear HT	671977	27	Guard, Rear	671970	3	Bolt	2x77
5	Push On Cap	28x42	28	Wheel (Dark Gray)	672060	4	Knob, Plastic	71495
6	Bracket, Left Handle	671988	--	Wheel (Light Gray)	672080	7	Locknut	15x116
7	Adjuster, Left Front HT	671973	29	Bracket, Right Handle	671967	8	Screw	3x144
8	Nut, Flange	15x68	30	Adjuster, Right Rear HT	671976	9	Throttle Controls	
9	Nut, Hex	15x102	31	Screw	26x259	--	20505x92A & 192A (Red)	672131
10	Washer	17x38	32	Bolt	1x85	--	20505x8A (Black)	672141
11	Screw	4x21	33	Wheel, Rear (20505x8A)	672074	--	20505x62A (Black)	672142
12	Hub Cap - Optional	43615	--	Wheel, (20505x92, 192A)	672075	12	Guide, Rope	43956
13	Nut, Flange	15x84	--	Wheel, Rear (20505x62A)	672064	13	Engine Stop Lever	671924E700
14	Washer, Belleville	17x137	34	Washer	17x164	14	Bracket, Stop Lever	43628 BC
15	Washer	17x124	51	Bolt, Carriage	2x81	15	Fastener, Cable	71372
16	Bolt	17x142	52	Screw	26x221	16	Engine Stop Cable	672127
17	Blade		66	Wingnut	71294	19	Screw	26x268
--	20505x92A & x192A	672056E701	67	Retainer, Push	28x64	20	Clamp	42294

* NOT INCLUDED IN MODEL 20505X8A

6e

Walking Mowers

12/96