



20707x6A Walk-Behind (1998)
Bag Assembly


Page 2 of 7

Ref #	Part Number	Qty	Description
1	071592		Frame, Top
2	672614		Frame Assembly
3	672069		Bag, Cloth-Black
	672614		Bag, Cloth-Gray




20707x6A Walk-Behind (1998)
Handle Assembly

Page 3 of 7




20707x6A Walk-Behind (1998)
Handle Assembly

Ref #	Part Number	Qty	Description
1	672665E701		Handle, Upper (Black)
2	671940E701		Handle, Lower (Black)
3	26X256		Bolt
4	672580		Control, Drive
5	15X116		Locknut
6	672554		Cable, Stop
8	672570E701		Lever, Stop
9	26X256		Screw
10	26X220		Screw
11	071372		Fastener, Cable
12	002X77		Bolt
13	071294		Knob
16	071530		Guide, Rope
17	091488		Cap
18	091489		Nut
19	03X136		Bolt
20	671916		Cover, Ignition
21	776011		Switch Ignition & Key
22	671992		Charger, Battery
23	776012		Harness, Wiring
24	776014		Battery
25	776013		Case, Battery
26	671959		Bracket, Battery
27	672220		Key, Ignition
28	43628 BC		Bracket, Stop Lever



20707x6A Walk-Behind (1998)
Mower Housing Assembly

Page 5 of 7



20707x6A Walk-Behind (1998)
Mower Housing Assembly

Ref #	Part Number	Qty	Description
1	776041		Housing
2			Engine Parts are available from an Authorized Engine Service Center. See "Engines, Gasoline" or "Gasoline Engines" in the yellow pages of the telephone directory.
3	071434		Pulley, Engine
4	032X64		Pin, Spring
5			UNKNOWN
6	671928		Cover, Belt
7	26X279		Screw
8	672605		Adjuster, Left Height
9	009X50		Bolt, Shoulder
10	071779		Pulley
11	071788		Spacer
12	671935 Z		Bracket, Idler Support
13	071778		Pulley, Idler
14	071793		Bearing
15	028X49		Nut, Push
16	672591		Bracket, Left Handle
17	671934		Bracket, Cable
18	015X43		Nut, Hex
19	071789		Spacer
20	671936		Arm, Idler
21	002X53		Bolt, Carriage
22	001X81		Bolt, Shoulder
23	011X16		E-Ring
24	071792		Gear, Pinion
25	001X85		Bolt
26	17X186		Washer
27	672603		Adjuster, Left Front Height
28	037X85		Belt
29	071791		Pulley, Axle
30	26X263		Screw
31	0031X9		Pin, Hair
32	043629		Pin, Spring
33	671931		Axle
34	671948		Cover, Axle
35	015X68		Nut, Flange
36	15X102		Nut, Hex
37	017X38		Washer
38	004X21		Screw
39	043615		Hub Cap Optional
40	17X169		Washer
41	015X84		Nut, Flange
42	672083		Wheel, Drive
43	17X120		Washer
44	071780		Cover, Dust
45	17X137		Washer, Belleville
46	17X124		Washer
47	01X153		Bolt
48	671921E701		Blade
49	672503		Adapter, Blade
50	672602		Adjuster, Right Front Height
51	002X16		Bolt, Carriage
52	26X221		Screw
53	0025X6		Bolt, Engine
55	17X146		Washer

20707x6A Walk-Behind (1998)
Mower Housing Assembly

Page 7 of 7

Ref #	Part Number	Qty	Description
56	015X88		Nut, Flange
57	215X17 Z		Rod, Pivot
58	672610		Door, Rear
59	166X44		Spring
60	671970		Deflector, Rear
61	672082		Wheel, Rear
63	672590		Bracket, Right Handle
64	672604		Adjuster, Right Height
65	26X245		Screw
66	071495		Wingnut
67	028X64		Retainer, Push
68	671926		Bezel
69	215X 18 Z		Pin, Pivot
70	671927		Deflector, Chute
71	028X42		Push On Cap
	F-98555		Instruction Book

