


MODE
21"
REG.
HARD

REAR BAGGER

REPL



KEY NO.	DESCRIPTION	B&S '09
1	Engine *	
2	Key, Woodruff	
3	Bolt, Engine	
4	Housing	
5	Adapter, Blade	
6	Blade	
7	Washer, Belleville	
8	Washer	
9	Bolt	
10	Push On Cap	
11	Pin, Hair	
12	Handle Bracket, Left	
13	Handle Bracket, Right	
14	Rod, Door Pivot	
15	Screw	
16	Deflector, Rear (Model with	
17	Door, Rear	
18	Spring, Torsion	
19	Spacer, Door	
20	Screw	
21	Wheel and Tire **	
22	Bolt, Axle	
23	Nut, Flange	
24	Height Adjuster	
25	Nut, Flange	
26	Stop, Rope	
27	Spacer	
28	Screw	
29	Frame Assembly *	
30	Nut, Hex	
31	Side Discharge Attachment	
32	Plastic Top	
33	Screw	
34	Bag (For Plastic Top)	
35	Support, Bag	
36	Frame Assembly	
37	Bag, Cloth	
38	Screw	
39	Clip	
40	Nut	
41	Push On Cap	
42	Hub Cap - Optional	
43	Hub Cap - Optional (For Bag)	
44	Washer	
45	Grip	

Parts Bag
Inst. Man.

* The engine model, type, and code numbers are
for the engine model, type, and code numbers are

Select Index Numbers here:

- | | |
|--|---|
| ☐ 1 093902-3114-01 | ☐ 23 15x68Z |
| ☐ 2 Key Woodruff | ☐ 24 Hgt Adjuster Assembly Lf Rr |
| ☐ 3 25x6 | ☐ 25 15x79 |
| ☐ 4 Qx Hsng Assembly 21" Pus -INACTIVE- | ☐ 26 Bearing Rope Stop 22 |
| ☐ 5 Adaptor Blade | ☐ 27 Spacer, Hgt Adjuster |
| ☐ 6 43836HT | ☐ 28 4x67 |
| ☐ 7 17x137 | ☐ 29 Handle 21" Sd Chute |
| ☐ 8 17x124 | ☐ 30 15x102 |
| ☐ 9 1x68 | ☐ 31 Chute, Side Discharge |
| ☐ 10 28x42 | ☐ 32 Top Hard Top Bagger |
| ☐ 11 31x5 | ☐ 33 26x254 |
| ☐ 12 Handle Support Assembly | ☐ 34 Bag Hard Top (8146) |
| ☐ 13 Handle Support Assembly | ☐ 35 Frame, Hard Top Upper |
| ☐ 14 215x14Z | ☐ 36 Frame Assembly H & S Bag |
| ☐ 15 26x245 | ☐ 37 Bag 21" Cloth Aeroval |
| ☐ 16 Deflector, Rear 21 3N | ☐ 38 4x21 |
| ☐ 17 Rear Door & Spacer K | ☐ 39 192x1 |
| ☐ 18 166x33 | ☐ 40 15x102 |
| ☐ 19 Spacer Door | ☐ 41 28x39 |
| ☐ 20 26x259 | ☐ 42 Qx Use 020107 Cap, H -INACTIVE- |
| ☐ 21 Wheel Assembly , Bar Trea | ☐ 43 Hub Cap 8X2 Bb Wheel |
| ☐ 22 9x10 | ☐ 44 17x173 |
| | ☐ 45 Grip, VINYL-75X1.25 |