




MOWER HOUSING

Key No.	Description	Part No.	Key No.	Description	Part No.	Key No.	Description	Part No.
1	Engine *		52	Clip, Indicator	48674	90	Screw	4x21
2	Key, Woodruff	20062	53	Link, Lifter	43721	91	Clip	192x1
3	Bolt, Engine	25x6	56	Crossbar, Front	71152E245	92	Nut	15x102
4	Housing	70127	57	Clip, Retainer	43675	Parts Bag, Hardware		
5	Adapter, Blade	43603	58	Screw	26x221			
6	Blade	43936E701	59	Bushing	43731			
7	Washer, Belleville	17x137	60	Nut, Lifter	43638			
8	Washer	17x124	61	Pin, Cotter	30x49			
9	Bolt	1x68	62	Strap, Lifter	43662Z			
10	Push On Cap	28x42	63	Crossbar, Rear	43643E700			
11	Pin, Hair	31x5	64	Bearing, Lifter	43788			
12	Handle Bracket, Left	71097	65	Bolt, Hex	1x91			
13	Handle Bracket, Right	71096	66	Rearing, Axle	71079			
14	Rod, Door Pivot	215x14Z	67	Locknut, Flange	15x88			
15	Screw	26x245	68	Belt, Drive	37x64			
16	Deflector, Rear	43640	69	Spring	16x27			
17	Door, Rear	43642E701	70	Transaxle	71121			
18	Spring, Torsion	188x33	71	Shield, Axle	43649			
19	Spacer, Door	43641	72	E-Ring	11x19			
20	Screw	26x259	73	Washer, Thrust	17x139			
21	Wheel and Tire, Front	43618	74	Pin, Drive	43629			
22	Nut	15x84	75	Pinion, Right	43630			
23	Screw	26x214	76	Pinion, Left	43631			
24	Nut, Flange	15x79	77	Cover, Dust	43616			
25	Stop, Rope	42189	78	Wheel and Tire, Drive	43617			
26	Cover, Belt	43770	79	Washer, Thrust	17x169			
27	Cover, Belt	43770	80	Nut, Lifter Crank	43787			
28	Screw	26x259	81	Locknut	15x88			
29	Cover, Rear	43611	82	Washer	17x47Z			
30	Hub Cap (Optional)	43615	83	Support, Spring	71118Z			
31	Nut, Push	28x65	84	Spacer	43844			
32	Knob	43673	85	Support, Bag	43669			
33	Crank, Lifter	43895Z	86	Frame Assembly	43666			
34	Spacer, Lifter Crank	43672	87	Bag (For Plastic Top)	43670			
35	Spacer, Axle	43797	88	Screw	26x254			
36	Pin, Hair	31x9	89	Cover, Plastic	43619			
37	Bushing	43639						

Model No.	Instruction Book
21711E	F-92476
21711x5D	F-92476
21711x7B	F-92445
21711x8D	F-92476
21711x28C	F-92476
21711x92E	F-92479

HANDLE

Key No.	Description	Part No.
1	Handle, Upper	71093E701
2	Handle, Lower	43614E701
3	Bolt	2x77
4	Knob, Plastic	43958
5	Nut	15x2
6	Locknut	15x116
7	Screw	3x144
8	Throttle Control	71085
9	Washer	17x184
10	Screw	26x220
11	Guide, Rope	43956
12	Stop Lever	43791
13	Bracket, Stop Lever	43628 BC
14	Fastener, Cable	43499
15	Engine Stop Cable	43733
16	Screw	26x268
17	Clamp	42294
18	Lever, Drive	43723
19	Push On Cap	28x48
20	Screw	26x256
21	Cable, Drive	71091

* Parts are available from a Briggs and Stratton Authorized Service Center. See "Engines, Gasoline" or "Gasoline Engines" in the yellow pages of the telephone directory.

** All replacement housings will be blue red.

+ Model 24072A Side Discharge Attachment. This optional accessory gives you the opportunity of discharging the grass to the side.