


MODEL 21715X50A

REPAIR PARTS



REF. LEVER ONLY
ON LEVER HEIGHT
ADJUST UNITS

REF. BELT ONLY
ON
SELF-PROPELLED
UNITS

REF.
FRAME ASSY.


KEY

NO.	PART NO.	DESCRIPTION
10	ENGINE	See Engine Manual
12	710265	Screw, 3/8-16x1.00
14	2125	Key, Woodruff #505
50	71877	Blade 21"
51	671058	Adapter, Blade
53	710210	Washer, Bellville
54	710207	Flatwasher .406x.812x.06
55	710163	Screw, 3/8-24x1.50
80	71761-860	Assy., Frame
80-20	71096	Bracket, RH Handle
80-30	671097	Bracket, LH Handle
80-35	710204	Nut, 5/16-18 Hexwdfllk Whiz
80-40	-	not used on this unit
600	43640	Deflector, Rear
601	710271	Screw, 10-16x.50 Tap.
610	71833	Door, Rear
611	672049	Spacer, RR Door
612	710273	Screw, 10-16x.50
613	340822	Rod, Pivot Rear Door
614	710285	Cap, Push On
615	340823	Spring, Torsion
701	710291	Hair Pin
742	642189	Stop, Rope

341207A

MODEL 21715X50A

REPAIR PARTS



341193A

KEY NO.	PART NO.	DESCRIPTION
480	672185	Cable Stop
481	-	Not used on this unit
490	672147	Throttle Control
491	710178	Screw, 1/4-20x2.00
492	-	Not used on this unit
493	710203	Nut, 1/4-20
494	-	Not used on this unit
495	710275	Screw, 10-32x.62 Tap.
500	672178	Cable, Drive
501	710272	Screw, #10x1.25 Tap.
510	671372	Cable Tie
700	71137-806	Lower Handle
710	671581-806	Upper Handle
711	710175	Carriage Bolt, 5/16-18x2.00
712	671294	Wing Knob 5/16-18 w/nut
720	43651-860	Lever, Engine Stop
721	643628	Bracket, Stop Lever
730	643722	Lever, Drive Control
731	-	Not used on this unit
732	710286	Cap, Retainer w/cover
740	643956	Rope Guide 1/4-20
741	710203	Nut, 1/4-20 Hexnyl



710537

MODEL 21715X50A


REPAIR PARTS

NOTE

KEY# 80-2 IS WELDED TO UNDER SIDE OF FRAME.



SIDE DISCHARGE OPTION ONLY.



341497A

710537


MODEL 21715X50A

REPAIR PARTS

KEY NO.	PART NO.	DESCRIPTION
80	71761-860	Frame Assy.
80-2	71238	Guard, Belt
185	643877	Index Plate
186	671142	Assy, Axle and Bracket
187	671444	Lever, Height Adj
188	446363	Washer Flat .375 x .88 x .082
189	643387	Spacer, Pivot
190	710258	Washer, Spring
191	180124	Screw, 3/8-16 x 1.25
200	672042	Transmission, 21 3N1
201	643649	Shield, Axle
215	71577	Assy, height Adj LH
216	71578	Assy, height Adj RH
220	710167	Screw, 3/8-16 x .75
221	45171	Nut, 3/8-16
222	710326	Nut, Weld 3/8-16
223	710273	Screw, 10-16 x .50
230	71481	Support, Spring
231	710274	Screw 1/4-20x.63 Tap.
232	71480	Bushing, Spring Supt.
233	43844	Spacer, .508x.712x.563
234	710327	Compression Spring .37x1.00
235	710205	Nut, 5/16-18 Wdflk
240	710270	Screw 1/4-14x.50 Tap.
241	671032	Dustcover 8" Wheel
253	643629	Pin, Drive
254	671904	Gear, Pinion RH
255	671903	Gear, Pinion LH
256	710190	Belt, 3L
257	710254	Washer, Flat .502 x .99
258	20864	Ring, Ret E
260	43770-860	Cover, Lower Belt Guard
261	71239-860	Cover, Front Belt Guard
262	710273	Screw, 10-16x.50
270	671923	Pulley, 2L
271	13424	Kit, Roll Pin
275	671925	Bracket, Trans Cable
276	710264	Screw, 1/4-20x .50
284	71246-860	Cover, Rear Transmission
285	71245-860	Cover, Lower Transmission
286	710259	Rivet, Pop
287	710133	Screw, 1/4x.50
300	671132	Tire & Rim 8x2.0
301	671133	Wheel, Drive
302	710252	Flatwasher .382x1.0x.03
303	710140	Nut, 3/8-16 Mack
304	672122	Hubcap, 8" Wheel
590	-	not used on this unit
592	-	not used on this unit
593	-	not used on this unit
594	-	not used on this unit
620	-	not used on this unit


MODEL 21715X50A

REPAIR PARTS



KEY NO.	PART NO.	DESCRIPTION
800	-	Not a serviceable part
801	-	Not used on this unit
802	318010	Decal, TUV GS
805	-	Not used on this unit
806	-	Not used on this unit
810	710448	Decal, "Sentinel"
812	-	Not used on this unit
813	710449	Decal, Mow/bag
814	710356	Decal, Power Propelled
815	-	Not used on this unit
816	402701	Decal, Caution Deck RH Cut Hand
818	-	Not used on this unit
820	710764	Decal, Caution Export
822	339404	Decal, Stop Handle
825	336279	Decal, Drive Lever
830	-	Not used on this unit

341330A



326165A

710537

KEY NO.	PART NO.	DESCRIPTION
931	43666	Assy, Bag Frame
933	71592	Frame, Catcher
934	672052	Catcher, Bag Cloth