


MODEL 21755X68A

REPAIR PARTS




KEY NO.	PART NO.	DESCRIPTION
10	ENGINE	See Engine Manual
12	710265	Screw, 3/8-16x1.00
14	2125	Key, Woodruff #505
50	71877	Blade 21"
51	671058	Adapter, Blade
53	710210	Washer, Bellville
54	710207	Flatwasher .406x.812x.06
55	710163	Screw, 3/8-24x1.50
80	71763-860	Assy., Frame
80-20	71096	Bracket, RH Handle
80-30	671097	Bracket, LH Handle
80-35	710204	Nut, 5/16-18 Hexwdfllk Whiz
80-40	71575	Assy, Quadrant
600	43640	Deflector, Rear
601	710271	Screw, 10-16x.50 Tap.
610	71409	Door, Rear
611	71410	Spacer, RR Door
612	710273	Screw, 10-16x.50
613	340822	Rod, Pivot Rear Door
614	710285	Cap, Push On
615	340823	Spring, Torsion
701	710291	Hair Pin
742	642189	Stop, Rope

341207A

MODEL 21755X68A

REPAIR PARTS




KEY NO.	PART NO.	DESCRIPTION
480	672126	Cable Stop
481	-	Not used on this unit
490	672143	Throttle Control
491	710178	Screw, 1/4-20x2.00
492	-	Not used on this unit
493	-	Not used on this unit
494	12425	Clamp, Throttle
495	710275	Screw, 10-32x.62 Tap.
500	672178	Cable, Drive
501	710272	Screw, #10x1.25 Tap.
510	671372	Cable Tie
700	71137-846	Lower Handle
710	671581-846	Upper Handle
711	710175	Carriage Bolt, 5/16-18x2.00
712	671294	Wing Knob 5/16-18 w/nut
720	43651-860	Lever, Engine Stop
721	643628	Bracket, Stop Lever
730	643722	Lever, Drive Control
731	-	Not used on this unit
732	710286	Cap, Retainer w/cover
740	643956	Rope Guide 1/4-20
741	710203	Nut, 1/4-20 Hexnyl

341193A

710648

MODEL 21755X68A

REPAIR PARTS



341333A

710648


MODEL 21755X68A

REPAIR PARTS

KEY NO.	PART NO.	DESCRIPTION
80	71763-860	Frame Assy.
80-2	-	Not a serviceable part
180	71152-860	Assy, Crossbar Front
181	71167	Clip, Retainer Front Axle
182	43731	Bushing, Front Housing
183	710270	Screw, 1/4-14x.50 Tap.
200	672042	Transmission, 21 3N1
201	643649	Shield, Axle
202	671411	Support, Axle w/bearing
203	643788	Bearing, Lifter
210	672172-860	Asst, Crossbar RR 21"
211	71482	Retainer, Bearing
212	710174	Screw, 1/4-20x.63 Tap.
213	710205	Nut, 5/16-18 Wdfllk
230	71481	Support, Spring
231	710274	Screw 1/4-20x.63 Tap.
232	71480	Bushing, Spring Supt.
233	43844	Spacer, .508x.712x.563
234	710327	Compression Spring .37x1.00
235	710205	Nut, 5/16-18 Wdfllk
240	710270	Screw 1/4-14x.50 Tap.
241	643616	Dustcover 8" Wheel
250	671293	Spring, Lever
251	710274	Screw, 1/4-20x.63 Tap.
252	671297	Knob, Height Adjust
253	643629	Pin, Drive
254	671904	Gear, Pinion RH
255	671903	Gear, Pinion LH
256	710190	Belt, 3L
257	710254	Washer, Flat .502 x .99
258	20864	Ring, Ret E
260	43770-860	Cover, Lower Belt Guard
261	71239-860	Cover, Front Belt Guard
262	710273	Screw, 10-16x.50
270	671923	Pulley, 2L
271	13424	Kit, Roll Pin
275	671925	Bracket, Trans Cable
276	710264	Screw, 1/4-20x .50
280	43271-860	Assy, Lifter Link
281	710292	Hair Pin
282	71576	Clevis Pin Lift Spring Suppt.
283	710337	Spring, Extension
284	71246-860	Cover, Rear Transmission
285	71245-860	Cover, Lower Transmission
286	710259	Rivet, Pop
287	710133	Screw, 1/4x.50
300	643618	Tire & Rim 8x2.0
301	643617	Wheel, Drive
302	710252	Flatwasher .382x1.0x.03
303	710140	Nut, 3/8-16 Mack
304	673615	Hubcap, 8" Wheel
590	-	not used on this unit
592	-	not used on this unit
593	-	not used on this unit
594	-	not used on this unit
620	-	not used on this unit

MODEL 21755X68A


REPAIR PARTS



KEY NO.	PART NO.
800	-
801	-
802	318010
805	340820
806	-
810	710646
812	-
813	-
814	710647
815	-
816	402701
818	-
820	339151
822	339404
825	336279
830	-

DESCRIPTION
Not a serviceable part
Not used on this unit
Decal, TUV GS
Decal, Height Adjust
Not used on this unit
Decal, "Delverde"
Not used on this unit
Decal, Power Propelled
Not used on this unit
Decal, Caution Deck RH Cut Hand
Not used on this unit
Decal, Caution Export
Decal, Stop Handle
Decal, Drive Lever
Not used on this unit

341330A



KEY NO.	PART NO.
931	43666
933	71592
934	71699

DESCRIPTION
Assy, Bag Frame
Frame, Catcher
Catcher, Bag Cloth

326165A

710648