


MODEL 21777x99B 21777x99C



- * Parts are available from a Tecumseh Authorized Service Center. See "Engines, Gasoline or "Gasoline Engines" in the yellow pages of the telephone directory.
- ** All replacement housings will be white red.
- + Model 24072A Side Discharge Attachment. This optional accessory gives you the opportunity of discharging the grass to the side.

MOWER HOUSING

Key No.	Description	Part No.
1	Engine	
2	Key, Woodruff	20062
3	Bolt, Engine	25x6
4	Housing	70194
5	Adapter, Blade	43609
6	Blade	71161E701
7	Washer, Belleville †	17x137
8	Washer	17x124
9	Bolt	1x142
10	Push On Cap	26x42
11	Pin, Hair	31x10
12	Handle Bracket, Left	71097E700
13	Handle Bracket, Right	71096E700
14	Rod, Door Pivot	215x14Z
15	Screw	26x245
16	Deflector, Rear	43640
17	Door, Rear	71409SE
18	Spring, Torsion	166x33
19	Spacer, Door	71409SE
20	Screw	26x259
21	Wheel and Tire, Front	43610
22	Nut	15x84
23	Screw	26x214
24	Nut, Flange	15x79
25	Stop, Rope	42189
26	Cover, Belt	43770E700
27	Screw	26x259
28	Cover, Front Belt	71239E700
29	Cover, Lower	71245E700
30	Cover, Rear	71246E700
31	Screw	4x21
32	Nut	15x102
33	Hub Cap	43615
34	Nut, Push	26x65
35	Knob	43678

Key No.	Description	Part No.
46	Crank, Lifter	43835Z
47	Spacer, Lifter Crank	43677
48	Pin, Hair	31x9
49	Bushing	43639
50	Clip, Indicator	43674
51	Link, Lifter	43721E246
52	Crossbar, Front	71152E245
53	Clip, Retainer	71187
54	Screw	26x221
55	Bushing	43731
56	Nut, Lifter	43638
57	Pin, Cotter	30x48
58	Strap, Lifter	43662E700
59	Crossbar, Rear	43643E700
60	Bearing, Lifter	43788
61	Bolt, Hex	1x91
62	Bearing, Axle	71079
63	Locknut, Hange	15x88
64	Belt, Drive	37x64
65	Spring	164x27
66	Transaxle	71479
67	Shield, Axle	43649
68	Retainer, Bearing	71482Z
69	Pin, Drive	43629
70	Pinion, Right	43630
71	Pinion, Left	43631
72	Cover, Dust	43616
73	Wheel and Tire, Drive	43617
74	Washer, Thrust	17x189
75	Nut, Lifter Crank	15x117
76	Locknut	15x88
77	Bushing	71480
78	Support, Spring	71481Z
79	Screw	25x2
80	Spacer	43644
81	Support, Bag	43669

Key No.	Description	Part No.
86	Frame Assembly	43666
87	Bag	43670
88	Screw	26x254
89	Cover, Plastic	43619
90	Screw	4x21
91	Clip	162x1
92	Nut	15x102
93	Plug, Mulcher	71250
94	Parts Bag, Hardware	70253
95	Instruction Book	F-94471

HANDLE

Key No.	Description	Part No.
1	Handle, Upper (Black)	71093E701
2	Handle, Lower (Black)	71137E701
3	Bolt	2x77
4	Knob, Plastic	71294
5	Locknut	15x116
6	Screw	3x144
7	Throttle Control	71282
8	Washer	17x184
9	Screw	26x220
10	Guide, Rope	43656
11	Stop Lever - Curved	43791
12	Bracket, Stop Lever	43628 BC
13	Fastener, Cable	71372
14	Engine Stop Cable	43732
15	Lever, Drive	43723
16	Push On Cap	20x48
17	Screw	26x256
18	Cable, Drive	71529

20k

Walking Mowers
Revised 7/94