


MODEL 21975X6B

REPAIR PARTS




KEY#	PART#	DESCRIPTION
10	-	SEE ENGINE MANUAL
12	710265	SCREW, 3/8-16X1.00
14	2125	KEY, WDRF 505 .625X.156X.250
50	71584-850	BLADE, 21"X2.25" MULCH
51	671058	ADAPTER, BLADE
53	710210	WASHER.39IDX2.25ODX.12 BELLVIL
54	710207	WASHER, FLAT.406X.812X.06
55	710163	SCREW,3/8-24X1.50 HH
80	71762-850	ASSY.FRAME
80-20	71096	BRKT, RH HANDLE
80-30	671097	BRKT, LH HANDLE
80-35	710204	NUT,5/16-18 HEWDFLLK WHIZ
80-40	71575	ASS'Y, QUADRANT
600	43640	DEFLECTOR,REAR 21
601	710271	SCREW,10-16X.50HWASEMTAP
610	71409	DOOR, REAR
611	71410	SPACER,RR DOOR
612	710273	SCREW, 10-16X.50 WAHHSEMSAB
613	340822	ROD,PIVOT REAR DOOR
614	710285	CAP, PUSH ON .250
615	340823	SPRING, TORSION
701	710291	PIN, HAIR.062DIA
742	642189	STOP, ROPE

341207A

710621

MODEL 21975X6B

REPAIR PARTS




KEY#	PART#	DESCRIPTION
480	672126	CABLE, STOP
490	672143	CABLE, THROTTLE
491	710178	SCREW, 1/4-20X2.00 RDHDM
494	12425	CLAMP, THROTTLE QUANTUM
495	710275	SCREW, 10-32X.62 SLWAHTAP
500	672043	CABLE, DRIVE
501	710272	SCREW, #10X1.25 TAP.
510	671372	CABLE TIE
700	71137-846	HANDLE, LOWER
710	671581-846	HANDLE, UPPER
711	710175	BOLT, 5/16-18X2.00
712	671294	KNOB, WING 5/16-18
720	672117-850	LEVER, ENGINE STOP
721	643628	BRKT, STOP LEVER
730	671566	LEVER, DRIVE CONTROL
731	710491	WASHER, NYLON .281X1.0X.151
732	710286	CAP, RETAINER W/COVER
740	643956	GUIDE, ROPE 1/4-20 .50
741	710203	NUT, 1/4-20 HEXNYL 15X116

710621

341511 A

MODEL 21975X6B

REPAIR PARTS



710621

341333B

MODEL 21975X6B


REPAIR PARTS

KEY#	PART#	DESCRIPTION
80	71762-850	ASSY,FRAME
80-2	71238	GUARD BELT
180	71152-850	ASS'Y,CROSSBAR FRONT
181	71167	CLIP, RETAINER FRT AXLE
182	43731	BUSHING, FRT HSG
183	710270	SCREW, 1/4-14X.50 HWATAP
200	672042	TRANSMISSION
201	643649	SHIELD, AXLE
202	671411	SUPPORT, AXLE W/BRNG
203	643788	BEARING, LIFTER
210	672172-850	ASS'Y,CROSSBAR
211	71482	RETAINER,BEARING
212	710174	SCREW,5/16-18X.75 HHCFLTH
213	710205	NUT, 5/16-18 WDFLLK
230	71481	SUPPORT, SPRING
231	710274	SCREW, 1/4-20X .63HHWATAPSERBZ
232	71480	BUSHING, SPRING SUPT
233	43844	SPACER, .508X.712X.563
234	710327	SPRING, COMPRESSION .37X1.00
235	710205	NUT, 5/16-18 WDFLLK (15X88)
240	710270	SCREW, 1/4-14X.50 HWATAP Z,B&W
241	643616	DUSTCOVER, 8" WHEEL
250	671293	SPRING, LEVER HGT/ADJ REAR
251	710274	SCREW, 1/4-20X .63HHWATAPSERBZ
252	671297	KNOB, HGT/ADJ
253	643629	PIN, DRIVE .177X.750
254	671904	GEAR, PINION RH
255	671903	GEAR, PINION LH
256	710190	BELT,2L
257	710254	WASHER, FLAT .502 X .99 .031
258	20864	RING, RET E
260	43770-850	COVER, LOWER BELT GUARD
261	71239-850	COVER, FRONT BELT
262	710273	SCREW, 10-16X.50 WAHHSEMSAB
270	671923	PULLEY, 2L
271	13424	PIN, SPRING
275	671925	BRACKET, TRANS CABLE
276	710264	SCREW, 1/4-20 X .50
280	43721-850	ASS'Y, LIFTER LINK
281	710292	PIN, HAIR .080 DIA X1.63LG
282	71576	CLEVIS,PIN LIFT SPRING SUPT
283	710337	SPRING, EXTENSION
284	71246-850	COVER, REAR
285	71245-850	COVER, LOWER
286	710259	RIVET, POP .187DIA.X.44
287	710133	SCREW,HHWATAP 1/4X.50
300	672082	TIRE & RIM, 8X2.0
301	672083	WHEEL, DRIVE 8"X2.00
302	710252	WASHER, FLAT .382 X 1.0 X.03HT
303	710140	NUT,3/8-16HWDFLLK MACK 15X84
304	643615	HUBCAP, 8" WHEEL
590	71770	DEFLECTOR, CHUTE
591	71769	COVER, MULCH
592	340826	SPRING,TORSION .34X2.2 166X38
593	340827	ROD,PIVOT .25 X 4.68 215X16
594	710285	CAP, PUSH ON .250 DIA ROD
620	71250	PLUG, MULCHER-SMALL

710621


MODEL 21975X6B

REPAIR PARTS



KEY#	PART#	DESCRIPTION
805	340820	DECAL, HEIGHT ADJ.
806	-	not used on this unit
810	710441	DECAL, "MURRAY ULTRA"
813	710442	DECAL, 3N1 MULCH/BAG/MOW
814	-	not used on this unit
816	710443	DECAL, CUT FINGER-CHUTE
818	335631	DECAL, WARNING MUL. KIT PLUG
820	710299	DECAL, CAUTION

341330 A



710621

KEY#	PART#	DESCRIPTION
931	43666	ASS'Y, BAG FRAME
933	71592	FRAME, CATCHER BAG TOP
934	71873	CATCHER, BAG

326165A