





MODEL 22615X14A

REPAIR PARTS

KEY NO.	DESCRIPTION	PART NO.	KEY NO.	DESCRIPTION	PART NO.
1	Engine *	_____	34	Screw	26x263
2	Housing	776023	35	Idler, Backside	672754
3	Height Adjuster, Left Rear	672641	36	Locknut	15x43
4	Knob	71495	37	Bearing	71793
5	Wheel and Tire, Rear	71132	38	Spring	166x45
6	Locknut, Flange	15x84	39	Spacer	71789
7	Bolt, Carriage	2x81	40	Arm, Pivot	1101121 Z
9	Bolt, Engine	25x11	41	Spacer	71788
10	Nut	15x68	42	Pulley, Idler	71779
11	Height Adjuster, Left Front	672643	43	Bolt, Shoulder	9x50
12	Washer, Belleville	17x137	44	Belt, Briggs & Stratton	37x100
13	Washer	17x124	45	Washer	17x186
14	Bolt, Hex	1x153	46	Ring, Retainer	11x16
15	Blade, Mulcher	1101120E701	47	Gear, Pinion	71792
16	Adapter, Blade	672503	48	Pulley	71791
17	Height, Adjuster, Right Frt.	672642	49	Pin, Drive	43629
18	Height, Adjuster, Right Rr.	672644	50	Pin, Hair	31x9
19	Guard, Rear	672738	51	Axle	672508
20	Screw	26x245	52	Washer	17x169
21	Deflector, Chute	672421	53	Cover, Dust	71780
22	Push-On Cap	28x42	54	Bolt	1x85
23	Pin, Pivot	215x11 Z	55	Hub Cap	43615
24	Spring	166x5	56	Plate, Mulch	672422 Z
25	Baffle	672744E701	57	Bracket, Left Handle	672335E700
26	Wheel and Tire, Drive	71133	58	Bracket, Right Handle	672334E700
27	Pulley	71434	59	Screw	26x289
28	Pin, Spring	32x64	60	Bolt	1x120
29	Base, Engine	672671	62	Washer	17x45
30	Cover, Belt (Black)	1101025	63	Screw	26x288
31	Screw	26x259	64	Shield, Debris	1101026E701
32	Bracket, Idler Support	672751 Z	-	Book, Instruction	F-000503L
33	Washer	17x102			



1	Handle, Upper (Black)	71581E701
2	Handle, Lower (Black)	71137E701
3	Bolt	25x14
4	Control, Drive	672877
5	Locknut	15x116
6	Cable, Stop	1101144

8	Lever, Stop	672879E701
9	Bracket, Stop Lever	43628BC
11	Fastener, Cable	71372
12	Bolt	2x77
13	Knob	71294
16	Guide, Rope	71530