


MODEL 533L OR 22855X11G

REPAIR PARTS



339313

MODEL 533L


REPAIR PARTS

KEY		
NO.	DESCRIPTION	PART NO.
1	Engine	0
2	Screw	25x2
3	Mulcher	71373
4	Cover, Rear	71547
5	Screw	26x220
6	Screw	6x74
7	Adapter, Blade	71285
8	Strap, Adjuster	71318E701
9	Washer, Spring	20x3
10	Bolt, Shoulder	9x49
11	Pin, Hair	31x10
12	Locknut, Flange	15x84
13	Nut, Hex	15x68
14	Bolt, Shoulder	9x48
16	Bearing, Lifter	43788
17	Support, Axle	71411
18	Screw	26x275
19	Index, Height Adjuster	71368E701
20	Bracket, Handle	71317E701
21	Housing (Green)	71801E541
22	Bolt, Shoulder	9x17
24	Panel, Front	71329E701
26	Cap-Ball Bearing (Red)	71136
27	Wheel, Front (Gray)	71134
28	Pin, Hair	31x9
29	Link, Lifter	71328
30	Crossbar Assembly, Front	71325E701
31	Bushing	71291
32	Clip, Front Axle	71292
33	Screw	26x263
34	Washer, Belleville	17x137
35	Washer	17x124
36	Bolt, Hex	1x148
37	Blade	71849E701
38	Spacer, Adapter	71470
39	Cover, Dust	43616
40	Bolt, Engine	25x6
41	Spring, Extension	165x97
42	Crossbar Assembly, Rear	71315E701
43	Lever, Height Adjuster	71293E701
44	Grip, Height Adjuster	71297
45	Bushing	43886
46	Wheel, Rear (Gray)	71133
47	Washer	17x169
48	Hub Cap (Red)	71135
49	Support, Wheel	71370E701
50	Deflector, Chute	71295
51	Locknut	15x88
52	Guard, Rear	71289
53	Deflector, Rear	71381
54	Rod	71319Z
55	Cap, Push On	28x42
56	Key, Woodruff #6	20062
57	Plate, Bagger	71298E701
58	Door, Rear	71299E701
59	Grip, door	71306
60	Rod, Door	71300Z
61	Spring, Torsion	166x36
62	Guide, Rope	71443
63	Seal	71471
64	Bolt, Carriage	2x53
65	Retainer	28x64
66	Flatwasher	17x53Z
-	Instruction Book	339313

◊ Parts are available from a Authorized Engine Service Centre.

MODEL 533L

REPAIR PARTS




339313

MODEL 533L

REPAIR PARTS

KEY NO.	DESCRIPTION	PART NO.
1	Belt	37x77
2	Adaptor, Blade	71285
3	Locknut, Flange	15x88
4	Arm, Idler	71309Z
5	Pulley, Idler	71054
6	Screw	26x216
7	Bolt	1x141
8	Bracket, Transmission	71376Z
9	Spring, Extension	165x108
10	Locknut, Flange	15x84
11	Screw	26x275
12	Washer	17x186
13	Gear, Left Pinion	17287
14	Bearing, Lifter	43788
15	Support, Axle	71411
16	Index, Height Adjuster	71368E701
17	Pin, Hair	31x10
18	Arm, Clutch	400312
19	Support, Clutch	400312
20	Locknut	190x15
21	Pulley, Transmission	71288
22	Arm, Shift	400311
23	Key, Woodruff	400314
24	Pin, Drive	43629
25	Transmissin	71374
26	Shield, Axle	43649
27	Support, Wheel	71370E701
28	Gear, Right Pinion	71286
29	Housing (Green)	71801E541
30	Locknut, Flange	15x68
31	Screw	26x259
32	Bolt, Shoulder	9x49
33	Bolt, Shoulder	9x48




KEY NO.	DESCRIPTION	PART NO.
1	Tube, Grass Bag	71307
2	Bag	71714
3	Frame	71303

MODEL 533L

OR
22 855 X 11 G

REPAIR PARTS



KEY NO.	DESCRIPTION	PART NO.
1	Stop Lever	71567
2	Grip, Foam	71637
3	Pin	29x102
4	Push On Cap	28x42
5	Lever, Drive	71566
6	Pin	29x101
7	Spacer	71635
8	Locknut	15x116
9	Bolt	1x152
10	Bolt	1 x151
11	Washer	17x38Z
12	Guide, Rope	43956
13	Fastener, Cable	71372
15	Screw	26x256
16	Cable, Drive	71593
17	Throttle and Stop Cable	71594
18	Handle	71713E701
19	Control, Speed	71595
20	Screw	26x259
21	Bolt, Carriage	2x81
22	Knob	71495
23	Bracket, Handle	71317E701
24	Screw	26x268
25	Clamp	42294

339313