


MODEL 22857X62B

REPAIR PARTS



710995

335911B

MODEL 22857X62B


REPAIR PARTS

KEY#	PART#	DESCRIPTION
48	2125	KEY, WDRF 505 .625X.156X.250
54	671470	SPACER, BLADE ADAPTER R/DR DUAL
56	671849	BLADE, 22" MULCH
57	710210	WASHER, 39IDX2.25ODX.12
58	710207	WASHER, FLAT .406X.812X.06
59	710201	SCREW, 3/8-24X2.00 HHC
90	671317-846	BRKT, ASSY HANDLE
92	710184	BOLT, .497X.215HHSH 3/8-16
93	710258	WASHER, SPRING .50X1.0X.021
94	710140	NUT, 3/8-16HWDFLK MACK 15X84
100	671318-846	STRAP, HANDLE ADJUSTER
102	710291	PIN, HAIR.062DIA BENT SPEC
104	710184	BOLT, .497X.215HHSH 3/8-16
106	710258	WASHER, SPRING .50X1.0X.021
108	710140	NUT, 3/8-16HWDFLK MACK 15X84
172	710184	BOLT, .497X.215HHSH 3/8-16
174	45171	NUT, 3/8-16 HWDFL WHIZ-LOCK
176	710268	SCREW, 5/16-18X.75 WAHTAP
198	710328	SPRING, TENSION .81X2.68
199	335694	BELT, V3L 35.73LG
204	671288	PULLEY, ENG V3L 3.443X.645
206	335696	NUT, M10X1.5 HNYL
208	643629	PIN, DRIVE .177X.750 HEATTR
270	671325-850	CROSSBAR, ASSY FRONT
272	671291	BUSHING, FRONT HSNG
276	671292	CLIP, FRONT AXLE
278	710274	SCREW, 1/4-20X .63HHWATAPSERB
300	643724	TIRE & RIM, SEPU 8X2
302	710258	WASHER, SPRING .50X1.0X.021
304	710140	NUT, 3/8-16HWDFLK MACK 15X84
308	643847	HUBCAP, 8"W/BALL BRNG
310	710254	WASHER, FLAT .502 X .99
312	671286	GEAR, PINION RH 11T
313	671287	GEAR, PINION LH 11T
316	643616	DUSTCOVER, 8" WHEEL
318	710264	SCREW, 1/4-20X .50 WAHTAP
340	643617	WHEEL, DRIVE 8"X2.00
342	710252	WASHER, FLAT .382 X 1.0 X.03HT
344	710140	NUT, 3/8-16HWDFLK MACK 15X84
348	643615	HUBCAP, 8" WHEEL

710995

MODEL 22857X62B

REPAIR PARTS




KEY#	PART#	DESCRIPTION
480	339195	CABLE, RESTART
481	710179	SCREW, 1/4-20X1.75 HHCAP
489	57444	TIE, CABLE BLACK NYLON 5.62L
490	339196	TRTOTTLE CONTROL
499	57444	TIE, CABLE BLACK NYLON 5.62L
500	339193	CABLE, DRIVE ASSY
505	710273	SCREW, 10-16X.50 WAHHSEMSAB
510	339194	CABLE, SHIFTER SPEED CONTROL
511	710179	SCREW, 1/4-20X1.75 HHCAP
516	710275	SCREW, 10-32X.62 SLWAHTAP
519	57444	TIE, CABLE BLACK NYLON 5.62L
630	53446	PIN, 5/16-18
631	120393	WASHER, FLAT .344 X L.69X.065
632	120376	NUT, /5/16-18
730	671713-846	HANDLE, 22"3&1
732	710176	BOLT, 5/16-8X1.5 CARR GR
737	671495	KNGB, WING 5/16-18
740	671567	BAIL, ENG CNTL FLATTEN
741	671566	LEVER, DR CNTL
742	339065	WASHER, NYLON
743	710289	PIN, CLEVIS .25X1.56LG
744	710285	CAP, PUSH ON .250 DIA
745	321354	GUIDE, ROPE 1/4-20 .50ID
746	780029	NUT, 1/4-20 HEXNYL

339435 A

710995


MODEL 22857X62B

REPAIR PARTS



KEY#	PART#	DESCRIPTION
200	671374	TRANSMISSION,
202	643649	SHIELD, AXLE
250	671315-850	CROSSBAR, ASSY REAR
260	671411	SUPPORT, AXLE W/BRNG
266	643788	BEARING, LIFTER

336481C




KEY#	PART#	DESCRIPTION
10	-	ENGINE (See engine manual)
14	710265	SCREW, 3/8-16X1.00
50	671285	ADAPTER, BLADE PULLEY 2.25OD
80	671377-850	FRAME, ASSY 22"
262	710277	SCREW, 5/16-18X.63
593	57072	BOLT, 5/16-18X.63
594	710288	NUT, RETAINER 5/16-18X.62OD
597	2968	WASHER, FLAT .504X .75X.059

336482B

710995

MODEL 22857X62B

REPAIR PARTS



710995


336484A

MODEL 22857X62B**REPAIR PARTS**

KEY#	PART#	DESCRIPTION
252	671293	SPRING, LEVER HGT/ADJ REAR
254	671297	KNOB, HGT/ADJ
256	710274	SCREW, 1/4-20X .63
258	710337	SPRING, EXTENSION .953X3.25
280	671328-850	LIFTER, ASSY LINK 22"3&1
282	710292	PIN, HAIR .080 DIA X 1.63LG
284	671547	COVER, REAR
286	710180	SCREW, 1/4-20X.63 HHMAPINCH
288	710269	SCREW, 10-16X.75 SLHWATAP
590	671296	CHUTE, RR DISCHARGE
591	672230-846	CHUTE, FLOOR REAR
592	710260	RIVET, POP
596	335644	NUT, WING 5/16-18 SERR
598	71906	GASKET, COMPRESSION (THICK)
599	671373	PLUG, MULCHER 22"3&1
600	671298-846	PLATE, BAG 22"3&1
601	710276	SCREW, 5/16-18 .62HHWATAP
603	671443	GUIDE, ROPE LOWER .25ID
604	710259	RIVET, POP .187DIA.X.44 LG
605	671289	GUARD, REAR TOE
607	671319	ROD, REAR GUARD
609	710285	CAP, PUSH ON
610	671299-846	DOOR, REAR 22"
612	671300	PIN, HING DOOR 10.02LG X.192OD
613	710267	SCREW, #8-32X.38HHWATAP
614	335572	SPRING, TORS .44ODX2.32LG
616	671306	GRIP, DOOR
830	710443	DECAL, CUT FINGER (NEW) 44X6458
	671295	SIDE DISCHARGE CHUTE (NOT SHOWN)


MODEL 22857X62B

REPAIR PARTS



KEY#	PART#	DESCRIPTION
170	338842	BRACKET, TRANSMISSION
180	336480	IDLER, ARM
182	710200	BOLT, .497X.138 HSSH 3/8-16
184	710140	NUT, 3/8-16
190	671054	PULLEY, IDLER BFF
192	180080	SCREW, 5/16-18X1.13 HHC
194	710205	NUT, 5/16-18 WDFLLK (15X88)

336483A




KEY#	PART#	DESCRIPTION
500	339193	CABLE, DRIVE ASSY
505	710273	SCREW, 10-16X.50
510	339194	CABLE, SHIFTER
516	710275	SCREW, 10-32X.62

336486A

710995


MODEL 22857X62B

REPAIR PARTS



KEY#	PART#	DESCRIPTION
818	-	NOT USED ON THIS UNIT
819	-	NOT USED ON THIS UNIT
820	-	NOT A SERVICEABLE PART
822	335633	DECAL, DECK LIFT INDICAT 1-7
823	-	NOT USED ON THIS UNIT
824	710445	DECAL,MURRAY ULTRA
825	-	NOT USED ON THIS UNIT
826	710442	DECAL,MULCH BAG & MOW
830	710443	DECAL, CUT FINGER
832	710446	DECAL,CAUTION RB (NEW) 44X6459
834	335631	DECAL, WARNING MUL KIT PLUG

335916D



KEY#	PART#	DESCRIPTION
931	671303	FRAME, ASSY GRASS BAG 22"3&1
933	671307	TUBE, GRASS BAG 22"3&1
934	71907	BAG,CATCHER Y.K.SIG.22"GRAY

326165A

710995