


228610x68B

MOWER HOUSING ASSEMBLY



228610x68B

MOWER HOUSING ASSEMBLY

Key No.	Description	Part No.	Key No.	Description	Part No.
1	Housing	1101616E700	40	Washer	17x124
2	Engine *	-----	41	Bolt	01x144
3	Pulley, Drive	1101653	42	Adapter, Blade	1101336
4	Spacer, Engine	1101331	43	Baffle, Front **	672915E701
5	Cover, Belt	1101596	44	Nut, Flange	015x68
6	Screw	26x304	45	Adjuster, Right Front Height	1101028
7	Adjuster, Left Rear Height	672605	46	Bolt	001x85
8	Screw	26x303	48	Baffle, Rear **	672916E701
10	Transmission – Note: There are no internal serviceable parts for the transmission.	1101571	49	Adjuster, Right Rear Height	672604
			50	Push Retainer ***	028x49
11	Spacer	043844	51	Bracket, Right Handle	1101238E700
12	Spring, Compression	164x27	52	Nut, Flange	015x79
13	Nut	015x88	53	Bolt	001x45
14	Bolt	01x156	54	Bracket, Left Handle	1101239E700
23	E-Ring	0011x16	55	Bolt, Engine	025x11
24	Washer	17x186	57	Rod, Pivot ***	215x21
25	Gear, Pinion	071792	58	Door, Rear	1101070
26	Adjuster, Left Front Height	1101029	59	Screw	26x245
28	Belt	37x123	60	Spring ***	166x44
29	Cap, Hub	672122	61	Guard, Rear	1101105
30	Nut, Flange	015x84	62	Wheel & Tire, Rear	071132
31	Washer	17x169	66	Deflector, Chute	1101097
32	Wheel & Tire, Drive	071133	67	Push On Cap	028x42
33	Washer	017x75	68	Rod, Pivot	215x19 Z
34	Cover, Dust	071780	69	Spring, Torsion	166x38
37	Pin, Drive	043629	70	Cover, Mulch	1101098
38	Blade	1101120E701	71	Extension, Rear	672111E701
39	Washer, Belleville	17x137	--	Book, Instruction	F-030432L


* Parts are available from an Authorized Engine Service Center. See "Engines, Gasoline" or "Gasoline Engines" in the yellow pages of the telephone directory.

** Included with Housing, Key No. 1.

*** These part are included with Key 58.

228610x68B

HANDLE & BAG ASSEMBLY



Key No.	Description	Part No.	Key No.	Description	Part No.
1	Handle, Upper	1101613E701	10	Bolt	002x77
2	Handle, Lower	672906E701	11	Knob	071294
3	Bolt	26x307	12	Guide, Rope	071530
4	Control, Drive	1101676	13	Bolt, Carriage	002x81
5	Locknut	15x116	14	Knob, Plastic	071495
6	Control, Starter	1101611	15	Tube, Bag	1101075
7	Fastener, Cable	1101353	16	Frame Assembly	1101074
8	Lever, Stop	1101612E701	17	Bag, Cloth	1101614
9	Nut	15x142			