


Prod.No: 952 71 52-82


SPAREPARTS

107 26 19-63

⚠ WARNING
 All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by qualified service personnel.



Ref.	Part No.	Description	Ref.	Part No.	Description
1.	530-094551	Drive Shaft-51"	20.	952-715552	Cutting Head Ass'y. (Incl. 21-25)
2.	530-014222	Handle	21.	530-094875	Hub Ass'y.
3.	530-029445	Grip-Drive Shaft	22.	530-094830	Spring
4.	530-014646	Throttle Hsg.	23.	530-094827	Release Button
5.	530-036855	Switch Cover	24.	952-715508	Spool w/Line
6.	530-036493	Switch	25.	530-094828	Cover
7.	530-069252	T-Handle Kit	26.	530-031159	Hex Wrench 5/32
8.	530-094742	Clamp-Handle	27.	952-030102	Shaft Lubrication.
9.	530-015820	Bolt-Shield	28.	530-015610	Nut-Square
10.	530-016118	Wing Nut-Shield			
11.	530-015886	Screw-Line Limiter			
12.	530-095249	Line Limiter			
13.	530-069666	Shield Kit Ass'y. (Incl. 11 & 12)			
14.	530-047160	Lead Wire Ass'y			
15.	530-015932	Screw (Short)-Switch Cvr.			
16.	530-015933	Screw (Long)-Switch Cvr.			
17.	530-015768	Locknut-Switch Cover			
18.	530-095303	Drive Shaft Hsg.			
19.	530-094543	Dust Cup			



Key No.	Part No.	Description	Key No.	Part No.	Description
1	530-015773	Screw	56	530-069291	Starter Pulley
2	530-027529	Air Filter Cover	57	530-029395	Starter Spring
3	530-027530	Air Filter	58	530-027569	Starter Handle
4	530-015849	Screw	59	530-069232	Rope Kit
5	530-015852	Spacer-choke	60	530-014180	Pulley Housing Ass'y.
6	530-015254	Wave Washer	61	530-094189	Clutch Washer
7	530-027526	choke Shutter	62	530-069254	Clutch Ass'y. Kit
8	530-027527	Air Filter Plate	63	530-015796	Washer
9	530-069247	Fuel Line Kit	64	530-001733	Nut
10	530-014362	Fuel Pick-up Ass'y.	65	530-014211	Clutch Housing
11	530-069641	Carburetor (WT-300A) Incl. Limiter Caps	66	530-015767	Screw
12	† 530-019156	Carburetor Gasket	67	530-027511	Spacer
13	530-014347	Fuel Cap Ass'y.	68	530-015770	Screw
14	530-015775	Screw	69	530-015769	Screw
15	530-037497	Throttle Cable Ass'y.	70	530-015496	Screw
16	530-047172	Shroud & Tank Ass'y.	71	530-027523	Retainer
17	† 530-019154	Crankcase/Shroud Gasket	72	530-015768	Locknut
18	530-027593	Reed	73	530-069276	Engine Gasket Kit († Indicates Contents)
19	530-027594	Reed Stop	74	530-016080	Screw (Incl. in Starter Pulley Kit)
20	530-010960	Connecting Rod Ass'y. (Incl. Bearings)	75	530-035260	Carburetor Repair Kit (● Indicates Contents)
21	530-010934	Crankshaft Ass'y.	76	530-038317	Limiter Cap-Low
22	530-015126	Flywheel Key	77	530-038318	Limiter Cap-High
23	530-015772	Screw			
27	530-015771	Screw			
28	530-014016	Crankcase Ass'y. (Incl. #39-42)			
31	530-047145	Lead Wire/Grommet Ass'y.			
32	530-014015	Crankcase & Crankshaft Ass'y (#21, 28, 38 & 43)			
33	530-016064	Screw			
34	530-015162	Piston Pin Retainer			
35	530-025875	Piston Ring			
36	† 530-019178	Cylinder Gasket			
37	530-069275	Piston Kit (Incl. #34,35 & pin)			
38	530-038205	Connector			
39	530-032103	Inner Bearing			
40	530-015787	Retaining Ring			
41	530-019158	Crankshaft Seal			
42	530-032102	Outer Bearing			
43	530-015789	Crankshaft Retaining Ring			
44	530-015717	Screw			
45	530-027781	Muffler Guard			
46	530-069257	Muffler Kit			
47	530-036409	Muffler Attachment Spring			
48	530-069626	Cylinder			
49	530-030075	Spark Plug (RCJ-8Y)			
50	530-001624	Screw			
51	530-039134	Ignition Module Kit			
52	530-015128	Screw			
53	530-039189	Flywheel Ass'y.			
54	530-016030	Washer			
55	530-038010	Fan Housing			