





## SPAREPARTS

107 24 88-65



| No. | Part no      | Description           | No. | Part no.     | Description            |
|-----|--------------|-----------------------|-----|--------------|------------------------|
| N 1 | 530 04 71-44 | Wire Harness Ass'y    | 29  | 530 09 46-16 | Screw                  |
| 2   | 530 03 64-05 | Grip                  | 35  | 530 09 46-40 | Seal                   |
| 3   | 503 09 83-02 | Rocker Switch         | 36  | 530 09 46-39 | Dust Cup               |
| 4   | 502 20 85-02 | Throttle Hsg. - Left  | 38  | 530 01 42-10 | Shield                 |
| 6   | 502 20 96-02 | Throttle Lock         | 39  | 530 02 78-15 | Shield Retention Plate |
| 7   | 502 20 97-01 | Spring                | 43  | 530 01 57-92 | Washer                 |
| 8   | 502 19 94-03 | Throttle Lockout      | 44  | 530 01 54-92 | Washer                 |
| 9   | 502 20 86-02 | Throttle Hsg. - Right | 45  | 530 01 57-93 | Nut                    |
| 10  | 503 21 07-19 | Screw                 | 46  | 530 03 01-02 | Shaft Lubrication      |
| 11  | 502 19 92-03 | Throttle Trigger      | 47  | 502 21 17-03 | Shoulder Strap         |
| 12  | 530 21 07-38 | Screw                 | 50  | 530 02 95-77 | Bracket                |
| 13  | 530 01 46-72 | Handlebar             | 52  | 952 71 55-20 | Weed Blade             |
| 14  | 530 09 45-72 | Handlebar Bracket     | 53  | 530 01 57-08 | Screw                  |
| 15  | 530 03 67-42 | Drive Shaft Pad       | 54  | 530 09 49-01 | Line Limiter           |
| 16  | 530 09 46-86 | Clamp Harness Ass'y.  | 55  | 530 01 57-68 | Nut                    |
| 17  | 530 01 51-97 | Nut                   | 57  | 530 09 49-18 | Shield (lcl. 53-55)    |
| 18  | 530 01 22-07 | Handlebar Clamp       | 58  | 530 09 46-12 | Screw                  |
| 19  | 530 09 48-70 | Drive Shaft Housing   | 62  | 952 71 55-45 | Cutting Head Ass'y.    |
| 20  | 530 09 45-66 | Drive Shaft           | 63  | 530 09 45-62 | Hub                    |
| 21  | 530 06 92-52 | "T" Handle Ass'y.     | 64  | 530 09 49-56 | Spring                 |
| 22  | 530 01 57-91 | Screw                 | 65  | 530 06 93-12 | Locking Plate Kit      |
| 23  | 530 01 53-28 | Lockwasher            | 66  | 530 01 55-42 | Screw                  |
| 24  | 530 09 46-12 | Screw                 | 67  | 952 71 55-10 | Spool w/Line           |
| 25  | 530 00 17-11 | Screw                 | 68  | 530 09 45-22 | Release Button         |
| 26  | 530 00 16-42 | Lockwasher            | 69  | 530 09 45-21 | Cover                  |
| 27  | 502 19 93-01 | Trigger Spring        | 70  | 530 09 45-71 | Grass Washer           |
| 28  | 530 09 45-68 | Gear Box Ass'y.       |     |              |                        |



| No.  | Part no      | Description                                          | No.  | Part no.     | Description                                  |
|------|--------------|------------------------------------------------------|------|--------------|----------------------------------------------|
| 1    | 530 01 57-73 | Screw                                                | 51   | 530 03 91-34 | Ignition Module Kit                          |
| 2    | 530 02 75-29 | Air Filter Cover                                     | 52   | 530 01 51-28 | Screw                                        |
| 3    | 530 02 75-30 | Air Filter                                           | 53   | 530 03 91-36 | Flywheel Ass'y.                              |
| 4    | 530 01 58-49 | Screw                                                | 54   | 530 01 60-30 | Washer                                       |
| 5    | 530 01 58-52 | Spacer                                               | 55   | 530 02 93-89 | Fan Housing                                  |
| 6    | 530 01 52-54 | Wave Washer                                          | 56   | 530 06 92-91 | Starter Pulley                               |
| 7    | 530 02 75-26 | Choke Shutter                                        | 57   | 530 02 93-95 | Starter Spring                               |
| 8    | 530 02 75-27 | Air Filter Plate                                     | 58   | 530 02 75-69 | Starter Handle                               |
| 9    | 530 06 92-47 | Fuel Line Kit                                        | 59   | 530 06 92-32 | Rope Kit                                     |
| 10   | 530 01 43-62 | Fuel Pick-up Ass'y.                                  | 60   | 530 01 41-80 | Pulley Housing Ass'y.                        |
| N 11 | 530 03 53-48 | Carburetor (WT-300)                                  | 61   | 530 09 41-89 | Clutch Washer                                |
| 12   | 530 01 91-56 | Carburetor Gasket                                    | 62   | 530 06 92-54 | Clutch                                       |
| 13   | 530 01 43-47 | Fuel Cap Ass'y.                                      | 63   | 530 01 57-96 | Washer                                       |
| 14   | 530 01 57-75 | Screw                                                | 64   | 530 00 17-33 | Nut                                          |
| N 15 | 530 04 70-40 | Throttle Cable Ass'y.                                | 65   | 530 01 42-11 | Clutch Housing                               |
| 16   | 530 02 95-51 | Shroud & Tank Ass'y.                                 | 66   | 530 01 57-67 | Screw                                        |
| 17   | 530 01 91-54 | Gasket                                               | 67   | 530 02 75-11 | Spacer                                       |
| 18   | 530 02 75-93 | Reed                                                 | 68   | 530 01 57-70 | Screw                                        |
| 19   | 530 02 75-94 | Reed Stop                                            | 69   | 530 01 57-69 | Screw                                        |
| 20   | 530 01 09-60 | Connecting Rod Ass'y. (Incl. Bearings)               | 70   | 530 01 54-96 | Screw                                        |
| 21   | 530 01 09-34 | Crankshaft Ass'y.                                    | 71   | 530 02 75-23 | Pulley Retainer                              |
| 22   | 530 01 51-26 | Flywheel Key                                         | 72   | 530 01 57-68 | Locknut                                      |
| 23   | 530 01 58-10 | Screw                                                | 73   | 530 06 92-76 | Engine Gasket Kit (+ Indicates Contents)     |
| 27   | 530 01 57-71 | Screw                                                | N 75 | 530 04 71-45 | Lead Wire/Grommet Ass'y.                     |
| 28   | 530 01 40-16 | Crankcase Ass'y. (Incl. 39-42)                       | 76   | 530 03 50-14 | * + Metering Diaphragm                       |
| 32   | 530 01 40-15 | Crankcase & Crankshaft Ass'y. (Incl. 21-28, 38 & 43) | 77   | 530 03 51-51 | * + Metering Diaphragm Gasket                |
| 33   | 530 01 52-41 | Screw                                                | 78   | 530 03 51-47 | * Circuit Plate Gasket                       |
| 34   | 530 01 51-62 | Piston Pin Retainer                                  | 79   | 530 03 51-42 | Hi Speed Needle                              |
| 35   | 530 02 58-75 | Piston Ring                                          | 80   | 505 31 67-21 | Hi Speed Needle Spring                       |
| 36   | 530 01 91-78 | Cylinder Gasket                                      | 81   | 530 03 51-41 | Idle Needle                                  |
| 37   | 530 06 92-77 | Piston Kit (Incl. 34,35 & pin)                       | 82   | 501 46 73-01 | Idle Needle Spring                           |
| 38   | 530 01 57-88 | Spacer                                               | 83   | 530 03 52-03 | Idle Needle Screw                            |
| 39   | 530 03 21-03 | Inner Bearing                                        | 84   | 530 03 52-08 | Idle Needle Spring                           |
| 40   | 530 01 57-87 | Retaining Ring                                       | 85   | 505 52 01-25 | + Metering Lever Pin                         |
| 41   | 530 01 91-58 | Crankshaft Seal                                      | 86   | 505 52 01-27 | + Metering Lever                             |
| 42   | 530 03 21-02 | Outer Bearing                                        | 87   | 530 03 51-88 | + Metering Lever Spring                      |
| 43   | 530 01 57-89 | Crankshaft Retaining Ring                            | 88   | 503 11 70-01 | + Inlet Needle Valve                         |
| 44   | 530 01 57-17 | Screw                                                | 89   | 530 03 51-78 | + Inlet Screen                               |
| 45   | 530 02 77-81 | Muffler Guard                                        | 90   | 530 03 51-66 | * + Pump Diaphragm                           |
| 46   | 530 06 92-57 | Muffler Kit                                          | 91   | 504 13 09-06 | * + Pump Gasket                              |
| 47   | 530 03 64-09 | Muffler Spring                                       | 92   | 505 52 01-30 | Carb. Kwik Repair Kit (+ Indicates Contents) |
| 48   | 530 01 22-38 | Cylinder                                             | 93   | 530 03 51-85 | Carb. Gasket/Diaphragm Kit                   |
| 49   | 530 03 00-58 | Spark Plug                                           |      |              | * Indicates Contents)                        |
| 50   | 530 01 52-39 | Screw                                                | 94   | 530 01 58-23 | Screw (Incl. in Starter Pulley Kit)          |

+ = Engine Gasket Kit Contents N = NEW PART