

## **ILLUSTRATED PARTS BREAKDOWN**

**PARTNER**

**11.0 HP 36" MOWER DECK**

**LAWN TRACTOR**


**MODEL NO. 11-92 (P1136D)**

**964 77 07-00**



# REPAIR PARTS

TRACTOR- -MODEL NO. 11-92 (P1136D) PRODUCT NO. 964 77 07-00  
ELECTRICAL



# REPAIR PARTS

TRACTOR- -MODEL NO. 11-92 (P1136D) PRODUCT NO. 964 77 07-00  
ELECTRICAL


| KEY<br>NO. | PART<br>NO.  | DESCRIPTION                     |
|------------|--------------|---------------------------------|
| 1          | 532 16 34-65 | Battery                         |
| 2          | 874 76 04-12 | Bolt Hex Hd 1/4-20unc X 3/4     |
| 8          | 532 17 66-89 | Box Battery Fender              |
| 16         | 532 17 61-38 | Switch Interlock                |
| 24         | 532 12 47-80 | Cable Battery 6 Ga 11" Red      |
| 25         | 532 14 61-47 | Cable Battery 6 Ga Red w/16 wir |
| 26         | 532 17 51-58 | Fuse                            |
| 27         | 873 51 04-00 | Nut Keps Hex 1/4-20 Unc         |
| 28         | 532 12 47-73 | Cable Ground 6 Ga 12" black     |
| 29         | 532 12 13-05 | Switch Plunger Nc Gray          |
| 30         | 532 17 55-67 | Switch Ign                      |
| 33         | 532 14 04-01 | Key                             |
| 40         | 532 17 97-30 | Harness Ing                     |
| 41         | 871 11 04-08 | Bolt Blk Fin Hex 1/4 - 20 x 1/2 |
| 42         | 532 13 15-63 | Cover Terminal Red              |
| 43         | 532 17 88-61 | Solenoid                        |
| 48         | 532 14 08-44 | Adapter Ammeter Rectangular     |
| 52         | 532 14 19-40 | Protection Wire Loop            |
| 90         | 532 18 04-49 | Cover Terminal Battery          |

**NOTE:** All component dimensions given in U.S. inches.  
1 inch = 25.4 mm.



# REPAIR PARTS

TRACTOR- -MODEL NO. 11-92 (P1136D) PRODUCT NO. 964 77 07-00  
CHASSIS



# REPAIR PARTS


TRACTOR- -MODEL NO. 11-92 (P1136D) PRODUCT NO. 964 77 07-00  
CHASSIS

| KEY NO. | PART NO.     | DESCRIPTION                                |
|---------|--------------|--------------------------------------------|
| 1       | 532 17 46-20 | Chassis                                    |
| 2       | 532 17 65-54 | Drawbar                                    |
| 3       | 817 06 06-12 | Screw 3/8-16 x 3/4                         |
| 5       | 532 15 52-72 | BumperHood/Dash                            |
| 6       | 532 18 12-71 | Saddle                                     |
| 8       | 532 15 51-38 | Clip, Retainer Slide-On                    |
| 9       | 532 17 22-43 | Dash                                       |
| 10      | 872 14 06-08 | Bolt, Carriage 3/8-16 x 1                  |
| 11      | 532 17 49-96 | Dashboard, Panel LH                        |
| 12      | 532 14 56-60 | Clip Tinnerman Grille P/L                  |
| 13      | 532 18 17-19 | Dashboard, Panel RH                        |
| 15      | 874 18 05-12 | Machine screw 5/16-18 unc x 3/4            |
| 16      | 873 51 05-00 | Nut, Keps 5/16-18 Unc                      |
| 17      | 532 16 03-82 | Hood Pnt                                   |
| 18      | 532 12 69-38 | BumperHood                                 |
| 24      | 874 78 06-16 | Bolt, Hex Head, Fin. 3/8-16 x 1<br>Grade 5 |
| 25      | 819 13 13-12 | Washer 13/32 x 13/16 x 12 Gauge            |
| 26      | 873 80 06-00 | Nut Lock Hex w/Ins. 3/8-16 Unc             |
| 28      | 532 17 97-79 | Grille/Lens Asm                            |
| 29      | 532 18 12-73 | Lens                                       |
| 30      | 532 18 12-72 | Fender                                     |
| 31      | 532 13 66-19 | Fender Bracket                             |
| 33      | 532 18 10-57 | Footrest, LH                               |
| 34      | 532 18 10-58 | Footrest, RH                               |
| 35      | 872 11 06-06 | Bolt 3/8-16 X 3/4                          |
| 37      | 817 49 05-08 | Screw Thdrol 5/16-18 x 1/2                 |
| 38      | 532 17 57-10 | Bracket Asm. Pivot Mower Rear              |
| 51      | 873 80 04-00 | Nut Lock, w/Insert 14/20 UNC               |
| 52      | 819 09 14-16 | Washer 9/32 x 7/8 x 16 Ga.                 |
| 53      | 532 14 46-97 | Bracket Grille LH                          |
| 54      | 532 16 14-64 | Screw Hex WsHd 8-18 x 7/8                  |
| 55      | 532 14 46-96 | Bracket Grille RH                          |
| 57      | 874 78 04-12 | Bolt FinHex 1/4-20 UNC x .75               |
| 58      | 532 15 01-27 | Duct Air Engine P/L LT                     |
| 145     | 532 15 65-24 | Rod Pivot Chassis/Hood                     |
| 205     | 817 49 06-08 | Screw Thdrol 3/8-16 x 1/2                  |
| 206     | 532 17 01-65 | Bolt Shoulder 5/16-18 TT                   |
| 208     | 817 67 06-08 | Screw Thdrol 3/8-16 x 1/2                  |
| 209     | 817 00 06-12 | Screw Hexwsh Thdr 3/8-16 x 3/4             |
| 212     | 532 15 64-94 | Insert Lens Reflect                        |
| --      | 532 00 54-79 | Button Plug                                |

**NOTE:** All component dimensions given in U.S. inches.  
1 inch = 25.4 mm.

# REPAIR PARTS

TRACTOR- -MODEL NO. 11-92 (P1136D) PRODUCT NO. 964 77 07-00  
DRIVE



# REPAIR PARTS

TRACTOR- -MODEL NO. 11-92 (P1136D) PRODUCT NO. 964 77 07-00

## DRIVE


| KEY NO. | PART NO.     | DESCRIPTION                                                                                      |
|---------|--------------|--------------------------------------------------------------------------------------------------|
| 1       | -----        | Transaxle (See Breakdown)<br>Peerless, Model 204-506B<br>Order parts from transaxle manufacturer |
| 2       | 532 14 66-82 | Spring, Brake Return                                                                             |
| 3       | 532 12 36-66 | Pulley, Transaxle                                                                                |
| 4       | 812 00 00-28 | Ring, Retainer                                                                                   |
| 5       | 532 12 15-20 | Strap, Torque                                                                                    |
| 6       | 817 06 05-12 | Screw, 5/16-18 x 3/4 SMGML                                                                       |
| 7       | 532 16 22-40 | Bracket, T/A, Saddle Shift                                                                       |
| 8       | 532 13 16-79 | Rod, Shifter                                                                                     |
| 10      | 876 02 04-16 | Pin, Cotter 1/8 x 1                                                                              |
| 11      | 532 10 57-01 | Washer, Shift Plate                                                                              |
| 12      | 819 15 12-16 | Washer 15/32 x 3/4 x 16                                                                          |
| 13      | 874 55 04-12 | Bolt 1/4-28 UNF Gr. 8 w/Patch                                                                    |
| 14      | 810 04 04-00 | Washer Lock                                                                                      |
| 18      | 874 78 06-16 | Bolt, Fin Hex 3/8-16 Unc x 1 Gr. 5                                                               |
| 19      | 873 80 06-00 | Locknut 3/8-16                                                                                   |
| 21      | 532 10 69-33 | Knob                                                                                             |
| 22      | 532 13 08-04 | Rod, Brake                                                                                       |
| 24      | 873 35 06-00 | Nut, Hex Jam 3/8-16                                                                              |
| 25      | 532 10 68-88 | Spring, Rod, Brake                                                                               |
| 26      | 819 13 13-16 | Washer 13/32 x 13/16 x 16 Gauge                                                                  |
| 27      | 876 02 04-12 | Pin, Cotter 1/8 x 3/4                                                                            |
| 28      | 532 17 57-65 | Rod, Brake, Park                                                                                 |
| 29      | 532 07 16-73 | Cap, Plunger                                                                                     |
| 30      | 532 17 49-73 | Bracket, Transaxle, L.H.                                                                         |
| 32      | 874 76 05-12 | Bolt Hex Hd 5/16-18 UNC x 3/4                                                                    |
| 34      | 532 17 55-78 | Shaft, Foot Pedal                                                                                |
| 35      | 532 12 01-83 | Bearing Nylon                                                                                    |
| 36      | 819 21 16-16 | Washer 21/32 x 1 x 16 Gauge                                                                      |
| 37      | 532 12 49-63 | Pin, Roll 3/16 x 1                                                                               |
| 38      | 532 17 91-14 | Pulley Idler                                                                                     |
| 39      | 874 76 06-48 | Bolt Fin Hex 3/8-16unc x 3                                                                       |
| 41      | 532 17 55-56 | Keeper, Belt                                                                                     |
| 47      | 532 12 77-83 | Pulley, Idler                                                                                    |
| 48      | 532 15 44-07 | Bellcrank Asm Clutch                                                                             |

| KEY NO. | PART NO.     | DESCRIPTION                       |
|---------|--------------|-----------------------------------|
| 49      | 532 12 32-05 | Retainer, Belt                    |
| 50      | 874 76 06-24 | Bolt, Hex 3/8-16 x 1-1/2          |
| 51      | 873 68 06-00 | Nut, Crownlock 3/8-16             |
| 52      | 873 68 05-00 | Nut, Crownlock 5/16-18            |
| 53      | 532 10 57-10 | Link, Clutch                      |
| 55      | 532 10 57-09 | Spring, Return, Clutch            |
| 56      | 817 06 06-20 | Screw 3/8-16 x 1-1/4              |
| 57      | 532 13 08-01 | V-Belt, Drive                     |
| 59      | 532 16 96-91 | Keeper Belt Center Span           |
| 61      | 817 12 06-14 | Screw 3/8-16 x .875               |
| 62      | 532 12 48-72 | Cover, Foot Pedal                 |
| 63      | 532 18 02-19 | Pulley, Engine                    |
| 64      | 871 17 07-64 | Bolt, Hex 7/16-20 x 4 Gr. 5       |
| 65      | 810 04 07-00 | Washer, Lock Hvy Hlcl Spr 7/16    |
| 66      | 532 15 47-78 | Keeper, Belt Engine F-Proof       |
| 70      | 532 18 02-18 | Guide Belt Mower Drive RH         |
| 74      | 532 13 70-57 | Spacer, Split                     |
| 75      | 532 12 17-49 | Washer 25/32 x 1-1/4 x 16 Ga.     |
| 76      | 812 00 00-01 | E-Ring                            |
| 77      | 532 12 35-83 | Key Square                        |
| 78      | 532 12 17-48 | Washer 25/32 x 1-5/8 x 16 Ga.     |
| 79      | 532 12 50-96 | Key Woodruff #9 3/16 x 3/4        |
| 96      | 532 12 47-80 | Retainer Spring 1" Ziinc/Cad      |
| 112     | 819 09 12-10 | Washer 9/32 x 3/4 x 10 Ga.        |
| 113     | 532 12 72-85 | Strap Torque L.H. Lt              |
| 116     | 872 14 06-08 | Bolt RDHD SQNK 3/8-16unc x 1      |
| 120     | 873 90 06-00 | Nut Lock Flg. 3/8-16 Unc          |
| 145     | 874 49 05-40 | Bolt, Hex Flghd 5/16-18 Gr. 5     |
| 150     | 532 17 54-56 | Spacer Retainer                   |
| 151     | 819 13 32-10 | Washer 13/32 x 2 x 10 Ga.         |
| 170     | 532 17 83-94 | Keeper, Belt, Transaxle           |
| 202     | 872 11 06-14 | Bolt Carr Sh 3/8-16 x 1-3/4 Gr. 5 |
| 212     | 532 14 52-12 | Nut Hex Flange Lock               |
| 250     | 817 06 06-12 | Screw, 3/8-16 x 3/4 SMGML         |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

# REPAIR PARTS

TRACTOR- -MODEL NO. 11-92 (P1136D) PRODUCT NO. 964 77 07-00  
STEERING ASSEMBLY



# REPAIR PARTS


## TRACTOR- -MODEL NO. 11-92 (P1136D) PRODUCT NO. 964 77 07-00 STEERING ASSEMBLY

| KEY NO. | PART NO.            | DESCRIPTION                      |
|---------|---------------------|----------------------------------|
| 1       | 532 13 97-68        | Wheel Steering Opp. Sears Blk    |
| 2       | 532 17 51-31        | Axle Asm                         |
| 3       | 532 16 98-40        | Spindle Asm LH                   |
| 4       | 532 16 98-39        | Spindle Asm RH                   |
| 5       | 5321249-31          | Bearing Race Thrust Harden       |
| 6       | 532 12 17-48        | Washer 25/32 x 1-5/8 x 16 Ga     |
| 7       | 819 27 20-16        | Washer 27/32 x 1-1/4 x 16 Ga     |
| 8       | 812 00 00-29        | Ring Klip #t5304-75              |
| 9       | 532 12 49-37        | Bearing Col Strg Blk             |
| 10      | 532 17 51-21        | Link Drag                        |
| 11      | 810 04 06-00        | Washer Lock Hvy Hlcl Spr 3/8     |
| 12      | 873 94 08-00        | Nut Hex Jam Toplock 1/2-20       |
| 13      | 532 13 65-18        | Spacer Brace Axle                |
| 15      | 532 14 52-12        | Nut Hexflange Lock               |
| 17      | <b>532 18 06-41</b> | Shaft Asm Strg                   |
| 26      | 532 12 68-47        | Bushing Link Drag Blk LR         |
| 28      | 819 13 14-16        | Washer 13/32 x 7/8 x 16 Ga       |
| 29      | 817 06 06-12        | Screw 3/8-16 x .75               |
| 30      | 876 02 04-12        | Pin Cotter 1/8 x 3/4 Cad         |
| 32      | 532 13 04-65        | Rod Tie Wire Form 19 75 Mech     |
| 36      | 532 15 50-99        | Bushing Strg Nat .623/.618ld     |
| 37      | 532 15 29-27        | Screw TT #10-32 x 5 x 3/8 Flange |
| 38      | 532 14 01-75        | Cap Wheel Steer P/L              |
| 39      | <b>819 18 38-12</b> | Washer 9/16 x 2-3/8              |
| 40      | 532 12 47-01        | Nut Lock Center 3/8-24unf        |
| 41      | 532 10 07-11        | Adaptor Wheel Strg               |
| 42      | 532 16 96-33        | Boot Shaft Steering              |
| 43      | 532 12 17-49        | Washer 25/32 X 1 1/4 X 16 Ga     |
| 44      | <b>532 18 06-40</b> | Extension Steering               |
| 46      | 532 12 12-32        | Cap Spindle Fr Top Blk           |
| 47      | 532 12 48-36        | Fitting Grease                   |
| 51      | <b>873 54 04-00</b> | Nut 1/4-28                       |
| 54      | <b>871 13 04-20</b> | Bolt Hex 1/4-28 x 1-1/4          |
| 63      | 874 78 06-16        | Bolt Fin Hex 3/8-16 UNC Gr. 5    |
| 65      | 532 16 03-67        | Spacer Brace Axle                |
| 67      | 872 14 06-18        | Bolt RDHD SQ 3/8-16 UNC x 2-1/4  |
| 68      | 532 16 98-27        | Brace Axle                       |
| 71      | 532 17 51-46        | Steering Asm                     |
| 82      | 532 16 98-35        | Bracket Susp. Chassis Front      |
| 85      | 532 13 38-35        | Fastener Christmas Tree          |
| 88      | 532 17 51-18        | Bolt Shoulder 7/16-20            |
| 91      | 532 17 55-53        | Cup Steering                     |

**NOTE:** All component dimensions given in U.S. inches.  
1 inch = 25.4 mm.

# REPAIR PARTS

TRACTOR- -MODEL NO. 11-92 (P1136D) PRODUCT NO. 964 77 07-00  
SEAT ASSEMBLY




| KEY NO. | PART NO.     | DESCRIPTION                    |
|---------|--------------|--------------------------------|
| 1       | 532 17 53-89 | Seat                           |
| 2       | 532 14 05-51 | Bracket Pivot Seat 8 720       |
| 3       | 871 11 06-16 | Bolt Fin Hex 3/8-16unc x 1     |
| 4       | 819 13 16-10 | Washer 13/32 x 1 x 10 Ga       |
| 5       | 532 14 50-06 | Clip Push-In                   |
| 6       | 873 80 06-00 | Nut Lock Hex w/Wsh 3/8-16 Unc  |
| 7       | 532 12 41-81 | Spring Seat Cprsn 2 250 Blk Zi |
| 8       | 817 00 06-16 | Screw 3/8-16 x 1.5             |
| 9       | 819 13 16-14 | Washer 13/32 x 1 x 14 Ga.      |
| 10      | 532 17 48-94 | Pan Seat                       |
| 12      | 532 12 12-46 | Bracket Mounting Switch        |
| 13      | 532 12 12-48 | Bushing Snap Blk Nyl 50 Id     |

| KEY NO. | PART NO.     | DESCRIPTION                       |
|---------|--------------|-----------------------------------|
| 14      | 872 05 04-12 | Bolt Rdhd Sht Nk 1/4-20 x 1-1/2   |
| 15      | 532 13 43-00 | Spacer Split 28 x 96 Yel Zinc     |
| 16      | 532 12 12-50 | Spring Cprsn 1 27 Blk Pnt         |
| 17      | 532 12 39-76 | Nut Lock 1/4 Lge Flg Gr 5 Zinc    |
| 21      | 532 17 18-52 | Bolt Shoulder 5/16-18 Unc -2A     |
| 22      | 873 80 05-00 | Nut Lock Hex W/Insert 5/16-18 UNC |
| 23      | 871 11 08-14 | Bolt Hex                          |
| 24      | 819 17 19-12 | Washer 17/32 x 1-3/16 x 12 Ga.    |
| 25      | 532 12 70-18 | Bolt Shoulder 5/16-18 x 62        |
| 26      | 810 04 08-00 | Washer Lock Hvy HLCLSPR 1/2       |

**NOTE:** All component dimensions given in U.S. inches.  
1 inch = 25.4 mm


# REPAIR PARTS

TRACTOR- -MODEL NO. 11-92 (P1136D) PRODUCT NO. 964 77 07-00  
DECALS



| KEY NO. | PART NO.     | DESCRIPTION                   | KEY NO. | PART NO.     | DESCRIPTION                     |
|---------|--------------|-------------------------------|---------|--------------|---------------------------------|
| 2       | 532 14 50-05 | Decal Bat Dan/Poi P/L Symbols | 11      | 532 14 54-94 | Decal Mower Cut finger Symbol   |
| 3       | 532 14 09-87 | Decal Hood                    | 12      | 532 18 04-32 | Decal 100 DbA                   |
| 5       | 532 17 08-43 | Decal Engine                  | 13      | 532 14 69-98 | Decal Strg Wheel Cap            |
| 6       | 532 13 75-88 | Decal Chas. Turbo Collection  | 15      | 532 15 97-37 | Decal Brake/Clutch              |
| 7       | 532 14 08-37 | Decal Saddle Brake Parking    | 19      | 532 13 68-32 | Decal V-Belt Sch                |
| 8       | 532 14 09-87 | Decal Fender Logo             | --      | 532 16 25-98 | Decal Drawbar Load Limit        |
| 9       | 532 14 54-98 | Decal Read Owners Manual Syms | --      | 532 13 83-11 | Decal Lift Handle (Lift Handle) |
| 10      | 532 15 97-36 | Decal Chassis Hot Muffler     | --      | 532 18 29-48 | Manual Operator's Euro          |
|         |              |                               | --      | 532 18 29-49 | Manual Operator's Scan          |

## WHEELS & TIRES




| KEY NO. | PART NO.     | DESCRIPTION                       |
|---------|--------------|-----------------------------------|
| 1       | 532 05 91-92 | Cap Valve Tire                    |
| 2       | 532 06 51-39 | Stem Valve                        |
| 3       | 532 13 74-22 | Tire F Ts 15 X 6 - 6 Service      |
| 4       | 532 05 99-04 | Tube Front (Service Item Only)    |
| 5       | 532 14 14-72 | Rim Asm 6" front Service          |
| 6       | 532 12 49-57 | Fitting Grease (Front Wheel Only) |
| 7       | 532 12 49-59 | Bearing Flange (Front Wheel Only) |
| 8       | 532 14 12-68 | Rim Asm 8" rear Service           |
| 9       | 532 13 27-03 | Tire R Ts 18 x 8.5-8 C. Service   |
| 10      | 532 12 49-26 | Tube Rear (Service Item Only)     |
| 11      | 532 17 50-39 | Cap Axle Blk 1 50 X 1 00          |

NOTE: All component dimensions given in U.S. inches  
1 inch = 25.4 mm

## REPAIR PARTS

**TRACTOR- -MODEL NO. 11-92 (P1136D) PRODUCT NO. 964 77 07-00**

# ENIGNE



# REPAIR PARTS

TRACTOR- -MODEL NO. 11-92 (P1136D) PRODUCT NO. 964 77 07-00  
ENIGNE


| KEY NO. | PART NO.     | DESCRIPTION                                                           |
|---------|--------------|-----------------------------------------------------------------------|
| 1       | 532 17 05-51 | Control Th/ch Flag                                                    |
| 2       | 817 72 04-08 | Screw Hex Thd Cut 1/4-20 x 1/2                                        |
| 3       | -----        | Engine B&S Model No. 289707<br>(Order parts from engine manufacturer) |
| 4       | 532 13 73-48 | Muffler LT B&S 12/12 5 HP                                             |
| 13      | 532 16 52-91 | Gasket Eng                                                            |
| 14      | 532 14 84-56 | Tube Drain Oil Easy                                                   |
| 16      | 811 05 06-00 | Washer Lock Ext Tooth 3/8                                             |
| 23      | 532 16 98-37 | Shield Brn/Dbk Guard                                                  |
| 25      | 532 18 09-45 | Control Choke                                                         |
| 26      | 873 92 06-00 | Nut Keps 3/8-24 Unf                                                   |
| 29      | 532 13 71-80 | Kit Spark Arrecter                                                    |
| 31      | 532 10 92-02 | Tank Fuel Front 1.25                                                  |
| 32      | 532 14 05-27 | Cap Asm Fuel W/sym Vented                                             |
| 33      | 532 12 34-87 | Clamp Hose Blk                                                        |
| 37      | 532 13 70-40 | Line Fuel 20"                                                         |
| 38      | 532 14 83-15 | Plug Oil Drain Easy                                                   |
| 40      | 532 12 40-28 | Bushing Snap Nyl Blk Fuel Line                                        |
| 44      | 817 67 04-12 | Screw Hexwsh Thdrol 1/4-20 x 3/4                                      |
| 45      | 817 00 06-12 | Screw Hexwsh Thdrol 3/8-16 x 3/4                                      |
| 46      | 819 09 14-16 | Washer 9/32 x 7/8 x 16 Ga.                                            |
| 62      | 810 04 05-00 | Washer Lock Hvy Hlcl Spr 5/16                                         |
| 72      | 871 07 05-12 | Screw Hexhd Cap 5/16-18 x 3/4                                         |
| 78      | 817 06 06-20 | Screw 3/8-16 x 1-1/4                                                  |
| 81      | 873 51 04-00 | Nut Keps Hex 1/4-20 UNC                                               |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm



# REPAIR PARTS

TRACTOR- -MODEL NO. 11-92 (P1136D) PRODUCT NO. 964 77 07-00  
MOWER LIFT




# REPAIR PARTS

TRACTOR- -MODEL NO. 11-92 (P1136D) PRODUCT NO. 964 77 07-00  
MOWER LIFT


| KEY<br>NO. | PART<br>NO.  | DESCRIPTION                   |
|------------|--------------|-------------------------------|
| 1          | 532 15 94-60 | Wire Asm Inner W/Plunger      |
| 2          | 532 15 94-71 | Shaft Asm Lift                |
| 3          | 532 10 57-67 | Pin Groove                    |
| 4          | 812 00 00-02 | E Ring #5133-62               |
| 5          | 819 21 16-21 | Washer PLTD 21/32 x 1 x 21 Ga |
| 6          | 532 12 01-83 | Bearing Nylon Blk 629 Id      |
| 7          | 532 10 94-13 | Grip Handle Bicycle Matte Blk |
| 8          | 532 12 45-26 | Button Plunger Black          |
| 11         | 532 13 98-65 | Link Lift LH                  |
| 12         | 532 13 98-66 | Link Lift RH                  |
| 13         | 532 12 46-70 | Retainer Spring               |
| 15         | 532 17 32-88 | Link Front                    |
| 16         | 873 35 08-00 | Nut Jam Hex 1/2-13 Unc        |
| 17         | 532 17 56-89 | Trunnion                      |
| 18         | 873 80 08-00 | Nut Lock W/Wsh 1/2-13 Unc     |
| 19         | 532 13 98-68 | Arm Suspension Rear           |
| 20         | 532 16 35-52 | Retainer Spring               |
| 31         | 532 16 98-65 | Bearing Pvt Lift              |
| 32         | 873 54 06-00 | Nut Crownlock 3/8-24          |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm



# REPAIR PARTS

TRACTOR- -MODEL NO. 11-92 (P1136D) PRODUCT NO. 964 77 07-00  
MOWER



# REPAIR PARTS



TRACTOR- -MODEL NO. 11-92 (P1136D) PRODUCT NO. 964 77 07-00  
MOWER

| KEY NO. | PART NO.     | DESCRIPTION                     | KEY NO. | PART NO.            | DESCRIPTION                                                                              |
|---------|--------------|---------------------------------|---------|---------------------|------------------------------------------------------------------------------------------|
| 1       | 532 17 45-95 | Mower Deck Assembly             | 56      | 532 16 57-23        | Spacer, Retainer                                                                         |
| 2       | 872 14 05-06 | Bolt                            | 67      | 532 10 69-32        | Knob RD 3/8-16 Plstc Thd                                                                 |
| 3       | 532 13 80-17 | Bracket Assembly, Sway Bar      | 68      | <b>532 18 02-13</b> | Belt                                                                                     |
| 4       | 532 17 56-54 | Bracket Sway Bar                | 69      | 876 02 03-12        | Pin, Cotter 3/32 x 3/4                                                                   |
| 5       | 532 12 46-70 | Retainer Spring                 | 89      | 819 13 16-12        | Washer 13/32 x 1 x 12 Ga                                                                 |
| 6       | 532 17 80-24 | Bar Sway Deck                   | 107     | 532 13 35-02        | Spacer, Retainer                                                                         |
| 7       | 532 14 06-08 | Keeper Belt                     | 108     | 532 13 35-03        | Stiffener, Idler Arm                                                                     |
| 8       | 532 85 08-57 | Bolt, Hex 3/8-24 x 1.25 Gr. 8   | 113     | 817 49 05-08        | Screw Thdrol 5/16-18 x 1/2                                                               |
| 9       | 810 03 06-00 | Washer, Lock Hvy Hlcl 3/8       | 122     | 532 17 45-05        | Rod, Brake, LH                                                                           |
| 10      | 532 14 02-96 | Washer, Hardened                | 123     | 532 17 45-04        | Rod, Brake, RH                                                                           |
| 11      | 532 13 84-96 | Blade, Mower                    | 146     | 532 16 58-91        | Bolt Carriage Idler                                                                      |
| 13      | 532 13 76-45 | Shaft Assembly, Mandrel, Vented | 148     | 532 16 90-22        | Spring Return Idler                                                                      |
| 14      | 532 12 87-74 | Housing, Mandrel, Vented        | 149     | 532 16 58-98        | Retainer Spring Yellow Zinc                                                              |
| 15      | 532 11 04-85 | Bearing, Ball, Mandrel          | 150     | 819 09 12-16        | Washer 9/32 x 3/4 x 16 Ga.                                                               |
| 16      | 532 17 44-93 | Stripper, Mower Deck            | 151     | 532 16 96-70        | Bracket Clutch                                                                           |
| 19      | 532 13 28-27 | Bolt, Shoulder                  | 152     | 532 17 60-79        | Cable Clutch                                                                             |
| 21      | 873 68 05-00 | Nut Crownlock 5/16-18           | 153     | 532 16 96-74        | Washer Flat 3/8" Type B                                                                  |
| 23      | 532 13 66-31 | Bracket, Mower Deflector        | 154     | 532 16 96-75        | Spring Retainer                                                                          |
| 24      | 532 10 53-04 | Cap, Sleeve                     | 155     | 532 16 96-71        | Spring Retention Lever                                                                   |
| 25      | 532 12 37-13 | Spring, Torsion, Deflector      | 156     | 532 16 96-72        | Spacer                                                                                   |
| 26      | 532 11 04-52 | Nut, Push                       | 157     | 532 16 96-69        | Rod Clutch                                                                               |
| 27      | 532 17 61-62 | Shield, Deflector               | 158     | 817 72 04-08        | Screw Hex Thd Cut 1/4-20 x 1/2                                                           |
| 28      | 819 11 10-16 | Washer 11/32 x 5/8 x 16 Ga.     | 164     | 532 17 49-76        | Bracket Asm Idler Support                                                                |
| 29      | 532 12 19-80 | Rod, Hinge                      | 168     | 532 17 23-77        | Bracket Deck Cable                                                                       |
| 30      | 532 17 39-84 | Screw Thdrol                    | 169     | 532 17 49-77        | Bracket Asm Suspension                                                                   |
| 31      | 532 12 99-63 | Washer, Spacer                  | 170     | 532 17 23-59        | Bracket Suspension RF                                                                    |
| 32      | 532 15 35-31 | Pulley, Mandrel                 | 171     | 532 16 52-37        | Brace Support Susp. Frt                                                                  |
| 33      | 532 17 83-42 | Nut, Toplock, Flanged           | 172     | 532 17 23-55        | Bracket Suspension LF                                                                    |
| 34      | 872 11 06-14 | Bolt Rdhd 3/8-16 x 1-3/4        | --      | 532 13 07-94        | Mandrel Assembly (Includes Housing, Shaft and Shaft Hardware Only - Pulley Not Included) |
| 36      | 532 13 14-94 | Pulley, Idler, Flat             | --      | 532 18 13-76        | Replacement Mower, Complete                                                              |
| 40      | 873 68 06-00 | Nut Crownlock 3/8-16            |         |                     |                                                                                          |
| 45      | 532 12 47-88 | Retainer, Spring                |         |                     |                                                                                          |
| 53      | 532 13 08-40 | Brake Assembly                  |         |                     |                                                                                          |
| 54      | 532 13 39-43 | Washer, Hardened                |         |                     |                                                                                          |
| 55      | 532 13 38-40 | Idler Arm Assembly              |         |                     |                                                                                          |

**NOTE:** All component dimensions given in U.S. inches  
1 inch = 25.4 mm

# TRACTOR- -MODEL NO. 11-92 (P1136D) PRODUCT NO. 964 77 07-00

## SCHEMATIC



**IGNITION SWITCH**

| POSITION | CIRCUIT   |
|----------|-----------|
| OFF      | M + G     |
| ON       | B + L     |
| START    | B + S + L |

### WIRING INSULATED CLIPS

**NOTE:** IF WIRING INSULATED CLIPS WERE REMOVED FOR SERVICING OF UNIT, THEY SHOULD BE REPLACED TO PROPERLY SECURE YOUR WIRING.

NON-REMOVABLE CONNECTIONS

REMOVABLE CONNECTIONS