

ILLUSTRATED PARTS BREAKDOWN

PARTNER

14.5 HP, 107 MOWER DECK

LAWN TRACTOR


MODEL NUMBER 145HCRD (P145HCRDD)

954 56 47-26



REPAIR PARTS

TRACTOR- -MODEL NO. 145HCRD (P145HCRDD), PRODUCT 954 56 47-26
ELECTRICAL



REPAIR PARTS

TRACTOR- -MODEL NO. 145HCRD (P145HCRDD), PRODUCT 954 56 47-26
ELECTRICAL


KEY NO.	PART NO.	DESCRIPTION
1	532 16 34-65	Battery
2	874 76 04-12	Bolt Hex Hd 1/4-20 Unc X 3/4
16	532 17 61-38	Switch Interlock
21	532 17 56-85	Harness Asm Light W/4152J
22	532 00 41-52	Bulb Light #1156
24	532 12 47-80	Cable Starter 6Ga 11" Red
25	532 16 59-87	Cable Battery Crd 56" Red
26	532 17 51-58	Fuse
27	873 51 04-00	Nut Keps Hex 1/4-20 Unc
28	532 12 77-25	Cable Ground 6Ga 18" Black
29	532 16 07-84	Switch Plunger Normal Op Olive
30	532 17 55-66	Switch Ignition
33	532 14 04-01	Key Ign Molded Indak
40	532 17 97-28	Harness Ign
41	871 11 04-08	Bolt Flk Fin Hex 1/4-20 Unc X 1/2
42	532 13 15-63	Cover Terminal Red
43	532 17 88-61	Solenoid
48	532 14 08-44	Adapter Ammeter Rectangular
52	532 14 19-40	Protection Wire Loop
58	532 16 94-19	Buzzer Crd
59	532 18 03-79	Switch FBI CRD
66	817 49 06-08	Screw Thdrol 3/8-16 x 1/2 Ty-Tt
81	532 10 97-48	Relay Asm

NOTE: All component dimensions given in U.S. inches.
1 inch = 25.4 mm.



REPAIR PARTS

TRACTOR- -MODEL NO. 145HCRD (P145HCRDD), PRODUCT 954 56 47-26
CHASSIS AND ENCLOSURES



REPAIR PARTS

TRACTOR- -MODEL NO. 145HCRD (P145HCRDD), PRODUCT 954 56 47-26 CHASSIS AND ENCLOSURES


KEY NO.	PART NO.	DESCRIPTION
1	532 17 46-20	Chassis
2	532 18 03-84	Drawbar
3	817 06 06-12	Screw 3/8-16 x .75
5	532 15 52-72	Bumper Hood/Dash
6	532 15 59-23	Saddle
8	532 12 64-71	Clip Insulator 13/32 Mtg. Hole
9	532 17 22-43	Dash
10	872 14 06-08	Bolt, Carriage 3/8-16 x 3/4
11	532 17 49-96	Panel, Dash, L.H.
12	532 14 56-60	Clip Tinnerman Grille P/L
13	532 18 17-19	Panel, Asm. Dash R.H.
15	874 18 05-12	Screw, Machine, Truss Head 5/16-18 UNC x 3/4
16	873 51 05-00	Nut
17	532 16 03-82	Hood Assembly
20	532 18 06-79	Plate Mtg. Battery/Fuel Tank
24	874 78 06-16	Bolt
25	819 13 13-12	Washer 13/32 x 13/16 x 12 Gauge
26	873 80 06-00	Nut
28	532 17 91-00	Grille Lens Asm
29	532 16 81-54	Lens
30	532 18 13-86	Fender
31	532 16 51-56	Bracket, Fender Support
33	532 18 10-57	Footrest, L.H.
34	532 18 10-58	Footrest, R.H.
35	872 11 06-06	Bolt
37	817 49 05-08	Screw Thdrol 5/16-18 x 1/2 TYT
38	532 18 17-48	Bracket Asm Pivot Mower Rear
51	873 80 04-00	Nut Lock w/Insert 1/4-20 UNC
52	819 09 14-16	Washer 9/32 x 7/8 x 16 Ga.
53	532 14 46-97	Bracket Grille Lh
54	532 16 14-64	Screw Hex Wshd 8-18 x 7/8
55	532 14 46-96	Bracket Grille Rh
57	874 78 04-12	Bolt, Fin Hex 1/4-20 UNC x .75

KEY NO.	PART NO.	DESCRIPTION
58	532 15 01-27	Duct Air Engine PI/Lt
69	532 14 24-32	Screw Hex 1/4-1/2
89	532 18 13-60	Console
145	532 15 65-24	Rod Pivot Chassis/Hood
161	532 16 46-55	Bumper Extrusion
162	532 18 03-82	Bracket Exten Chassis Lh CRD
163	532 18 03-83	Bracket Exten Chassis Rh CRD
164	532 16 56-05	Support Battery CRD
165	532 18 13-56	Cover Battery CRD Lt
170	532 17 88-62	Backplate Asm CRD
171	872 14 06-20	Bolt Rdhd Sqnk 3/8-16 x 2-1/2 G5
172	819 13 20-16	Washer 13/32 x 1-1/4 x 16 Ga.
173	873 51 06-00	Nut, Keps Hex 3/8-16 UNC
175	532 18 03-10	Trap Door CRD
179	532 18 03-76	Rod Pivot FBI CRD
184	532 17 46-62	Bracket Actuator Bagger CRD
185	532 18 11-01	Knob Rod
186	532 16 07-93	Latch Asm Multch Bagger
187	532 12 50-04	Nut Weld .327/.304 #10-24
188	819 06 12-16	Washer #10
189	810 07 10-00	Washer Lock #10
190	871 08 10-10	Screw Pan Hd Phillips 10-24 x 5/8
198	532 16 89-37	Nut Push
205	817 49 06-08	Screw 3/8-16 x 1/2
207	817 67 05-08	Screw Thdrol 5/16-18 x 1/2
208	817 67 06-08	Screw Thdrol 3/8-16 x 1/2
209	817 00 06-12	Screw Hex Wsh Thdrol 3/8-16 x 3/4
212	532 15 62-29	Insert Lens Reflective
214	532 12 47-88	Retainer Spring 1"
219	817 00 05-12	Screw 5/16-18 x 3/4
256	532 18 13-61	Cover Fender Rack CRD
--	532 00 54-79	Plug, Button

NOTE: All component dimensions given in U.S. inches.
1 inch = 25.4 mm.

REPAIR PARTS

TRACTOR- -MODEL NO. 145HCRD (P145HCRDD), PRODUCT 954 56 47-26
DRIVE



REPAIR PARTS

TRACTOR- -MODEL NO. 145HCRD (P145HCRDD), PRODUCT 954 56 47-26 DRIVE


KEY NO.	PART NO.	DESCRIPTION
1	-----	Transaxle Hydro Gear 321-0510 (Order parts from transaxle manufacturer)
8	532 1656-19	Rod, Shift Fender Adjust Lt
9	532 1803-54	Clutch Noram
10	876 02 04-16	Pin, Cotter 1/8 x 1
14	810 04 04-00	Washer, Lock Hvy Helical
16	873 80 05-00	Nut, Lock Hex w/Ins 5/16-18 UNC
21	532 1069-33	Knob
22	532 1756-07	Rod, Brake
24	873 35 06-00	Nut
25	532 1068-88	Spring, Rod, Brake
26	819 13 13-16	Washer 13/32 x 13/16 x 16 Ga.
27	876 02 04-12	Pin, Cotter 1/8 x 3/4
28	532 1757-65	Rod, Parking Brake
29	532 07 16-73	Cap, Parking Brake
30	532 1695-92	Bracket, Mfg. Transaxle
34	532 1755-78	Shaft, Asm Pedal Foot CRD
35	532 1201-83	Bearing, Nylon
36	819 21 16-16	Washer 21/32 x 1 x 16 Ga.
37	532 1249-63	Pin, Roll 3/16 x 1"
38	532 1659-36	Pulley Flat Composite 3.06"
39	874 76 06-44	Bolt Fin Hex 3/8-16 Unc x 2-3/4
40	532 1249-65	Spacer, Split 395 x 59 Bzp
42	819 13 13-12	Washer 13/32 x 13/16 x 12 Ga.
43	819 11 10-12	Washer 11/32 x 5/8 x 12 Ga.
47	532 1277-83	Pulley, Idler, V Groove Plasitc
48	532 1544-07	Bellcrank Clutch Grnd Drv
49	532 1232-05	Retainer, Belt Style Spring
51	873 68 06-00	Nut, Crownlock 3/8-16 UNC
52	873 68 05-00	Nut Crownlock 5/16-18
53	532 1057-10	Link, Clutch 7.66
55	532 1057-09	Spring, Return, Clutch
56	817 06 06-20	Screw 3/8-16 x 1-1/4
57	532 1701-40	V-Belt Kev 112" 0650 CRD
62	532 1248-72	Cover, Pedal
65	810 04 07-00	Washer
66	532 1547-78	Keeper, Belt Engine F-Proof
71	532 1691-83	Strap, Torque, Lh
73	532 1691-82	Strap, Torque, Rh
74	532 1370-57	Spacer, Split
75	532 1217-49	Washer 25/32 x 1-1/4 x 16 Ga.
76	812 00 00-01	Ring, E
77	532 1235-83	Key, Square
78	532 1217-48	Washer 25/32 x 1-5/8 x 16 Ga.
81	532 1700-06	Asm, Shaft
82	532 1657-11	Spring, Torsion
83	819 17 12-16	Washer 17/32 x 3/4 x 16 Ga.
84	532 1700-07	Link, Transaxle
95	532 1700-15	Control Asm Bypass Hydro
96	532 1247-88	Spring, Retainer 1"
120	873 90 06-00	Nut Lock Flg. 3/8-16 Unc
145	874 49 05-44	Bolt Hex FGHD 5/16-18 x Gr 5

KEY NO.	PART NO.	DESCRIPTION
150	532 1658-50	Bushing, Bellcrank Grnd Dr
151	819 13 32-10	Washer 13/32 x 2 x 10 Ga.
156	532 1660-02	Washer Srrted 5/16ID x 1.125
158	532 1655-89	Bracket Shift Mount
159	532 1654-94	Hub Tapered Flange Shift Lt
160	819 29 20-16	Washer 29/32 x 1-1/4 x 16 Ga.
161	872 14 04-06	Bolt Rdhd Sqnk 1/4-20 x 3/4 Gr 5
162	873 68 04-00	Nut Crownlock 1/4-20 Unc
163	874 78 04-16	Bolt Hex Fin 1/4-20 Unc x 1 Gr 5
164	819 09 10-10	Washer 5/8 x .281 x 10 Ga.
165	532 1656-23	Bracket Pivot Lever
166	532 1668-80	Screw 5/16-18 x 5/8
167	532 1655-88	Bracket Support Shift CRD
168	532 1654-92	Bolt Shoulder 5/16-18 x .561
169	532 1655-80	Plate Fastening Lt
171	817 49 06-08	Screw Thdrol 3/8-16 x 1/2 Ty-Tt
172	532 1702-71	Shaft Asm Shifter Frt CRD
177	532 1659-32	Keeper Flat Idler 3.06" CRD
178	532 1659-33	Keeper Belt Idler 1.88" CRD
179	532 1209-58	Washer Sintered
180	532 1656-30	Pulley, Idler, Flat 1.88"CRD
181	532 1802-11	Bracket Idler Ground Drive CRD
182	532 1826-82	Keeper Belt 2.5"
183	532 1790-50	Pulley V-Idler 2.50" Od CRD
184	817 49 06-44	Screw Hexwsh Thdrol 3/8-16 x 2-3/4
185	532 1700-08	Link Shift
186	532 1656-14	Hub Tapered Round CRD
187	817 58 05-20	Screw Thdrol 5/16-18 x 1.25
197	532 1696-13	Nyliner Snap-In 5/8
199	532 1696-12	Bolt Shoulder 5/16-18 Unc
200	872 14 05-08	Bolt RDHD SQNK 5/16-18 x 1
203	871 17 07-80	Bolt Hex 7/16-20 x 5
207	532 1698-45	Washer Nylon Rear
214	532 1756-09	Shaft Asm. Brake
215	532 1756-52	Rod Brake Hydro
250	817 07 06-12	Screw 3/8-16 x .75
253	532 1750-28	Bracket Cable Chassis
254	817 06 06-16	Screw 3/8-16 x 1
255	532 1756-08	Brace Shaft Brake Mtg.
258	532 1780-62	Clip Retainer
259	532 1802-12	Bracket Pulley
261	532 13 14-94	Pulley Idler
263	817 06 06-12	Screw Thdrol 3/8-16 x 3/4
264	532 18 19-95	Bracket Clutch Mounting
265	532 1820-13	Spacer Idler Chassis
266	532 1820-61	Shield Idler
267	872 14 06-26	Bolt RDHD SQNK 3/8-16unc x 3-1/4
268	532 1824-02	Guard Muffler

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

REPAIR PARTS

TRACTOR- -MODEL NO. 145HCRD (P145HCRDD), PRODUCT 954 56 47-26
STEERING ASSEMBLY



REPAIR PARTS


TRACTOR- -MODEL NO. 145HCRD (P145HCRDD), PRODUCT 954 56 47-26 STEERING ASSEMBLY

KEY NO.	PART NO.	DESCRIPTION
1	532 13 97-68	Steering Wheel
2	532 17 23-93	Cast Iron Axle Assembly
3	532 16 98-40	Spindle Assembly, L.H.
4	532 16 98-39	Spindle Assembly, R.H.
5	532 12 49-31	Bearing, Race, Thrust, Hardened
6	532 12 17-48	Washer 25/32 x 1-5/8 x 16 Gauge
8	812 00 00-29	Ring, Klip
10	532 17 51-21	Link, Drag
11	810 04 06-00	Washer, Lock
12	873 94 08-00	Nut Hex Jam Toplock 1/2-20 Unf
13	532 13 65-18	Spacer Brg Axle Front
15	532 14 52-12	Nut, Hexflange Lock
17	532 18 06-41	Shaft Assembly, Steering
29	817 06 06-12	Screw, 3/8-16 x 3/4
32	532 17 01-62	Rod, Tie
33	819 11 12-16	Washer 11/32 x 3/4 x 16 Ga
34	810 04 05-00	Washer Lock Hvy Hlcl Spr 5/16
35	873 54 05-00	Nut Crownlock 5/16-24 Unf
36	532 15 50-99	Bushing, Steering
37	532 15 29-27	Screw TT #10-32 x 5 x 3/8 Flange
38	532 14 01-75	Cap Wheel Steer
39	819 18 38-12	Washer 9/16 x 2-3/8
40	532 12 47-01	Nut Lock Center 3/8-24 Unf
41	532 10 07-11	Adaptor, Steering Wheel
42	532 16 96-33	Boot, Steering Dash P/L Mtl
43	532 12 17-49	Washer 25/32 x 1-1/4 x 16 Gauge
44	532 18 06-40	Extension Steering
46	532 12 12-32	Cap, Spindle
51	873 54 04-00	Nut Crownlock 1/4-28
54	871 13 04-20	Bolt Hex 1/4-28unf x 1-1/4 Gr. 8
65	532 16 03-67	Spacer Brace Axle
67	872 14 06-18	Bolt Rdhd Sq 3/8-16 UNC x 2-1/4
71	532 17 51-46	Steering Asm.
68	532 16 98-27	Brace Axle
82	532 16 98-35	Bracket Susp Chassis Front
87	532 17 39-66	Washer Flat .781 x 1-1/2 x .14
88	532 17 51-18	Bolt Shoulder 7/16-20 Unc
91	532 17 55-53	Clip Steering

NOTE: All component dimensions given in U.S. inches.
1 inch = 25.4 mm.

REPAIR PARTS

TRACTOR- -MODEL NO. 145HCRD (P145HCRDD), PRODUCT 954 56 47-26 SEAT ASSEMBLY




KEY NO.	PART NO.	DESCRIPTION
1	532 14 01-18	Seat
2	532 14 05-51	Bracket Pnt Pivot Seat (blk)
3	871 11 06-16	Bolt Fin Hex 3/8-16 Unc x 1
4	819 13 16-10	Washer Flat 13/32 x 1 x 10 Ga.
5	532 14 50-06	Clip Push In Hinged
6	873 80 06-00	Nut Lock Hex 3/8-16 Unc
7	532 12 41-81	Spring Seat Cprsn 2 250 Blk Zi
8	817 00 06-16	Screw 3/8-16 X 1-1/2
9	819 13 16-14	Washer 13/32 X 1 X 14 Ga
10	532 18 24-93	Pan Pnt Seat
11	532 16 63-69	Knob Seat Adj Wingnut
12	532 12 12-46	Bracket Pnt Mounting Switch

KEY NO.	PART NO.	DESCRIPTION
13	532 12 12-48	Bushing Snap Blk Nyl 50 Id
14	872 05 04-12	Bolt Rdhd Sht Nk 1/4-20x1-1/2
15	532 12 12-49	Spacer Split
16	532 12 37-40	Spring Cprsn Plate SW 1.310 Ga
17	532 12 39-76	Nut Lock 1/4 Lge Flg Gr 5 Zinc
21	532 17 18-52	Bolt Shoulder 5/16-18 Unc-2A
22	873 80 05-00	Nut Hex Lock w/Ins 5/16-18
24	819 17 19-12	Washer 17/32 X 1-3/16 X 12 Ga.
25	532 12 70-18	Bolt Shoulder 5/16-18 X 62

NOTE: All component dimensions given in U.S. inches.
1 inch = 25.4 mm

REPAIR PARTS


TRACTOR- -MODEL NO. 145HCRD (P145HCRDD), PRODUCT 954 56 47-26 DECALS



KEY NO.	PART NO.	DESCRIPTION
1	532 14 54-98	Decal Read Owner's Manual Sym
2	532 17 63-96	Decal Hp Engine
3	532 16 71-53	Decal Hood RH
4	532 16 71-54	Decal Hood LH
5	532 14 09-50	Decal Fender Automatic
6	532 18 04-32	Decal 100 DBA
7	532 14 09-87	Decal Fender
8	532 14 69-98	Decal Steering Wheel
10	532 14 50-05	Decal Bat Dan/Poi P/L Sym Wpn

KEY NO.	PART NO.	DESCRIPTION
11	532 18 21-66	Decal Mower Cut Finger
12	532 15 97-37	Decal Brake/Clutch Symbol Lt
14	532 15 97-36	Decal Chassis Hot Muffler
17	532 14 08-37	Decal Saddle Brake Parking
18	532 13 75-88	Decal Chas Turbo
21	532 16 62-86	Decal Hex Belt Sch
—	532 16 69-60	Decal Bypass Fender CRD
—	532 13 83-11	Decal Lift Handle
—	532 18 10-90	Pad Footrest RH
—	532 18 01-91	Pad Footrest LH
—	532 18 39-59	Manual Operator's (Euro)
—	532 18 39-60	Manual Operator's (Scan)

WHEELS & TIRES




KEY NO.	PART NO.	DESCRIPTION
1	532 05 91-92	Cap Value Tire
2	532 06 51-39	Stem Value
3	532 10 62-22	Tire F Ts 15 X 6 0 - 6 Service
4	532 05 99-04	Tube Inner Front #35060
5	532 12 51-21	Rim Asm 6" front Service
6	532 12 49-57	Fitting Grease
7	532 12 49-59	Bearing Flange
8	532 12 51-22	Rim Asm 8" rear Service
9	532 13 84-68	Tire R Ts 20 x 8-8 Service
10	532 12 49-26	Tube Rear 9 5 X 8 Service
11	532 17 50-39	Cap Axle Blk 1 50 X 1 00
--	532 14 43-34	Sealant, Tire (10 oz. tube)

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

REPAIR PARTS

TRACTOR- -MODEL NO. 145HCRD (P145HCRDD), PRODUCT 954 56 47-26
ENGINE



OPTIONAL EQUIPMENT
Spark Arrester

REPAIR PARTS


TRACTOR- -MODEL NO. 145HCRD (P145HCRDD), PRODUCT 954 56 47-26
ENGINE

KEY NO.	PART NO.	DESCRIPTION
1	532 17 05-51	Control Throt Flag
2	817 72 04-08	Screw Hex Thd Cut 1/4-20x1/2
3	-----	Engine B&S Model 287707 (Order Parts from Engine Manufacturer)
4	532 13 73-52	Muffler Exhaust
13	532 16 52-91	Gasket Muffler
14	532 14 84-56	Tube Drain Oil Easy
16	811 05 06-00	Washer Lock Ext Tooth 3/8
23	532 16 98-37	Shield BRN/DBR Guard
25	532 18 09-45	Control Choke
26	873 92 06-00	Nut Keps 3/8-24 Unf
29	532 13 71-80	Arrestor Spark
31	532 18 06-45	Tank Fuel Front 2.00 Gal.
32	532 14 05-27	Cap Fuel Asm Top Vent
33	532 12 34-87	Clamp Hose Blk
37	532 13 70-40	Line Fuel
38	532 14 83-15	Plug Drain Oil Easy
40	532 12 40-28	Bushing Snap
41	532 13 92-77	Stem Tank Fuel
44	817 67 04-12	Screw Hexwsh Thdrol 1/4-20 x 3/4
45	817 00 06-12	Screw 3/8-16 x 3/4
46	819 09 14-16	Washer 9/32 X 7/8 X 16ga
62	810 04 05-00	Washer Lock Hvy HLCL Spr 5/16
72	871 07 05-12	Screw Hex HD Cap 5/16-18 x 3/4
78	817 06 06-20	Screw 3/8-16 x 1-1/4
81	873 51 04-00	Nut Keps 1/4-20 UNC
112	532 12 49-52	Bushing

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

REPAIR PARTS

TRACTOR- -MODEL NO. 145HCRD (P145HCRDD), PRODUCT 954 56 47-26
MOWER LIFT



REPAIR PARTS

TRACTOR- -MODEL NO. 145HCRD (P145HCRDD), PRODUCT 954 56 47-26
MOWER LIFT


KEY NO.	PART NO.	DESCRIPTION
1	532 15 94-60	Washer Asm Inner Spring W/Plunger
2	532 15 94-71	Shaft Asm. Lift
3	532 10 57-67	Pin Groove
4	812 00 00-02	E Ring #5133-62
5	819 21 16-21	Washer 21/32 x 1 x 21 Ga.
6	532 12 01-83	Bearing Nylon
7	532 10 94-13	Grip Handle Bicycle
8	532 12 45-26	Button Plunger Black
11	532 16 58-29	Link Asm Lift L.H.
12	532 16 58-31	Link Asm Lift R.H.
13	532 12 46-70	Retainer Spring
15	532 17 32-88	Link Front
16	873 35 08-00	Nut Jam Hex 1/2-13 Unc
17	532 17 56-89	Trunnion
18	873 80 08-00	Nut Lock w/Wsh 1/2-13 Unc
19	532 13 98-68	Arm Suspension Mower
20	532 16 35-52	Retainer Spring
31	532 16 98-65	Bearing, Pvt. Lift
32	873 54 06-00	Nut Crownlock 3/8-24

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm



REPAIR PARTS

TRACTOR- -MODEL NO. 145HCRD (P145HCRDD), PRODUCT 954 56 47-26
MOWER



REPAIR PARTS

TRACTOR- -MODEL NO. 145HCRD (P145HCRDD), PRODUCT 954 56 47-26
MOWER


KEY NO.	PART NO.	DESCRIPTION
1	532 1691-60	Housing Asm. Mower
2	872 1405-06	Bolt Rdhd Sqnk 5/16-18 Unc x 3/4
3	532 1655-69	Bracket Asm. S-Bar Chass
4	532 1691-67	Bracket Bar Sway Deck
5	532 1246-70	Retainer Spring
6	532 1655-57	Bar Sway
8	532 1817-13	Bolt 3/8-24 x 1.25 Gr8 Patched
9	810 0306-00	Washer Lock Hvy 3/8 Unplated
11	532 1805-83	Blade 3-1 Lh
13	532 1376-45	Shaft Asm. W/Lower Bearing
14	532 1287-74	Housing Mandrel Vented (Machd)
15	532 1104-85	Bearing Ball Mandrel
16	532 1805-84	Blade 3-1 Rh
19	532 1328-27	Bolt Shoulder 5/16-18 Thd Form
20	532 1817-12	Bolt 3/8-24 x 1.25 Gr8 Ptch Lhthd
21	873 6805-00	Nut Crown Lock 5/16-18
22	532 1691-65	Bracket Idler RR
23	532 1691-66	Bracket Idler RF
24	532 1691-70	Bracket Suspension LF
25	532 1691-71	Bracket Suspension RF
26	532 1652-37	Brace Support Susp Frt CRD
27	532 1691-72	Bracket Asm. Susp RR
28	532 1691-68	Bracket Asm. Susp LR
30	532 1739-84	Screw Thd Rolling
31	532 1299-63	Washer Spacer Mower Vented
32	532 1757-07	Mandrel Pulleys
33	532 1783-42	Nut Flg Top Lock
34	532 1795-09	Bracket Gauge Wheel Lf
35	532 1762-92	Bracket Gauge Wheel Rf
36	532 1467-63	Pulley Idler V-Groove Dim 4.25
37	819 1313-16	Washer 11/32 x 13/16 x 16 Ga
38	532 1698-51	Spacer Hub Arm Idler 107 CRD
39	872 1106-22	Bolt Rdhd 3/8-16 Unc x 2-3/4 Gr. 5
40	873 6806-00	Nut Crownlock 3/8-16 Unc
41	873 9006-00	Nut Lock Flg. 3/8-16 Unc

KEY NO.	PART NO.	DESCRIPTION
44	532 1755-38	Cover Mandrel Lh
45	532 1755-39	Cover Mandrel Rh
46	532 1377-29	Screw Thd Roll 1/4-20 x 5/8
55	532 1698-49	Arm Idler 107 CRD
61	532 1751-59	Spring Tension Belt
67	532 1069-32	Knob Rd 3/8-16 Plstc Thds Blk
68	532 1691-78	Hex-Belt Mower
69	532 1654-82	Shaft Asm W/Lwr Brg Rh Thd CRD
84	532 1560-85	Keeper Belt Idler
116	532 1376-44	Bolt Shoulder
117	532 1339-57	Wheel Gage Donut Wide
118	873 9306-00	Nut Centerlock 3/8-16 Unc
119	819 1214-14	Washer 3/8 x 7/8 x 14 Ga.
124	872 1106-12	Bolt Carr Sh 3/8-16 x 1-1/2 Gr5
130	872 1105-06	Bolt Rdhdsqnk 5/16-18 Unc x 3/4
131	532 1656-61	Chute Bagger CRD 92cm
151	532 1696-70	Bracket Clutch Cable
152	532 1760-74	Cable Clutch CRD Service
153	532 1696-74	Washer Flat 3/8" Type B
154	532 1696-75	Spring Retainer
155	532 1696-71	Spring Retainer Lvr Cltch Cab
156	532 1696-72	Spacer Clutch Cable
157	532 1696-69	Rod Clutch Cable 3/8"
158	817 7204-08	Screw Hex Thdcut 1/4-20 x 1/2
161	532 1804-24	Blade Cross LH
162	532 1808-78	Adapter Weldment Blade
163	532 1804-25	Blade Cross RH
-	532 1818-57	Mandrel Asm Service
-	532 1818-58	Mandrel Asm CRD Lh Threads SVC
-	532 1817-70	Deck Mower Complete

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

REPAIR PARTS

TRACTOR- -MODEL NO. 145HCRD (P145HCRDD), PRODUCT 954 56 47-26
BAGGER



REPAIR PARTS

TRACTOR- -MODEL NO. 145HCRD (P145HCRDD), PRODUCT 954 56 47-26
BAGGER

KEY NO.	PART NO.	DESCRIPTION
1	532 16 52-49	Tube Handle Bagger CRD
2	872 14 04-16	Bolt Carriage 1/4-20 X 2.0 Gr.5
3	532 12 39-76	Nut Lock 1/4 Lge Flg Gr. 5 Zinc
4	532 16 99-16	Handle Bagger w/Lvrs Gr. 5 Zinc
5	874 98 10-24	Screw Pan Head #10-24 X 1.50 Blk
6	874 98 10-32	Screw Pan Hd
7	873 40 10-00	Nut Wiz Lock Hex Serr/Hd #10-24
8	532 16 99-63	Cover Bagger
9	872 14 04-18	Bolt Carriage 1/4-20 x 2.25d x Gr.5
10	532 18 12-82	Tube Support Bagger CRD
11	532 16 57-19	Bracket Support Upper Bag CRD
12	532 16 96-85	Bracket Horiz. Adj Bagger
13	872 11 06-06	Bolt Rdhd Sht Sqnk 3/8-16 X 3/4
14	874 52 06-36	Bolt Hex 3/8-16 X 2-1/4 Gr. 5
16	873 90 06-00	Nut Lock Flg 3/8-16 Unc
17	872 14 05-06	Bolt Rdhd Sht Sqnk 5/16-18Unc X 3/4
18	819 11 12-16	Washer 11/32 x 3/4 x 16
19	873 90 05-00	Nut Lock Hex Flange 5/16-18
20	532 16 96-84	Bracket Horiz Adj Bagger
21	532 18 08-80	Bag Asm CRD
22	532 16 57-81	Bracket Side Bagger CRD
23	532 16 57-82	Tube Upper Bagger CRD
24	532 16 57-83	Tube Pivot Bagger CRD
25	532 18 01-24	Tube Front Bagger CRD
26	532 16 57-85	Tube Lower Bagger CRD
28	532 16 57-87	Grip Handle Black
31	532 12 47-88	Retainer Spring 1" Zinc/Cad
32	532 12 68-75	Rivet Rd Hd Drilled 3/8 Dia
36	819 13 20-16	Washer 13/32 x 1-1/4 x 16 Ga.
37	532 17 54-01	Plug Support Bagger CRD
38	872 01 05-20	Bolt 5/16-18 x 2-1/2
39	532 18 09-85	Seal
41	532 16 96-83	Bracket Vert Adj Bagger CRD
42	873 80 05-00	Nut Lock Hex W/Ins 5/16-18 UNC
43	532 17 40-83	Plug Tubing

NOTE: All component dimensions given in U.S. inches
1 inch = 25.4 mm

TRACTOR- -MODEL NO. 145HCRD (P145HCRDD), PRODUCT 954 56 47-26

SCHEMATIC

