

1  
1989


10

**PARTNER<sup>(R)</sup>**

**550/650**


**A**

\* compl 503 15 72-01  
① compl 503 15 73-01




**B**





\* compl 503 15 68-01




**C**



\*\* compl 505 34 12-80 (550) \* compl 505 34 12-81 (650)


**D****F****\*compl 503 15 65-01****E****G 'compl 503 15 80-01**


**H**



**\*compl 503 15 66-01**


**J**






\*compl 503 15 49-01

**L**




## M




②503 08 84-01 Packningssats  
Set of gaskets  
Dichtungssatz  
Jeu de joints  
Juego de junta

## N

Tillbehör  
Accessories  
Zubehöre  
Accessoires  
Accesorios



505 26 21-30



503 41 75-01



505 38 13-07



503 24 06-02



501 60 02-02



501 69 17-01

| Ref.-No.<br>Teil-Nr.<br>N° de réf.<br>N° ref.<br>Ref. nr. | Square<br>Viereck<br>Carreau<br>Cuadro<br>Ruta | Remark<br>Vermerk<br>Notes<br>Observ.<br>Anm. | Ref.-No.<br>Teil-Nr.<br>N° de réf.<br>N° ref.<br>Ref. nr. | Square<br>Viereck<br>Carreau<br>Cuadro<br>Ruta | Remark<br>Vermerk<br>Notes<br>Observ.<br>Anm. | Ref.-Nr<br>Teil-Nr.<br>N° de réf.<br>N° ref.<br>Ref. nr. | Square<br>Viereck<br>Carreau<br>Cuadro<br>Ruta | Remark<br>Vermerk<br>Notes<br>Observ.<br>Anm. |
|-----------------------------------------------------------|------------------------------------------------|-----------------------------------------------|-----------------------------------------------------------|------------------------------------------------|-----------------------------------------------|----------------------------------------------------------|------------------------------------------------|-----------------------------------------------|
| 501 46 84-01                                              | M                                              |                                               | 503 22 21-02                                              | K                                              |                                               | 505 27 92-16                                             | D                                              |                                               |
| 501 46 87-01                                              | M                                              |                                               | 503 22 65-01                                              | A, E                                           |                                               | 505 27 95-11                                             | E                                              |                                               |
| 501 48 54-02                                              | K                                              |                                               | 503 22 70-01                                              | B, D                                           |                                               | 505 27 95-12                                             | E                                              |                                               |
| 501 48 56-01                                              | K                                              |                                               | 503 23 00-11                                              | E                                              |                                               | 505 29 31-30                                             | H                                              |                                               |
| 501 60 02-02                                              | N                                              |                                               | 503 23 00-30                                              | E                                              |                                               | 505 29 31-62                                             | A                                              |                                               |
| 501 66 61-01                                              | M                                              | (N)                                           | 503 23 00-36                                              | H                                              |                                               | 505 29 41-25                                             | H                                              |                                               |
| 501 69 17-01                                              | N                                              |                                               | 503 23 01-01                                              | K                                              |                                               | 505 29 51-10                                             | L                                              |                                               |
| 501 76 83-01                                              | J                                              |                                               | 503 23 11-01                                              | H                                              |                                               | 505 29 56-13                                             | K                                              |                                               |
| 501 76 83-13                                              | J                                              |                                               | 503 23 51-08                                              | C, K                                           |                                               | 505 29 56-14                                             | E                                              |                                               |
| 501 82 58-01                                              | J                                              |                                               | 503 23 96-02                                              | D                                              |                                               | 505 29 79-17                                             | L                                              |                                               |
| 501 87 76-01                                              | J                                              |                                               | 503 24 06-02                                              | N                                              |                                               | 505 30 23-30                                             | H                                              |                                               |
| 502 10 31-01                                              | M                                              |                                               | 503 25 00-01                                              | G                                              |                                               | 505 30 23-33                                             | C, G                                           |                                               |
| 503 08 84-01                                              | M                                              |                                               | 503 26 30-09                                              | H                                              |                                               | 505 30 32-45                                             | H                                              |                                               |
| 503 10 19-01                                              | A                                              |                                               | 503 31 67-02                                              | M                                              |                                               | 505 30 36-63                                             | H                                              |                                               |
| 503 10 87-01                                              | M                                              |                                               | 503 40 00-01                                              | E                                              |                                               | 505 30 51-20                                             | L                                              |                                               |
| 503 11 67-01                                              | M                                              |                                               | 503 40 17-01                                              | E                                              |                                               | 505 31 07-70                                             | J                                              |                                               |
| 503 11 68-01                                              | M                                              |                                               | 503 40 18-01                                              | E                                              |                                               | 505 31 22-27                                             | J                                              |                                               |
| 503 11 69-01                                              | M                                              |                                               | 503 40 23-01                                              | D                                              |                                               | 505 31 54-75                                             | D                                              |                                               |
| 503 11 70-01                                              | M                                              |                                               | 503 40 41-01                                              | M                                              |                                               | 505 31 67-07                                             | M                                              |                                               |
| 503 11 71-01                                              | M                                              |                                               | 503 40 43-01                                              | M                                              |                                               | 505 31 67-17                                             | M                                              |                                               |
| 503 11 75-01                                              | M                                              |                                               | 503 41 18-01                                              | E                                              |                                               | 505 31 67-20                                             | M                                              |                                               |
| 503 11 76-01                                              | M                                              |                                               | 503 41 75-01                                              | N                                              |                                               | 505 31 67-21                                             | M                                              |                                               |
| 503 11 77-01                                              | M                                              |                                               | 503 44 22-01                                              | E                                              |                                               | 505 31 67-31                                             | M                                              |                                               |
| 503 11 78-01                                              | M                                              |                                               | 503 44 25-01                                              | J                                              |                                               | 505 31 67-34                                             | M                                              |                                               |
| 503 11 79-01                                              | M                                              |                                               | 503 44 31-01                                              | J                                              |                                               | 505 31 67-92                                             | M                                              |                                               |
| 503 11 80-01                                              | M                                              |                                               | 503 44 32-01                                              | H                                              | (N)                                           | 505 31 71-64                                             | H                                              |                                               |
| 503 12 15-02                                              | B                                              |                                               | 503 45 40-01                                              | C                                              |                                               | 505 31 71-77                                             | H                                              |                                               |
| 503 12 25-01                                              | M                                              |                                               | 503 45 65-01                                              | E                                              |                                               | 505 31 72-20                                             | H                                              |                                               |
| 503 12 61-01                                              | A                                              |                                               | 503 45 96-01                                              | A                                              |                                               | 505 31 72-31                                             | H, J                                           |                                               |
| 503 12 79-01                                              | L                                              | (N)                                           | 503 49 08-01                                              | D                                              |                                               | 505 31 83-53                                             | J                                              |                                               |
| 503 15 49-01                                              | L                                              |                                               | 503 49 09-01                                              | D                                              |                                               | 505 32 01-79                                             | K                                              |                                               |
| 503 15 50-01                                              | L                                              |                                               | 503 49 11-01                                              | C                                              |                                               | 505 32 01-92                                             | K                                              |                                               |
| 503 15 53-01                                              | E                                              |                                               | 503 57 41-01                                              | M                                              | (N)                                           | 505 32 56-24                                             | K                                              |                                               |
| 503 15 54-01                                              | E                                              |                                               | 503 59 58-01                                              | M                                              | (N)                                           | 505 34 07-77                                             | C                                              |                                               |
| 503 15 56-01                                              | E                                              |                                               | 504 14 00-08                                              | M                                              |                                               | 505 34 09-20                                             | K                                              |                                               |
| 503 15 57-01                                              | E                                              |                                               | 504 21 00-50                                              | M                                              |                                               | 505 34 12-80                                             | C                                              |                                               |
| 503 15 59-01                                              | E                                              |                                               | 504 30 24-10                                              | J                                              |                                               | 505 34 12-81                                             | C                                              |                                               |
| 503 15 63-01                                              | E                                              |                                               | 504 35 72-01                                              | J                                              |                                               | 505 35 03-94                                             | F                                              |                                               |
| 503 15 64-01                                              | F                                              |                                               | 505 22 09-14                                              | J                                              |                                               | 505 35 03-95                                             | F                                              |                                               |
| 503 15 65-01                                              | F                                              |                                               | 505 23 09-02                                              | A                                              |                                               | 505 38 13-07                                             | N                                              |                                               |
| 503 15 66-01                                              | J                                              |                                               | 505 24 49-26                                              | D                                              |                                               | 506 02 72-01                                             | K                                              |                                               |
| 503 15 67-01                                              | J                                              |                                               | 505 26 02-20                                              | A                                              |                                               | 506 02 83-01                                             | M                                              |                                               |
| 503 15 68-01                                              | B                                              |                                               | 505 26 21-30                                              | N                                              |                                               | 506 03 48-01                                             | M                                              |                                               |
| 503 15 72-01                                              | A                                              |                                               | 505 26 21-34                                              | L                                              |                                               | 506 05 57-02                                             | D, M                                           | (N)                                           |
| 503 15 73-01                                              | A                                              |                                               | 505 26 58-14                                              | C                                              |                                               | 506 07 14-01                                             | L                                              |                                               |
| 503 15 75-01                                              | A                                              |                                               | 505 26 60-48                                              | C                                              |                                               | 506 07 71-01                                             | C                                              |                                               |
| 503 15 80-01                                              | G                                              |                                               | 505 26 60-65                                              | C                                              |                                               | 720 13 07-00                                             | J                                              |                                               |
| 503 15 85-01                                              | B                                              |                                               | 505 26 72-61                                              | H                                              |                                               | 721 42 58-20                                             | E                                              |                                               |
| 503 16 03-01                                              | L                                              |                                               | 505 26 76-50                                              | A                                              |                                               | 721 43 03-00                                             | A                                              |                                               |
| 503 16 33-01                                              | B                                              |                                               | 505 26 76-73                                              | E                                              |                                               | 721 43 12-00                                             | A                                              |                                               |
| 503 16 40-01                                              | J                                              |                                               | 505 26 77-47                                              | E                                              |                                               | 721 43 79-50                                             | A                                              |                                               |
| 503 17 99-01                                              | E                                              |                                               | 505 26 83-03                                              | N                                              |                                               | 721 61 38-00                                             | J                                              |                                               |
| 503 20 00-01                                              | E, K                                           |                                               | 505 26 91-06                                              | L                                              |                                               | 723 12 97-51                                             | K                                              |                                               |
| 503 20 00-03                                              | A                                              |                                               | 505 26 91-28                                              | J                                              |                                               | 723 13 67-51                                             | H                                              |                                               |
| 503 20 00-05                                              | C, F                                           |                                               | 505 26 91-29                                              | A                                              |                                               | 729 22 75-05                                             | L                                              | (N)                                           |
| 503 20 00-07                                              | J                                              |                                               | 505 26 91-72                                              | H                                              |                                               | 729 57 13-01                                             | E                                              |                                               |
| 503 20 00-08                                              | E, J                                           |                                               | 505 26 93-00                                              | A                                              |                                               | 731 23 10-01                                             | L                                              |                                               |
| 503 20 00-09                                              | F                                              |                                               | 505 26 93-04                                              | A                                              |                                               | 732 21 14-01                                             | E                                              |                                               |
| 503 20 00-10                                              | E                                              |                                               | 505 26 93-10                                              | A                                              |                                               | 734 11 46-01                                             | L                                              | (N)                                           |
| 503 20 00-16                                              | E                                              |                                               | 505 26 94-29                                              | E                                              |                                               | 735 31 09-20                                             | A                                              |                                               |
| 503 20 00-21                                              | K                                              |                                               | 505 27 21-25                                              | D                                              |                                               | 735 58 18-00                                             | E                                              |                                               |
| 503 20 00-28                                              | E                                              |                                               | 505 27 57-15                                              | J                                              |                                               | 735 88 06-00                                             | G                                              |                                               |
| 503 20 00-34                                              | E                                              |                                               | 505 27 72-30                                              | J                                              |                                               | 740 42 02-00                                             | H                                              |                                               |
| 503 20 31-01                                              | L                                              |                                               | 505 27 75-16                                              | K                                              |                                               | 740 42 06-00                                             | H                                              |                                               |
| 503 20 86-01                                              | B                                              |                                               | 505 27 75-76                                              | J                                              |                                               | 740 42 09-00                                             | H                                              |                                               |
| 503 21 11-02                                              | L                                              |                                               | 505 27 91-06                                              | D                                              |                                               | 740 44 05-00                                             | J                                              |                                               |
| 503 21 11-03                                              | F                                              |                                               | 505 27 95-13                                              | E                                              |                                               | 740 48 18-04                                             | J                                              |                                               |
| 503 22 00-01                                              | A                                              |                                               | 505 27 75-66                                              | K                                              |                                               |                                                          |                                                |                                               |

☐ 505 27 99-27  
 Packningssats  
 Set of gaskets  
 Dichtungssatz  
 Jeu de joints  
 Juego de junta

(N) New part  
 Neues Teil  
 Nouvelle piece  
 Nueva pieza  
 Ny detalj