


PARTS LIST NO. 67113-9/25/87		PARTNER® PARTS LIST	CHAIN SAW MODEL: PC 335
PAGE 1 of 3	REPLACES NONE		

NOTE: Illustrations may differ from actual models due to design changes.

⚠ WARNING
All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by qualified service personnel.



KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION			
1	530 01 54-45	Nut - Bar Mounting	20	530 02 21-72	Crankshaft - Solid State	37	530 01 05-87	Piston Kit (Incl. 28, 45 & Pin)	61	530 01 04-74	Connecting Rod Ass'y. Kit (Incl. 58 & 59)			
2	—	Bar Clamp (See p.3 #9)	21	530 02 10-26	Line - Oil Discharge	43	530 00 16-66	Screw - #10 - 24 x 1/2	62	530 01 54-74	Screw - Muffler Shield - Front - #10 - 24 x 1/2			
3	530 01 51-35	Lock Nut #8 - 32	22	530 06 91-93	Clutch Ass'y. Kit (Incl. washer)	44	*530 01 91-39	Gasket - Cylinder	63	530 02 52-59	Muffler Shield			
4	530 02 34-92	Pin - Bar Adjust	23	530 06 91-97	Clutch Washer Kit (Outside)	45	530 02 58-75	Piston Ring	64	530 01 54-63	Screw - Muffler Shield - Rear - #10 - 14 x 9/16			
5	530 01 52-36	Screw Bar Adjust	24	530 04 43-10	Guide Bar	46	530 02 37-88	Knob Ass'y. Switch	66	530 01 53-33	Screw - Hex - 8 - 24 x 7/16			
6	530 02 37-92	Pin - Oil Tank Vent			12" —	47	530 02 37-86	Ramp Switch	67	530 02 42-01	Shield - Heat			
7	530 01 56-42	Stud - Bar Mounting		530 04 43-01	14" —	48	530 01 52-38	Screw #10 - 24 x 11/16	68	530 01 53-31	Spacer - Cover			
8	530 01 04-69	Crankcase Assembly (Incl. #3, 7, 10, 11 & 18)	25	—	Chain	49	530 02 37-97	Baffle - Muffler	69	530 02 42-02	Cover - Muffler			
9	530 01 56-23	Screw #10 - 24 x 1 Soc. Hd.		952 05 11-92	12" (P91SG-45)	50	530 02 37-94	Body - Muffler	70	530 01 53-32	Lock Nut - 8 - 32			
10	530 06 91-42	Check Valve Kit - Oil Tank Pressure (Incl. #12)		530 05 11-94	14" (P91SG-52)	51	530 02 37-87	Clamp - Switch	71	530 06 90-34	Kit - Heat Shield			
			26	530 01 54-64	Screw #10 - 24 x 1 x 7/16	52	530 01 52-35	Sealant - Crankcase (Optional)	DECALS A 530 02 75-74 B 530 02 75-73 NOT SHOWN 530 06 70-26					
11	*530 01 90-59	Seal - Crankshaft	27	530 02 52-63	Cover - Muffler	53	530 03 00-54	Bar Adjusting Tool						
12	*530 01 90-89	Gasket - Check Valve	28	530 02 38-43	Retainer - Piston Pin	54	530 03 10-63	Spark Plug RCJ-8	DECAL - Bar Clamp DECAL - Hearing Protection					
13	530 01 51-76	Screw - #8 - 32 x 1/2	30	530 02 38-87	Thrust Washer - Crankshaft	55	530 03 00-58	Cylinder						
14	530 02 38-02	Cover - Metering Body	31	530 01 02-21	Oil Cap Ass'y. (Incl. O-Ring)	56	530 01 21-40	Screw - 1/4 - 20 x 3/4 Socket	Operator's Manual					
15	*530 01 90-91	Gasket - Metering Body			Clutch Drum	57	530 01 52-39	Washer - Rod (Top)						
16	*530 02 38-01	Filter Oil	32	530 06 91-66	Bearing - Clutch	58	530 01 54-86	Bearing Rod (Top - Incl. 22 bearings)						
17	530 01 01-95	Ass'y. - Metering Body	33	530 03 20-79	Spacer - Clutch (Inside)	59	530 03 20-75	Chain Repair Kit (Optional)						
18	530 03 20-58	Bearing - Crankshaft	34	530 02 35-19	Spacer - Muffler Cover									
19	530 03 20-65	Bearing - Roller (Incl. 12 bearings)	35	530 02 52-62	Screen - Spark Arrestor	60	530 05 20-73							
			36	530 02 37-96										


* = Part Change
= New Part No.

*Indicates Contents of Engine Gasket Kit, Key No. 85, Page 2.

503.23 5011/7

PARTS LIST NO. 67113-9/25/87		PARTNER® PARTS LIST	CHAIN SAW MODEL: PC 335
PAGE 2 of 3	REPLACES NONE		

NOTE: Illustrations may differ from actual models due to design changes.



KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	530 03 91-11	Flywheel Assembly (Incl. #8)	24	530 02 56-79	Bracket - Upper Isolator	53	530 01 07-29	Fuel Cap Ass'y. (Incl. O-Ring)	70	530 01 54-99	Screw - Handlebar Mtg. - Top (#14 - 10 x 1-3/4)
2	530 01 51-26	Key - Flywheel	25	530 02 43-17	Pad - Isolator	54	530 02 67-35	Handle Starter	71	530 01 51-49	Washer Handlebar
3	530 00 39-34	Boot - Spark Plug	26	530 03 51-81	Carburetor - See Page 3	55	*530 01 90-93	Seal - Fuel Tank Neck	72	530 01 51-29	Screw - #8 - 32 x 7/16
4	530 00 39-33	Connector - Spark Plug	27	530 02 37-81	Air Filter	56	530 01 07-75	Fuel Tank Ass'y. (Incl. #44, 48, 53 & 55)	73	530 02 56-82	Rear Handle - Right
5	530 03 91-16	Lead Switch	28	530 01 52-42	Screw - 1/4 - 20 x 11/16	57	530 02 56-85	Wire - Throttle	74	530 02 56-84	Lever - Throttle Lockout
6	530 06 92-02	Module - Ignition (Incl. #5 & 15)	29	*530 01 90-45	Gasket - Carburetor	58	530 01 55-51	Screw - Isolator (#1-1/4 - 20 x 2 3/16)	75	530 02 56-81	Rear Handle - Left
7	530 01 51-28	Screw - #8 - 32 x 3/4 Sems	30	530 02 54-87	Baffle - Air Intake	59	530 01 56-50	Screw - #10 - 24 x 5/8	76	530 01 54-95	Screw - Rear Handle (#10 - 16 x 3/4)
8	530 02 38-17	Spring - Starter Dog	31	530 00 17-26	Fan Housing	60	530 01 56-49	Socket Head Sems	77	530 02 56-78	Spacer
9	530 02 56-91	Knob Choke	32	530 01 20-60	Screw - #10 - 24 x 1-5/8	61	530 01 55-15	Socket Head	78	530 02 56-75	Handlebar w/insert
10	530 02 56-76	Cover - Carburetor	33	530 01 52-45	Spacer - Choke	62	530 02 56-89	Locknut - Handlebar Mtg. (#1/4 - 20)	79	530 01 55-31	Washer - Handlebar Lower (1/4)
11	530 01 51-68	Screw - #10 - 24 x 5/8	34	530 02 38-65	Wave Washer	63	530 01 51-23	Bracket - Lower Isolator	80	530 01 53-43	Spacer
12	530 01 51-47	Wave Washer	35	530 01 52-54	Shutter - Choke	64	530 01 55-57	Washer - Lower Bracket Mtg. (#10)	81	530 06 91-99	Kit - Fan Hsg. Screws (Incl. #59 & 60, this page & #9 on page 1)
13	530 02 38-06	Lever - Choke	36	530 02 38-05	Housing - Carburetor	65	530 02 56-86	Screw - Bracket Mounting (10 - 24 x 5/8)	82	530 02 56-92	Lower Brace
14	530 01 54-07	Screw - #8 - 16 x 3/8 Tapping	37	530 02 59-78	Gasket - Carburetor Housing	66	530 02 56-87	Spring Trigger	83	530 01 56-53	Nut-Lock
15	530 03 90-82	Lead Spark Plug	38	*530 01 91-18	Reed Valve	67	530 01 54-26	Spring - Throttle	84	530 01 53-05	Screw 10 - 24 x 1-3/16
16	530 02 66-05	Nut - 5/16 - 24	39	530 02 33-66	Washer - Reed Valve	68	530 02 76-87	Locknut Lever	85	530 06 90-22	Engine Gasket Kit (*Includes Contents)
17	530 01 51-27	Washer - Flywheel	40	530 02 33-67	Screw - #6 x 5/16 Tapping	69	530 01 55-33	Bolt - 1/4 - #20 x 1/2			
18	530 01 50-36	Screw - #10 x 24 x 1/2	41	530 01 52-41	Spacer			Bracket - Rear Isolator			
19	530 01 51-23	Washer	42	530 01 53-42	Cup - Isolator			Screw - Rear Handle Front (#10 - 16 x 1-1/8)			
20	530 06 92-00	Kit Pulley Replacement (Incl. #19, 49 & 54)	43	530 02 61-63	Fuel Line (Bulk no. 8133)						
21	530 04 20-23	Spring - Starter	44	530 02 10-35	Boot - Throttle Wire						
22	530 01 55-24	Screw - Isolator (#14 - 20 x 1-11/16)	45	*530 02 33-73	Isolator						
23	530 00 16-48	Screw - 14 - 20 x 1-1/4 Hex Head	46	530 02 42-56	Fuel Pick-up Ass'y.						
			47	530 02 42-56	Rope Kit						
			48	530 09 18-78	Washer - Trigger (nylon)						
			49	530 06 92-32	Trigger - Throttle						
			50	530 01 55-28							
			51	530 02 56-83							
			52								

✓ = Part Change
◇ = New Part No.


*Indicates Contents of Engine Gasket Kit, Key No. 85, this page.

PARTS LIST NO. 67113-9/25/87		PARTNER® PARTS LIST	CHAIN SAW MODEL: PC 335
PAGE 3 of 3	REPLACES NONE		

NOTE: Illustrations may differ from actual models due to design changes.


A. Carburetor Assembly #530 03 51-81

KEY NO.	PART NO.	DESCRIPTION
1	505 52 01-08	Valve Throttle
2	530 03 50-15	Screw - Throttle Valve
3	530 03 50-34	Shaft Assembly - Throttle
4	530 03 51-71	Needle - Low Speed Mixture
5	505 31 67-45	Spring - Throttle Return
6	501 46 73-01	Spring - Low Speed Mixture Needle
7	530 03 51-67	Spring - High Speed Mixture Needle
8	530 03 51-69	Needle - High Speed Mixture
9	504 10 00-11	*Plug - 5/16 Dia. Welch
10	504 10 00-12	*Plug - 1/4 Dia. Welch
11	501 46 99-01	Screw - Pump Cover
12	530 03 51-59	Cover - Fuel Pump
13	504 13 09-06	†*Gasket - Fuel Pump
14	504 13 08-01	†*Diaphragm - Fuel Pump
15	501 31 67-64	*Screen - Fuel Inlet
16	505 31 67-16	Screw - Idle Speed Adjusting
17	530 03 51-68	Spring - Idle Speed Adjusting Screw
18	502 11 98-01	Ring - Throttle Retainer
19	501 46 67-01	*Valve - Inlet Needle
20	503 57 20-01	*Spring - Metering Lever
21	505 52 01-27	*Lever - Metering
22	505 52 01-25	*Pin - Metering Lever
23	505 31 67-17	*Screw - Metering Lever Pin
24	504 35 09-06	†*Gasket - Metering Diaphragm
25	504 13 08-08	†*Diaphragm - Metering
26	505 31 67-54	Cover - Metering Diaphragm
27	501 46 88-01	Screw Assembly - Metering Cover
28	530 03 51-61	Kit - Carb. Repair (Includes parts marked *)
29	502 10 35-01	Kit - Carb. Gasket/Diaphragm (Includes parts marked †)



B. Chain Brake Assembly #530 01 07-94

KEY NO.	PART NO.	DESCRIPTION
1	530 01 53-21	Screw
2	530 01 51-23	Washer
3	530 01 15-76	Actuating Lever
4	530 02 53-66	Latch
5	530 01 55-48	Pin - Spiral - Band Anchor
6	530 01 52-64	Pin - Latch Pivot
7	530 01 51-45	Roll Pin
8	530 06 91-43	Latch Roller - Kit
9	530 01 15-75	Bar Clamp
10	530 02 41-54	Brake Band Assembly
11	530 01 53-22	Pin - Band Anchor



✓ = Part Change
◇ = New Part No.