




Ref. No	Part No.	Part Name	Q`ty	Remarks,Serial No.
1- 1	70144-12110	CYLINDER	1	
2	20018-12120	GASKET	1	
3	11022-05160	BOLTSPW	3	
4	11022-05350	BOLTSPW	1	
5	20110-12211	INSULATOR	1	
6	20110-12221	GASKET	1	
7	20024-12260	NUT	2	
8	11022-05300	BOLT SW	2	
9	70135-15100	MUFFLERSUBASSY	1	
10	70135-15110	*MUFFLER	1	
11	70103-15150	*SPARKARRESTER	1	
12	01270-03062	*SCREWTAPPING	1	
13	20018-15150	GASKETMUFFLER	1	
14	01020-05500	BOLT	2	
15	01610-05080	WASHER	2	
16	01020-05120	BOLT	1	






2- 1	20018-21100	CRANKCASESCOMP	1	
2	20018-21111	*CRANKCASES	1	
3	12900-60010	*BEARING	1	
4	22150-21250	*OILSEAL	1	
5	20110-21201	CRANKCASEMCOMP	1	
6	20018-21122	*CRANKCASEM	1	
7	12900-60010	*BEARING	1	
8	20000-21211	*OILSEAL	1	
9	12492-40080	*ROLLER	4	
10	01020-05250	BOLT	3	
11	62011-31011	FANCOVERCOMP	1	
12	20134-31111	*FANCOVER	1	
13	02006-06000	*BEARING	2	
14	02432-26120	*SNAPRING	1	
15	20018-31330	*CLUTCHDRUM	1	
16	22000-13320	*SNAPRING	1	
17	20110-31130	*CUSHION	1	
18	11022-05160	BOLTSPW	2	
19	11022-05300	BOLT SW	2	
20	70192-31510	EARTHCORD	1	
21	62011-32010	CYLINDERCOVERCOMP	1	
22	20134-32110	*CYLINDERCOVER	1	
23	20134-32130	*PLUG	1	
24	11022-05160	BOLTSPW	2	
25	20018-31410	JOINT	1	
26	20018-31420	FRONTCUSHION	1	
27	20018-31430	REARCUSHION	1	
28	11023-05250	BOLT SW	1	
29	20018-31460	SHIM	1	
30	70135-31470	CAP	1	
31	20024-83152	CABLEHOLDER	1	
32	11022-05200	BOLTSPW	4	
33	70201-83130	CORD	1	
34	70201-32120	LABELTRADE	1	





3- 1	20000-41111	PISTON	1	
2	20000-41210	PISTONRING	2	
3	20000-41310	PISTONPIN	1	
4	20000-41320	SNAPRING	2	
5	37019-41230	NEEDLEBEARING	1	
6	37019-41240	THRUSTWASHER	2	
7	20018-42000	CRANKSHAFTASSY	1	
8	70140-51102	CLUTCHSHOEASSY	1	
9	70140-51113	*CLUTCHSHOE	2	
10	37013-51310	*COILSPRING	1	
11	20087-51210	*BOLT	2	
12	20087-51231	*SPRINGPLATE	2	
13	22100-71430	*WASHER	2	






4- 1	20018-71200	ROTOR	1	
2	02403-03100	KEY	1	
3	20035-71220	NUT	1	
4	20029-71600	COILASSY	1	
5	70201-71640	CORD	1	
7	20010-72221	PLUGCAP	1	
8	20000-72241	PLUGCAPCOVER	1	
9	20000-72250	COVERBAND	1	
10	70180-72260	SHIELD	1	
11	20000-72230	SPRINGSPARKPLUG	1	
12	20089-83120	TUBE	1	
13	13000-13506	SPARKPLUGBPMR6A	1	
14	70030-71620	INSULATOR	2	
15	11024-04261	BOLTSLPW	2	








5- 1	70102-75101	RECOILSTARTERSUBASS	1	
2	70102-75111	*STARTERCASE	1	
3	20024-75120	*REEL	1	
4	20024-75130	*RECOILSPRING	1	
5	20035-75170	*SCREW	1	
6	20024-75140	*WASHER	1	
7	20024-75160	*ROPE	1	
8	20024-75190	*STARTERKNOB	1	
9	20024-75180	*DAMPER	1	
10	20024-75200	STARTERPULLYSUBASS	1	
11	20024-75210	*STARTERPULLEY	1	
12	20024-75220	*RATCHET	1	
13	20024-75230	*RETURNSPRING	1	
14	20024-75240	*ERING	1	
15	20035-43230	NUT	1	
16	11022-05200	BOLTSPW	2	
17	11022-05250	BOLTSPW	2	
18	19420-00026	LABELTRADE	1	






6- 1	70144-81021	CARBURETORSUBASSY	1	
2	70144-81340	*BODYTOPCOMP	1	
3	20019-81120	*SCREW	1	
5	70144-81320	*ELBOWASSY	1	
6	20055-81810	**CABLEADJUSTER	1	
7	20000-81260	**LOCKNUT	2	
8	70144-81330	**ELBOW	1	
9	20003-81140	*THROTTLESPRING	1	
10	20000-81150	*SPRINGRECEIVE	1	
11	70144-81170	*JETNEEDLE	1	
12	20019-81182	*THROTTLEVALVE	1	
13	20019-81280	*RINGGASKET	1	
14	72920-81820	*SPRING	1	
15	20019-81310	*SLOWSTOPSCREW	1	
16	20040-81430	*SPRING	1	
17	20019-81440	*NEEDLEVALVE	1	
18	20019-81450	*CONTROLLEVER	1	
19	20011-81460	*PIN	1	
20	20011-81470	*SCREW	2	
21	20019-81510	*GASKET	1	
22	20019-81520	*DIAPHRAGMSSY	1	
23	20019-81530	*COVERDIAPHRAGM	1	
24	20000-81540	*SCREW	4	
25	20019-81560	*PLATE	1	
26	20019-81570	*CHECKVALVE	1	
27	20019-81580	*GASKET	1	
28	20011-81680	*SPRING	1	
29	20019-81610	*PUMPPLATE	1	
30	20019-81620	*DIAPHRAGMPUMP	1	
31	20019-81630	*GASKET	1	
32	20019-81641	*PUMPCOVER	1	
33	20019-81660	*GASKET	1	
34	20019-81670	*COVERDIAPHRAGM	1	
35	20019-81680	*SCREW	4	
36	20110-83431	GASKET	1	
37	20134-82100	CLEANERBODYCOMP	1	
38	20134-81711	*CLEANERBODY	1	
39	20115-82121	*CHOKEPLATE	1	
40	20115-82130	*CHOKELEVER	1	
41	20110-82140	*CHOKESHAFT	1	
42	20024-81790	*CONEWASHER	1	
43	11524-06211	*UNUT	1	
44	19404-00008	*LABELCHOKE	1	
45	62028-82310	NET	1	
46	60028-98010	FILTER	1	
48	20024-81770	CLEANERCOVER	1	
49	20115-81780	KNOBCLEANERCOVER	1	
50	22100-82430	ORING	1	


51	20024-81790	CONEWASHER	1	
52	01020-05600	BOLT	2	
53	01600-05131	SPRINGWASHER	2	
54	01610-05080	WASHER	2	
55	20024-83111	THROTTLECABLE	1	
56	70201-83140	TUBE	1	
57	20005-83160	CABLECAP	1	







7- 1	70223-85000	FUELTANKASSY	1	
2	20018-85113	*FUELTANK	1	
3	70168-85201	*FUELCAPASSY	1	
4	70168-85210	**FUELCAP	1	
9	20000-85221	**GASKET	1	
10	20018-83311	*PIPE	1	
11	20020-85540	*CLIP	6	
12	20019-83320	*SPRING	1	
13	20019-85351	*GROMMET	1	
14	20110-85320	*FUELPIPE	1	
15	22115-85401	*FUELFILTERSUBASSY	1	
16	20110-83311	*PIPE	1	
17	20035-85522	*VALVE	1	
18	72933-85620	*JOINT	1	
19	20019-85600	*PUMPCOMP	1	
20	20018-86112	TANKHOLDER	1	
21	20018-86120	TANKCUSHION	4	
22	62902-85320	TANKGUARD	1	
23	11022-05180	BOLTSPW	2	











8- 1	37094-62010	OUTERPIPECOMP	1	
2	22420-12120	*BUSH	5	
3	63901-62140	GRIP	1	
4	22000-12413	MAINSHAFT	1	
5	33008-62340	HANGERASSY	1	
6	33008-62321	*COLLAR	1	
7	33008-62151	*HANGER	1	
8	33008-62311	*CLAMP	1	
9	11203-04160	*SCREWPM	1	
10	01500-04031	*NUT	1	
11	65006-62310	PROTECTOR	1	
12	63052-62020	THROTTLELEVERASSY	1	
13	72549-62320	*BODYRIGHT	1	
14	63002-62330	*BODYLEFT	1	
15	63002-62340	*LEVER	1	
16	63901-62352	*LOCKLEVER	1	
17	63002-62350	*HOLDER	1	
18	63880-65350	*COILSPRING	1	
19	63901-62370	*COILSPRING	1	
20	63052-62310	*SWITCH	1	
21	63880-65360	*SCREWTAPPING	3	
22	11206-05201	*SCREWPMSPW	1	
23	01501-05030	*NUT	1	
24	63880-65411	*PLUG	1	
25	70871-65180	*COILSPRING	1	
26	70871-65170	*BUTTON	1	
27	19402-00223	LABELCAUTION	1	
28	19422-00010	LABELCAUTION	1	
29	19404-00037	LABELDECIBEL	1	
30	72017-12150	HANDLELABEL	1	








9- 1	63030-63023	GEARCASESUBASSY	1	
2	22420-13110	*GEARCASE	1	
3	02036-00608	*BEARING	1	
4	37074-63310	*BEARING	1	
5	22420-13140	*OILSEAL	1	
6	02432-28120	*SNAPRING	1	
7	01014-06100	*BOLT	1	
8	01610-06080	*WASHER	1	
9	22495-13210	*GEARSHAFT	1	
11	22000-13230	*COLLAR	1	
13	02000-00609	*BEARING	1	
14	02002-00609	*BEARING	1	
15	22420-13350	*SNAPRING	1	
16	02432-24120	*SNAPRING	1	
17	11022-05160	*BOLTSPW	1	
18	11022-05350	*BOLTSPW	1	
19	22000-13420	*SHIM	1	
28	60088-98310	*GEARSET	1	
20	01613-05080	WASHER	1	
21	01500-05041	NUT	1	
22	72480-16130	LOWERCLAMP	1	
23	22420-13510	HOLDERA	1	
24	37019-63170	HOLDER	1	
25	22000-13290	BOLTGUARD	1	
26	22000-13512	BOLT	1	
27	22000-13530	SLIDEPIN	1	






10- 1	60904-98310	HANDLEASSY	1	
2	62901-64113	*HANDLE	1	
3	65011-64120	*BARRIER	1	
4	11022-05350	*BOLTSPW	4	
5	22420-16120	*NUT	4	





11- 1	62903-66321	GUARDSET	1	
2	62903-66110	*GUARD	1	
3	62903-66331	*SUBGUARDASSY	1	
4	72480-16121	**CUTTER	1	
5	11020-05160	**BOLTSW	2	
6	22420-16120	**NUT	2	
7	72480-16210	*UPPERCLAMP	1	
8	72480-16220	*SPACER	2	
9	11022-05450	*BOLTSPW	4	
10	22421-17202	STRAPASSY	1	
11	22421-17130	*HOOK	1	
12	22007-17220	*PROTECTOR	1	








12- 1	22410-91000	TOOLSET	1	
2	22000-91181	*PLUGWRENCH	1	
3	09026-04001	*HEXAWRENCH	1	
4	22000-91120	*SPANNER	1	
5	19639-01400	*TOOLBAG	1	





13- 1	22550-92310	BLADECOVER	1	
-------	-------------	------------	---	--

